

# Starfish PPS

## Complete Catalog

Updated May 17, 2026

Contact:

Marc Webb

903-245-4684

marc.webb@starfishpps.com

Part Number	Description
00-35412-2-600FL-SS-53-S6-FTS-S/A	Water Injection Valve
000	Differential Pressure Transmitter
0004-2500-770	Gasket
0004-3003-830	Sealing ring
0004-3004-830	Sealing ring
0007-2573-750	Gasket
0007-2608-750	Gasket
0011-6208-000	Grooved ball bearing
0013-3137-060	Collar nut
0019-6202-150	Allen screw
0021-2858-000	CLUTCH SHOE 60 Hz
0026-1659-000	Centering disk
0026-5682-170	Fan-type lock washer
0026-5871-170	Retaining ring
003015G27-001	SHAFT
00355V195-001	PIN
0038-0035-096	Coupling
0038-0056-096	Coupling
0038-9098-096	Coupling
00380035096	Coupling
00380056096	Coupling
00389098096	Coupling
004-304661-008	HEATER
004-304661-012	Heater
004120J33G0001	OIL DEFLECTOR
005418-003	TRANSMITTER
00638A386-004	GASKET
00647A857-001	GASKET
00655A770-010	O-RING
00655A770-014	O-RING
00655A770-115	O-RING
00655A770-124	O-RING
00655A770-126	O-RING
00655A770-132	O-RING
00655A770-135	O-RING
00655A770-214	O-RING
00655A770-216	O-RING
00655A770-236	O-RING
00655A770-242	O-RING
00655A770-244	O-RING
006607-018	DETECTOR, GAS TRANSMITTER
006618-001	
006748-002	CAL CUP-REMOTE, SSTL SCREENS, Transmitter, combustable gas

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
006748-006	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
006748-008	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
006817-001	Board, PC, 505, 125OHM
006817-002	Board, PC, 505, 500OHM
006824-001	SENSOR, GAS
006824-002	SENSOR, GAS
006824-003	SENSOR, GAS
006824-004	SENSOR, GAS
006824-005	Gas Sensor
00705-A-1735	Sensor
007168-001	Detector, Gas
007168-002	Detector, gas
007168-014	PIRECL Infrared Hydrocarbon Gas Detector
007168-015	Gas Sensor
007168-205	Gas Detector
007290-001	Flame Sensor Mounting Arm
007371-003	MODULE. DCIO, DIN RAIL
007609-462	Controller
007800-001	Software
007800-011	KIT, SOFTWARE
0078D25N00A025T34E6	TEMP, ELEMENT
0078N21N00N050C5	Temperature Sensor
0078N25N00N020E6B3	SENSOR, SPRING LOADED TEMP
0078R2500A020T32	RTD Rosemount
0078R25N00A020	RTD, Dual Platinum
0078R25N00A025T34E6	Temp sensor, GLO
0078R25N00A120T22E5	RTD, Dual
0078R25N00N120E6	Sensor, temp
008700-006	SENSOR, FLAME
00870B450-001	RETAINER DU
008716-001	SENSOR, FLAME
009174-003	MODULE, EDIO
009700-001	TOOL, MAGNETIC
01-441-071	Bearing
010-588-20-A040	Power Supply
010252-003	DISPLAY, RELAY
010254-002	Display
010254-005	DISPLAY, DCU
010254-006	DISPLAY, DCU
010271016-686-0000	Diaphragm
010535-001	MODULE, DISPLAY, UD10, EQP-DCU
010569-001	MODULE, DISPLAY, UD10, RELAY/4-20mA
0105C7213G3	MECHANISM
01063J94P0001	Lockplate
01066J70P0001	PLATE, LOCK
010765-006	Transmitter, DCU
01078J88P0001	Bolt
0108B1931R005	Secondary Disconnect
010973-001	REPLACEMENT BOARD
01104-TC-335	Thermocouple, Wheelspace
01141J37P0018	SPRING, PACKING
01141J37P0023	SPRING, PACKING

Starfish PPS - Complete Catalog

Part Number	Description
01141J37P0024	SPRING, PACKING
01141J37P0025	Packing Spring
01141J37P0031	Packing Spring
01141J37P0032	Packing Spring
01141J37P0033	Spring, Packing
011534226-999-0000	Packing Kit
0116B6708G3B	Lamp, Blue Lens
0116B6708G3E	Indicating Lamp, Red Lens
01184J49P0001	SCREW,SET
01184J49P0007	Screw
0137B235G0004	Diaphragm, Relief
0137B729P0001	Bushing
014046-243	Gas Detector
01414-521401002	ASSEMBLY: FILTER, TURBINE LUBE OIL
014394-001	Combustible Gas Transmitter
01518-0150-1001	ASSEMBLY: FILTER, GENERATOR LUBE OIL
0154HN-1	SENSOR, P2/T2
0154LT4	T23/P23 SENSOR
01610.0-01	Heater
0180046-013	Power Supply
018713194	Thread Lock
02-00125	SR Drive Panel ; POWER CONVERTER FOR VSR175
02013J29P0001	Valve Stem
02028J49P0001	Heater, Strip
020481000042	INSERT, SPIDER
02101SP001	Speed Probe
021181448	Washer, M12 "C"
021189157	Disk Spring
021189267	Disk Spring
02122J34P0001	Plug
02122J37P0001	Plug
021815109	Cap head screw
021815168	Cap Hd screw
021815169	Cap Hd screw
021815172	Cap Hd screw
021844065	Screw
02186J31P0012	Gasket
0237C0473G009	Secondary Disconnect
0247A390P0008	PLATE, LOCK
0247A390P0011	Lock Plate
0247A390P0012	Bolt
024907	WASHER, TAB (M20)
02518-520502001	ASSEMBLY: FILTER, GENERATOR LUBE OIL
025564632	Connector, male, straight, 1/2"
025564633	Connector, male, straight, 3/4"
025566381	Conduit, elbow, LR17
0263X0592G009	ASSEMBLY: SWITCH, AUX, W/ MECHANISM
0269A369034R	PHILA AUXILIARY SWITCH STATIONARY
0269A369034T	PHILA AUXILIARY SWITCH STATIONARY

## Starfish PPS - Complete Catalog

Part Number	Description
028100-034	DETECTOR, FLAME
028247-001	DETECTOR, FLAME
028247-034	DETECTOR, FLAME
0282A2009G002	Coil, Electrical
0282A2009G008	Coil, Electrical
0291A6820AAP072	MODULE, COMBO, ANALOG
0291A6820AAP073	MODULE, INPUT, DIGITAL
0291A6820AAP074	MODULE, OUTPUT, RELAY
0291A6820ACP007	CONTROLLER, HIGH SPEED
0291A6820ACP008	BASE, 12 SLOT
0294A937P0007	Rivet
0295V749P0001	Dowel
03031-0189-0003	KIT, MOUNTING, 3051
03035J85P0001	Cover, Valve
03035J88P0001	Bushing, Valve
0305RC32B11	Manifold, for Pressure Transmitter
0306-N-04-SS	Jam Nut
030G10A8	GASKET, RING
0314A3290P0003	Bushing
031G10A6	GASKET, RING
031G10A8	GASKET, RING
0356C317G0002	Seal, Deflector
0360-02-00-0150	GASKET
0360-03-00-0150	GASKET
036348	Switch, Vibration
03666789P0006	PLATE, ., LOCK, 1-1/4" WD X 4" LG X 1/16" THK, STEEL
03666789P0007	LOCKPLATE
03666789P0013	Lock Plate
0391-00-004	O-RING
0391-00-024	O-Ring
0391-00-038	O-RING
0391-00-119-T	O-Ring
0391-00-123-T	O-Ring
0391-00-124-T	O-Ring
0391-00-136-T	O-RING, HILLIARD
0391-00-168-T	O-Ring
0391-00-169-T	O-Ring
0391-00-170-T	O-RING
0391-00-204-T	O-RING
0391-00-288-T	O-Ring
0391-00-399-T	O-RING
0391-00-402-T	Gasket, Cover
0391-00-463-T	O-RING
04-00059	Sensor, RPT VSR100 / VSR175
04-00209	Board, Temperature Sensor, VSR100 / VSR175
04-060-00	PH PROBE
04036J18P0001	Disc, Valve
0405-03-007-T	SCREW, HILLIARD
04089J46P0056	THERMOCOUPLE, CASING
04110J75P0047	Thermocouple
0429B299G0006	Valve Stem Guide ASM
0431B501P0040	Screw

## Starfish PPS - Complete Catalog

Part Number	Description
0431B502P0034	Screw
0432B515P0004	Valve
0432B570P0001	PISTON
0437B524P0001	VALVE
04804856P0055	Packing Lock
049880-005	Filter, Inlet
05-00020	Buss Bar, Laminated - VSR175
05-00027	GATE DRIVE SUB-ASSEMBLY PCB, VSR100 / VSR175
05-00030	PCB, DISPLAY, W/O FACIA (PCB42); VSR100 / VSR175
05-00105	Board, Flashing LED, VSR100 / VSR175
05-00207	CONTROL BOARD(PCB94), VSR100 / VSR175, M2
05-00213	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
05343739P0002	RING, PISTON, 9-1/2"ID X 10-1/4"OD X 1/2"THK, BRONZE
0553-00-126-T	1/4" Ball Valve
05549676P0002	Screw
05549676P0007	Screw
0562-02-020-C	8" Check Valve
05PV50CDRX-22CCCXX01	Breaker
060-1042-08G	TRANSDUCER, PRESSURE
060-1083-04	TRANSDUCER, PRESSURE
060-1083-11-07	TRANSDUCER, PRESSURE
060-1083-13-03	TRANSDUCER, PRESSURE
060-308-154	Pump, Lube and Scavenge
0625-00-184-T	Pressure Blower
0631A539P0001	Spring
0632A933P0005	Ring
0636A369P0002	Gasket
0638A528P0001	Bushing
0647A136P0002	Bearing
0649A219P0001	Spring
0652L277G0010	Seal, Hydrogen, Turbine End, Set
0657602	Gearbox, RotoJet
0657603	GEARBOX, ROTOJET
0657603-AR	GEARBOX, AS REMOVED
0657604	GEARBOX, ROTOJET
0657605	GEARBOX, ROTOJET
0657606	GEARBOX, ROTOJET
0657607	GEARBOX, ROTOJET
06658978P0001	Spring
0685C0810G004	Elevating Motor, 120VAC/125VDC
07-00156	Cable, 9-Way D-Type, Female/Female VSR100 / VSR175
07-00263	Cable; VSR100 / VSR175
07-00775	Cable VSR100 / VSR175
07-1ZLC-PM-IS	Mini-Z-Purge System
0719A318P0007	LOCK PLATE
0719A679P0013	LOCK PLATE
0719A679P0022	LOCK PLATE
0719A817P0002	Weight
072-1603-70	Servo Valve
0728C775P0002	Gasket
0731B820P0002	Bearing

Starfish PPS - Complete Catalog

Part Number	Description
075528-2733	SET, BALANCED FASTENER
075528-2929	PT Coupling Fastener Kit
075528-2990	BALANCED FASTENER SET
075528-3675	SET, BALANCED FASTENER
0771A136P0326	SCREW, MOUNTING
0776654	Kit, Seal
0784E431G0001	Deflector, Oil
0789E879G0002	Oil Deflector
0789E891G0001	Oil Deflector
08-00002	IGBT DF200R12KE3 VSR100 / VSR175
08-00003	IGBT FD200R12KE3 VSR100 / VSR175
08-00040	Thyristor, Diode Module, VSR
08-00041	Thyristor, Diode Module
08-00114	IGBT VSR100 / VSR175
08-00115	IGBT VSR100 / VSR175
080855-DR6D89A	5HP 3PH 240V REGEN ASSY
08382818-1-1 SHAFT	SHAFT, GENERATOR COMPT FAN
08501375-42	Thermocouple,
0870B672P0001	BUSHING, STEAM SEAL REGULATOR
09-00002	CAPACITOR .47UF 1200V for VSR100 / VSR175
09-00023	Capacitor, Fan VSR100 / VSR 175
09-00031	CAPACITOR 3300UF 400V VSR100 / VSR175
0930B432P0005	Valve Seat
09448530P0001	Bolt-Pin
09449090P0004	LUG,CENTERING
09449090P0031	Lug
09449090P0032	LUG
0946	E-SEAL, RING
0950-00-025-T	Spring, Stainless Steel
0950-00-028-T	SPRING, STAINLESS
0951-04-022-A	PAD, SEALING
09895319G0001	DEFLECTOR, OIL
1 1/2CFRJ11002F	3 Way Thermostatic Valve
1 1/2CFRJ13002F	THERMO VALVE
1 1/2CFSJ10002	Thermo Valve
1 1/2CFSJ11002	Thermo Valve
1 1/2CFSJ14002	Thermo Valve
1"CPT4466TSEA.125	Valve, Control
1-011-30-305	Gage Repair Kit
1-024553	Gasket, Cylinder Cover
1-1/2CFRJ11002F	3 Way Thermostatic Valve
1-1/2CFRJ13002F	THERMO VALVE
1-640-01-3012	Aluminum Plate
1-73-R-20-AD	Flow Meter
1.2X2.6X100M	Basket, Strainer
1.2X2.6X100m	Basket, Strainer
1.5F2JLTJOS-EOR15S6A	Relief Valve
1/2HHCSUNSSPA	BOLT HEX, 1/2" - 13NC X 1 1/2", 304
1/2INCH-S2000	Valve, Ball, Stainless
1/4MW085-SW	NOZZLE, AMMONIA
1/4P48	NOZZLE, FOG, AMMONIA

Starfish PPS - Complete Catalog

Part Number	Description
1/4PJ36	NOZZLE, AMMONIA
10-0042-004	Thermocouple
10-0551-1-135-200	Thermocouple, Wheelspace
10-0551-2-330-200	Thermocouple, Wheelspace
10-0551-2-332-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-333-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-335-200	Thermocouple, Wheelspace
10-0551-2-336-200	THERMOCOUPLE, WHEELSPACE
10-0551-2-337-200	Thermocouple, Wheelspace
10-0551-4-672-200	Thermocouple, Wheelspace
10-0589-001-200	Thermocouple, Exhaust
10-0620-012	THERMOCOUPLE, WHEELSPACE
10-0639-001-210	THERMOCOUPLE, WHEELSPACE
10-0639-002-210	THERMOCOUPLE, WHEELSPACE
10-0639-004-210	THERMOCOUPLE, WHEELSPACE
10-0651-003	Thermocouple type K.ext.
10-0651-005-210	THERMOCOUPLE, WHEELSPACE
10-0879-001	THERMOCOUPLE, WHEELSPACE
10-0879-001-210	THERMOCOUPLE, WHEELSPACE
10-1008-S-028-5000	Gauge
10-1094-022-200	Thermocouple, Exhaust
10-1094-022-200-AR	THERMOCOUPLE, AS REMOVED
10-1222-G-001	RTD, Dual
10-127598	Brush, Carbon
10-1578-001-210	Thermocouple, Immersion, EGT, FT8
10-2859-031-210	Thermocouple
10-319987	Insulator, Tube, Ceramic, Unison
10-3634-022-210	Thermocouple, Exhaust
10-3634-022-210-AR	THERMOCOUPLE, AS REMOVED
10-392775-4	Exciter, Ignition
10-392775-5	Exciter, Ignition
10-630225-1	PLUG, IGNITER
100-0041-002	Thermocouple
100-C23E*10	BREAKER
100-DA	Diaphragm Kit
1000191348	GASKET, RING
1000208778	GASKET, FLANGE, FUEL NOZZLE, 1IN, 600LB
1000224	Strainer, 1 1/2
10003-1566	Seal Pad
1000600	Strainer
10007632	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
10014-005	KIT, REPLACEMENT PARTS
10014-061	Rebuild Kit for Transfer Valve
10014-113	Repair Kit for Transfer Valve
10014-122	Rebuild Kit for Transfer Valve
100191879	GASKET
1002204	Strainer
10056005002	STRIKER
1007-3-14	T3 Sensor
1008-4446	ADJUSTER - PISTON STROKE
100P44C3	Adjustable Pressure Switch

Starfish PPS - Complete Catalog

Part Number	Description
100P44C6NR	Switch, Pressure, Adj.
100P44C6R	Switch, Pressure, Adj.
100P47C6B	SWITCH, PRESSURE
100P4S1548-056	Switch, Pressure
100P4S1548-066	Switch, Pressure
100T3595P001	Retention Wire
100T3856P001	Combustor Tip Support
100TC5DC6NR	Switch, Temperature
100TC5DC6R	SWITCH, TEMPERATURE
100TC5DCC6NR15	SWITCH, TEMPERATURE, ADJUSTABLE
100TC5DCC6R15	SWITCH, TEMPERATURE, ADJUSTABLE
100TC5FC6R	SWITCH, TEMPERATURE
101-2103	Weatherstripping, window
1011-05	GASKET, WEATHERSTRIP
1011-06	GASKET, WEATHERSTRIPPING
101109	Aerokroil
1011D-100	BODY, EX PACK
1013673	CABLE, VIBRATION
1013675	CABLE, ELECTRICAL, VIBRATION
1013680	CABLE, OFF-ENGINE
1013683	CABLE, OFF-ENGINE
1013692	CABLE, XN44A LPC-IPT ROTOR SPEED
1013699	CABLE, OFF-ENGINE
1014035	CABLE, OFF-ENGINE, TM2500
10150194	RELAY, DPDT
1015612	Plug, Valve, 4"
10170011	Switch, Pressure
1018363	Gasket
101A293AR-14	Relief Diaphragm
101A362BK-2601	GASKET, SPIRAL WOUND, GRAPHITE FILL, 3/16" THK,
101A636AF-1	BOLT, , 1" DIA, 3-1/4" LTH, 8UN, BRONZE ALLOY, HEX H
101A743CR-1	PIN, DOWEL, 1/4" DIA, 3/4" LTH, FERROUS METAL
101A750FA-1	GASKET, ., OIL FILTER, 8"ID X 8-3/4"OD, RUBBER, ROUN
101A782AD-102	SINGLE GASKET, SPIRAL WOUND, , PIPE, 2500LB, 2-1/32"ID X 2-
101T6088P0001	Valve Disc
101T6089P0001	Valve Pin
101T6097P0002	Pin
101T6358P004	Valve, 8" Butterfly, Left
102044-0-18-10-02-05	PROBE 3300 DRESSER RAND
1020G20	Coupling
1020G20-1020G	Coupling, Water Injection
102109LP	SWITCH/PUSHBUTTON,AC SWITCH,,BREAKER AUX SWITCH
102147	SURGE PROTECTOR 12A12
1027-1-11	RTD, Detector, Resistance Immersion
1027-2-12	RTD, Detector, Resistance Immersion
10287347	FLEX ELEMENT FOR ALTERNATE COUPLING
102T2262P203	Rotary Positive Blower
102T8993P002	Valve, Gas Fuel Control
103656001POS570	Valve, Check
103M2215P0006	LINKNET-HT, MODULE

## Starfish PPS - Complete Catalog

Part Number	Description
103M2215P0008	LINKNET-HT
103M2719P0001	Driver, Woodward
103M2719P0002	DIGITAL VALVE POSITIONER, 125VDC, IP30
104C1150P001	BEARING, TURNBUCKLE
104T2321P0001	Plug
104T3771P001	VALVE, CHECK
104X109AD109	FUSE, 2AG, 1.5A, 250 V
104X123DE 016	Resistor
104X123DE016	Resistor
104X125AA175	DIODE
1050-11	Clamps, Set, 6"
1051-02	Flex Hose, 6" x 10'
1053V3	Valve, Globe
105PP1S904	SWITCH, PRESSURE
1060T10	Kit, Seal
1066-C-HT-69	Analytical 1066 Liquid Analytical Transmitter
106765-07	CABLE VELOMITOR XA
106C7156P04	CAN, TRANSPORT, LM2500, UNIVERSAL
106M1079-01	MODULE, POWER SUPPLY, AC
106M1081-01	MODULE, POWER INPUT, AC
1071-03E	PROP, 42B725
107A8324P0035	Lockplate
107A8327P0050	Lock Plate
107C6638P0063	SHIM PLATE, THRUST BRG TURBINE END
107C6638P0064	SHIM PLATE, THRUST BRG GENERATOR END
107T2251P0001	QD ANODE/CATHODE, INPRO 6800
1080274	Cable - Exciter, Left Spark Ignition
1080275	Cable - Exciter, Right Spark Ignition
1081194	Seal, T/C
1081197	Gasket
1081198	Gasket
1081669	Valve, Check
1081670	Valve, Check
1081873	Wire Harness Assembly, N1 Sensor
1081976	Hose
1081978	Hose
1081981	Hose
1082126	Thermocouple, Immersion, EGT, FT8
1083362	Igniter, plug
1084918	Actuator, IGV
1084936	Harness, FT8, Engine, Left
1084939	FILTER, HYDRAULIC PUMP
1084940	Clutch
1084947	VALVE, SERVO, HYDRAULIC
1085280	Bolt, Coupling
1085281	Nut
1085282	Washer, Insulating
1085283	Washer
1085415	Locknut
1085457	Bolt, Coupling
1085998	Transducer (N3) - Motional Speed

Starfish PPS - Complete Catalog

Part Number	Description
1087MKS-1BLONG	Strut, flow enhancer
1087MKS-1GMEDIUM	Strut, flow enhancer
1087MKS-1MSHORT	Strut, flow enhancer
1088025	Valve, Flow Divider
1088046	Speed Probe
1088177	Igniter, plug
109B4683G001	7E COMPRESSOR BOLT SET
109E3763G005	PROBE, FLEX, 3300 XL 8MM
109E3763G006	Cable, Proximitor
109E3763G007	KIT - Probe, Proximity Assy, 3300XL, W/Extension Cable
109E3763G033	Proximity Probe
109E3763P201	Vibration Probe
109E3763P202	Vibration Detector Probe
109E3763P300	Key Phaser or Vib Probe
109E3763P500	Probe
109E3763P502	3300 XL 8MM
109E3763P600	Cable, Proximity
109E3763P602	Cable, Proximitor
109E3763P610	Probe
109E3763P700	3300 XL 8mm Proximitor Sensor
109E3763P702	3300 XL 5/8mm Proximitor Sensor
109E3763P703	SENSOR, PROXIMITOR, 3300XL, 5/8MM
109E3763P809	Booster, LMS100
109E3763P812	Probe
109E3763P813	Probe
109E3763P952	Probe
109E3763P953	Probe
109E6646G0001	Heater, Strip
109E9348G006	SPARK PLUG, BALL JOINT
10AX002G0006	SWITCH
10AX002G10	PHILA AUXILIARY SWITCH STATIONARY
10AX002G3	PHILA AUXILIARY SWITCH STATIONARY
10AX002G6	SWITCH
10F10M511M201	SWITCH, PRESSURE
10G559	Weatherstripping, window
10P053	Valve, Balance
10SV11NC30	Sprint Pump
10SV12NC30	SPRINT Pump
10SV17NC10	PUMP/MOTOR
10SVR120	Stack Kit
11-0019-001	SEAL, GLAND
11-0019-002	SEAL, GLAND
11-0019-003	SEAL, GLAND
11007L001	O-RING BUNA N
11009L001	O-RING BUNA N
1100M65G16	GASKET
110100-139	Packing
110181-14	CLOSURE

Starfish PPS - Complete Catalog

Part Number	Description
110181-16	CLOSURE
110194	BEARING, SHELL TE
110195	BEARING, SHELL CE
110196	SEAL, RING, INSIDE TE
110198	SEAL, RING, OUTSIDE TE
110199	SEAL, RING, INSIDE CE
110201	HEATER, GENERATOR
110202	HEATER, EXCITER
110213	AIR THERMOMETER
110231	THERMOMETER, OIL DRAIN
110236	PRESSURE TRANSMITTER AIR
110239	SET OF GASKET FOR SILENCER
110909A	Aerokroil
110C1032G1	SE-Breaker Operator Sub-Asm
110M3255P0060	CABLE, PACK PWR, GRY/WHT 60IN
110P12C6B	Switch, Pressure
1112SD	SNUBBER, PRESSURE
111571	DIODE-MODULE, POSITIVE
111572	DIODE-MODULE, NEGATIVE
111605020	VALVE, BALL
111E2906P0146	Screw
1122601	RTD, Detector, Resistance Immersion
112P12C6B	Switch, Pressure, 10"-120"
112T1672P0001	Valve, RELAY, PILOT OPERATED DIRECTIONAL VALVE
11300216	Yarway SAS BOA , PCB
11305	Pump Repair Kit
113T1089P0005	CABLE, RTD, J2 BEARING TEMP
1141J37PT23	SPRING
114A2212P001	Connector, Wire (box of 100)
114A2212P003	Connector, Wire (box of 100)
114A3517P001	Valve Seat
114A3759P001	Valve
114A6734P004	PLATE, LOCK
114A6734P007	Lock Plate
114CE0025TAB1SC017AXW	Thermowell

## Starfish PPS - Complete Catalog

Part Number	Description
114CE0120TAB3SC032AXW	Thermowell
114E1249P014	Cloth Seal
114E1249P015	Cloth Seal
114E6078G0002	DEFLECTOR, OIL, OUTER
114E8680G0002	Bearing, Liner
114M5330-01	Refresh Low DC Power Supply
114M5335-01	Refresh Low Voltage DC PIM
1150556	Turning Tool Adapter
115436-1	Hose, Flexible
115762	Hose, Convoluted
115763	Hose, Convoluted
115764	TUBE & HOSE, CONVOLUTED
1157M31P01	Bolt
115E1077P012	Fan
115E6237G001	Seal
115T8956P0001	GASKET
115T9361G0001	Spark Plug
115X108.9X1.5	RING, BACKUP, FILTER HOUSING
116B6708G3	LAMP, INDICATING
116T4955P0001	Bellows Seal
116T5990P0001	GASKET
117-305192-013	Heator, Stator
117T6409P025A	Switch, Ethernet
117T9031P0003	Gas Fuel Control Valve
117T9035P0003	Gas Fuel Control Valve
117T9037P0003	Gas Fuel Control Valve
118-78-00225484	HEATER
118700-1-1	Thermocouple, Immersion, EGT, FT8
118D6753P009	Gasket
1193J67P0001	Bushing
11A1AB4M5Q4	Transmitter
12 AWG XHHW	12 AWG XHHW SINGLE STRAND
12 AWWG XHHW	12 AWG XHHW SINGLE STRAND
12-00061	Transformer, Current - VSR100 / VSR175
12-00062	EM Filter
12-00083	Fan, Main Cooling, VSR175
120-0032P0001	Inline Pressure Transmitter
120-0156P0001	Strainer, 1 1/2
120-0158P0001	Ventilation Fan + Motor Assembly
120-0608P0001	RTD
120-5153P0001	Valve, Manifold
120-5726P0001	AC, 8000 BTU
120-5727P0001	AC, 6000 BTU
120-6963P0001	Valve, USOV
120-7033P0001	Gauge, Differential
120-9575P0001	FLAME TRACKER
1201-T1037	Differential Pressure Gauge
120321SP-FF03	Filter, Inlet Air
1204002	Gasket
120A352P001	Differential Pressure Regulator, 2", 300#
120A352PT.1	DIFFERENTIAL PRESSURE REGULATOR
120E8112G0001	Oil Deflector

Starfish PPS - Complete Catalog

Part Number	Description
121-0518P0001	Transformer, Current
121-1798P0001	Valve, Relief
121-3066P0001	Cable, DVP Feedback
121-3067P0001	Cable, Fuel Valve Feedback
121-3500P0001	Differential Pressure Transmitter
121-7333P0001	LM6000
	EXTERNAL MLO, TLO, HLO, JLO FLUSHING KIT BOM
121-9201P0001	Y-STRAINER
1211245-26	Actuator, VSV
1211425-002	ACTUATOR, VSV
1211425-002-OH	VSV Actuator
1211425-003	Actuator
1211425-003-OH	ACTUATOR, OVERHAULED
1211425-006	Actuator
1211425-007	Actuator
1211426-007	Actuator
1211427-007	Actuator
121T4154P0001	Exciter
122-1471P0001	Flow Meter
122732-002	Insulator
122809-001	O-Ring
122P82C6413NR	Switch, Pressure
122P84C6413NR	SWITCH, PRESSURE
122P84C6NR413	SWITCH, PRESSURE
122P84C6NR443	SWITCH, PRESSURE
122P87CC6443	SWITCH, PRESSURE
123765-03-80	Filter, Fuel
124T5712P0001	FLAME TRACKER
124T7623P2002	Valve
124T7741G0002	SCANNER, FLAME, DRY, DETECTOR, KIT
125-SS 2"-BSKT	Basket for Mueller 125 Strainer
125-SS 2"-GSKT	Gasket
125680-01	MODULE, I/O
125720-01	MODULE, OUTPUT, 4-CHANNEL RELAY
125736-01	MODULE, I/O
125744-01	MODULE, RACK INTERFACE, TMR
125744-02	MODULE, RACK INTERFACE, STANDARD
125760-01	MODULE, I/O
125768-01	MODULE, I/O
125792-01	MODULE, ENHANCED KEYPHASOR
125800-01	MODULE, I/O
125800-02	MODULE, I/O
125808-01	BLOCK, PROXIMITOR ET, EURO STYLE
125808-02	BLOCK, PROXIMITOR ET, EURO STYLE
125808-03	BLOCK, EXTERNAL TERMINATION
125808-05	Term Block
125808-08	Term Block
125840-01	MODULE, POWER INPUT
125840-02	MODULE, POWER INPUT
125D441AA-1	FILTER, OIL, 1/2"LG, 25 MICRON, SS MESH
126599-01	MODULE, I/O
126615-01	MODULE, I/O

## Starfish PPS - Complete Catalog

Part Number	Description
126623-01	MODULE, I/O
126632-01	MODULE, I/O
126640-01	MODULE, I/O
126648-01	MODULE, I/O
126648-02	MODULE, I/O
126957-01F	RACK, 3500, BENTLY NEVADA
126B5195P001	Gasket
126B5195P1	Gasket
127610-01	POWER SUPPLY, AC
1279-00-040-T	Retaining Ring
128015-01	BLOCK, PROXIMITOR ET, TERM STRIP
128229-01	MODULE, I/O
128240-01	MODULE, I/O
12833	RING, SEAL
128702-01	BLOCK, EXTERNAL TERMINATION
128718-01	BLOCK, EXT TERM, KEYPHASOR, EURO STYLE
128726-01	BLOCK, EXT TERM, KEYPHASOR, TERM STRIP
1288M66P04	STRIP, SEAL
1288M66P05	SEAL
128C306AA-1	VALVE, TURBINE BOILER FEED PUMP, 1-15/16" ID X 4" O.D., THRD, STEEL, NON-ASBESTOS
1293	Shunt 500A/50mV
12943	Seal
129478-01	MODULE, POWER INPUT
129486-01	POWER SUPPLY, HIGH VOLTAGE DC
1294M38P01	GASKET
1294M38P02	Gasket
1295-10-001-T	Demister Breather Filter
129525-0005-02	Cable
129525-0010-02	Cable
129529-0005-02	Cable, Bently
129530-0005-02	Cable, Bently
129530-0025-02	Cable, Bently
129595-0010-02	CABLE, B NEVADA
129715-138-040-05-05	PROBE, FLEX, 3300 XL 8MM
12976-06	Cable, Proximitor
129957-085-057-05	Cable, Proximity
129T6532P0001	Thermocouple
12A-F12L-50-BN-SS	Filter Valve
12A-F12L50-BN-SS	Filter Valve
12A-F16L-50-BN-SS	Valve, Check
12A-F16L50-BN-SS	Valve, Check
12B01ATS	Flame Sensor
12VF12-SS	QUICK COUPLING
1300 R 025 W/HC	Element, Filter, Hydac
1300R010 ON/-V-B6	FILTER, ELEMENT
1300R025 W/HC/-V	O-RING
1303M20P01	Pressure Probe
1303M20P02	Pressure Probe
130419-0025-02	CABLE, BENTLY
1304M52G03	Plug, Borescope, S2
1304M52G04	Plug, Borescope, S2

Starfish PPS - Complete Catalog

Part Number	Description
130539-20	Cable
130539-50	Cable
1306-629	Relief Valve
1311-1006	VALVE, SOLENOID
1311-1088	Solenoid
1311-917	Valve, Solenoid
1311-933	Valve, Solenoid
1311-933-AR	VALVE, SOLENOID
131151-01	Cable, Bently
131178-01	Cable, Bently
13220-1406	VALVE, SOLENOID,
1326-1014	Filter, Hydraulic
1326-8002	FILTER, HYDRAULIC, CARTRIDGE
1327-202	FILTER
1327-204	FILTER
1327M98P01	Bearing
132836386	PRESSURE TRANSMITTER AIR
132839079	THERMOMETER, BEARING SHELL
132839910	DIODE-MODULE, POSITIVE
132839911	DIODE-MODULE, NEGATIVE
132841338	Ground Brush
132844586	Grounding brush holder
132915957	BEARING, SHELL TE
132915959	BEARING, SHELL CE
132915960	SEAL, RING, INSIDE TE
132915985	SEAL, RING, OUTSIDE TE
132915992	THERMOMETER, BEARING SHELL
132915996	THERMOMETER, OIL DRAIN
132B7791G001	PIPING, PURGE AIR, 0909
132B7792G001	PIPING, PURGE AIR, 0909
132P41C6B	Switch, Pressure, Adj (Neo-Dyn)
132P41C6BNR	SWITCH, PRESSURE, ADJ
132P42C6BR	SWITCH, PRESSURE
132P44C6B	SWITCH, PRESSURE
132P44C6BNR	Switch, pressure

Starfish PPS - Complete Catalog

Part Number	Description
132P44C6BR	SWITCH, PRESSURE
132P46C6BNR	SWITCH, PRESSURE
132P46CC6BNR	switch, pressure
132P48C3R	SWITCH, PRESSURE
132P48C6BNR	Switch, Pressure, Adj.
132P48C6BR	SWITCH, PRESSURE
132P48CC3R	SWITCH, PRESSURE
132P48CC6BNR	Switch, pressure
132P49C6B	SWITCH, PRESSURE
132P49C6BNR	SWITCH, PRESSURE
132P4S129	Pressure Switch
132P4S185	SWITCH, PRESSURE
132P4S40-023	Pressure Switch
132P4S408-001	Pressure Switch
132P4S408-003	Pressure Switch
132P4S408-007	Pressure Switch
132P4S408-008	Pressure Switch
132P4S408-009	Pressure Switch
132P4S408-023	Switch, Pressure
132P4S408-102	Switch, Pressure
132P4S408-121	Switch, Pressure
132P4S408-123	Switch, Pressure
132P4S429	Pressure Switch
132T4FC6	SWITCH, TEMPERATURE
132T4FC6HNR	SWITCH, TEMPERATURE, ADJUSTABLE
132T4FC6NR	SWITCH, TEMPERATURE
132T4HC6	SWITCH, TEMPERATURE
1330-708	Pump, Gear
133292-01	POWER SUPPLY, LOW VOLTAGE DC
133300-01	MODULE, POWER INPUT
133323-01	MODULE, I/O
1333M60P01	Spacer
1333M60P02	Guide
1333M67P01	BEARING, ACTUATOR
1333M68P01	BEARING, SLOT LOADED, ACTUATOR, COMPRESSOR
1333M69P01	Bearing, rod end
1334498	GASKET
133572876	HEATER, GENERATOR
133572880	HEATER, EXCITER
1336M28P01	Bearing, Rod End
1337M46P03	Washer
133A1624P15	WASHER
133A1624P36	Washer
133A1624P37	Washer
133A1624P40	Washer
133A1624P48	Washer; 1/2
133A1624P6	Washer
133A1624P64	Washer
133A1624P67	WASHER

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
133A1624P7	WASHER, FLAT
1340M24P02	BOOT, DUST AND MOISTURE SEAL
1340M24P04	BOOT, DUST AND MOISTURE SEAL
1340M24P06	BOOT, DUST AND MOISTURE SEAL
1340M69P01	SEAL
1345M58G40	CLAMP
1347M18P01	BOLT, MACHINE, DBL HEX
134T4883P0001	O-RING
134T7506P0001	Adapter
134T8027P0001	Motor, Electric
1350-5019	EH Servo Valve for VSV ACTUATOR
1350-5027	Servo, LPC-IGV
1350-5274	Servo Valve
135031-01	MODULE, I/O
135473-01	MODULE, I/O
135489-01	MODULE, I/O
135489-02	MODULE, I/O
135489-03	MODULE, I/O
135489-04	MODULE, I/O
1355-1001	O-Ring
1355-107	O-Ring
1355-111	O-RING
1355-1164	O-Ring
1355-1282	Oring
1355-169	O-RING
1355-217	O-RING
1355-423	Seal, Gas
135T5405P0001	Pump; Jacking oil
135T5408P0001	Pump; Jacking oil
135T5546G0001	MOTOR, STARTER
136180-01	MODULE, COMMUNICATION GATEWAY
136188-01	MODULE, I/O
136188-02	MODULE, I/O
136T1715P0001	Heater
136T7224P0001	PRESSURE INDICATOR
136T8191P0001	Filter Assembly
136T8191P0001-ELEMENT	Filter, Element
13743087-02	GASKET, RING
1375M50P03	SEAL
1375M50P04	SEAL
1375M50P19	SEAL
1375M50P20	SEAL
137A4662P001	Thermocouple
137A4662P002	Thermocouple
137A4662P003	Thermocouple
137A4662P004	Thermocouple
137A4662P005	Thermocouple
137A4662P006	Thermocouple
137A4662P011	Thermocouple
137A4662P012	Thermocouple
137A4662P021	Thermocouple
137A4662P022	Thermocouple

## Starfish PPS - Complete Catalog

Part Number	Description
137A4662P031	Thermocouple
137B729P0001	Bushing
137D2440P0001	Flushing Valve
137T0032P1001	Brush Holder Assembly FCW-104G1001-AG
137T0556P003	Valve
138131-A010	CABLE, BENTLY, 10FT
138607-01	MODULE, STANDARD TRANSIENT DATA INTERFACE
138607-02	MODULE, TMR TRANSIENT DATA INTERFACE
138700-01	MODULE, I/O
138708-01	MODULE, I/O
138C9173G003	DEFLECTOR, OIL
138T1081P0001	Valve, Thermostatic
138T1411P0001	Valve, Check
138T2294P0001	Filter Element
138T5220P0001	Heater
138T7715P0001	Check Valve
138T7716P0001	Valve, Check
138T9157P0001	Immersion Heater
138T9346P0001	Solenoid Valve
138T9790P0001	Filter, Element
1390-607	GASKET, 2" PIPE, ANSI FLANGE, SPIRAL WOUND
139299-001	LED Indicator
139E7771G005	Fuel Nozzle Tip
139T0192P0001	Heater
139T2700P0001	Pressure Snubber
139T5765P0009	VALVE, BUTTERFLY, 8IN
139T7794P0001	CABLE
139T8996P0001	IR Gas Detector Assembly
14-0007-026	CABLE, THERMOCOUPLE
14-0025-1-203	CABLE, THERMOCOUPLE
14-0027-003	CABLE
14-412570-1-1-FSHEAVE	SHAFT, FAN, W/ BUSHING
140-152	TRANSFORMER, CURRENT
140-252	TRANSFORMER, CURRENT
140-302	TRANSFORMER, CURRENT
140-402	TRANSFORMER, CURRENT
140-SD-38548	TRANSFORMER, POWER
140100-110	O-RING
140352	NOZZLE, AMMONIA
140471-01	MODULE, I/O
140471-02	MODULE, I/O
140482-01	MODULE, I/O
140482-02	MODULE, I/O
140734-02	MONITOR, PROX/SEISMIC
140734-03	MONITOR, AERODERIVATIVE
140734-05	MONITOR, DYNAMIC PRESSURE
141-152	TRANSFORMER, CURRENT
141-302	TRANSFORMER, CURRENT: 3000:5
141-402	TRANSFORMER, CURRENT
1411-13	HEPA Final Filter
141A7363P0001	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
141A7364P0001	ASSEMBLY: MODULE, AERODERIVATIVE

## Starfish PPS - Complete Catalog

Part Number	Description
141A7371P0001	PREFILTER, AIR
141A7377P0001	VALVE, FUEL
141A7377P0001-AR	VALVE, FUEL, AS REMOVED
141A7377P0001-OH	VALVE, FUEL
141A8859P0001	VALVE, VENT, FUEL SYSTEM, DLE - 15 PPM
141A8869P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE
141A8877P0001	STABILIZER, T10 POWER SYSTEM
141C5244P001	Bushing, Outer Trunion
1420050949	O-RING
142C5824P0001	SHIM
142C5824P0005	Shim
142D4058G007	Insulation Box
142D4059G004	Insulation Box
142D4060G005	Box
142D4060G006	Box
142D4060G007	Box
142D4060G008	Box
142I-15246MA	Current Transformer
142I-SD-14684	TRANSFORMER, POWER
142I-SD-14684MA	TRANSFORMER, POWER
142P82C6NR413	Switch, Pressure
142P8S34	SWITCH, PRESSURE
143-103-000-532	Sensor, Dynamic
143-106-000-011	SENSOR, ACOUSTIC
143-106-000-111	SENSOR, ACOUSTIC
143-106-000-121	SENSOR, ACOUSTIC. PX36
143-202	Transformer, Current
143A6072P0001	PIN, VALVE, LOWER STEM NUT, 3/8" DIA, 4-1/2" LTH, F METAL
143B2775P002	Nozzle Pin
143B2775P003	Nozzle Pin
143B2775P2	PIN, NOZZLE
143B280G0004	Nozzle, Fuel, Cap
143B3045G003	DEFLECTOR, AIR
143D7407G004	Bull Horn
143E3334L0001	VBV Actuator
144-175-000-101	Accelerometer
144-175-000-201	ACCELEROMETER
144-303-000-011	Accelerometer, LM2500
144-303-000-111	ACCELEROMETER
144-303-000-221	Accelerometer
144-303-000-311	Accelerometer
1442861	Cable
145193-01	SENSOR, PROXIMITOR, 3300XL, 5/8MM
1454M98P04	Gasket
14590 A	TEST MATCH
14590A	TEST MATCH
145E1156L0001	KIT, HARDWARE
145E3639L0001	CABLE, TERMINAL BLOCK, KIT
146031-01	MODULE, I/O
146032-01	MODULE, I/O
146564001	GAUGE, TEMP, STAMI

## Starfish PPS - Complete Catalog

Part Number	Description
147-802	TRANSFORMER, CURRENT
1473M46P03	Ring
1473M46P04	Ring
1474M24G01	BRACKET, LPT
1474M32G01	Bolt, Shear
1474M32G02	Bolt, Shear
1478130000	Power Supply
148-802-863	Filter, Inlet
14847-50	CONDUIT ASSEMBLY STANDARD 1/2" NPT, 50'
148654-01	HMI, BENTLY NEVADA
1487589-1	Cable, Bently
149369-01	MODULE, ENHANCED KEYPHASOR
149716-01	MODULE, I/O
149986-02	MODULE, CONTROL, 4-CHANNEL RELAY
1499M88P02	SPACER
149M1613P0001	EX2100, DSPX/EISB Assembly
149M1684P0001	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVIe
149M1691P0001	RESISTOR
15-5CAVH0-5E	FUSE, 80000 AMP
15-767	VALVE, SOLENOID
15.5CAVH1E	FUSE 15.5 KV
1502DG-4A-4.5F	GAUGE, DIFFERENTIAL, 0-30
1506M44P08	NUT, SELF-LOCKING, HEX
1509M85P04	NUT, SELF-LOCKING DOUBLE HEXAGON
151X1202EAP04	DTBS MKVIE CARD INSULATOR
151X1202XJP03	Support Bracket, 3-I/O Pack, 12"
151X1202YE03SA04	BRACKET, 4IN S-CARD, DIN MOUNT
151X1202YE04PP05	COVER, 7-INCH S-CARD, DIN MOUNT
151X1202YE12PP01	Cover, Terminal Board, JPDE, Black
151X1202YE12PP02	Cover, Term. BD., JPDG/JPDS, Black
151X1207BB31S	EX2100, DSPX/EISB Assembly
151X1207BD01WK09A	Cable
151X1207CK02SA12	MODULE, DE-EXCITATION 77mm
151X1207DA01WK02	Cable, Excitation
151X1207DI16PP01	COVER, LEXAN, FOR 41DC CONTACTOR
151X1213BP03PC02	CAPACITOR, 350V
151X1213BP06PC01	DIODE, BEARING
151X1213PE07SA01	ECTB / EPCT CARD ASSY
151X1215DG02SA52	Blower Assembly
151X1215DG60SA51	Blower Assembly
151X1219DC20SA13	FAN
151X1224GAP0001	FAN,24VDC W/STAB CONNECTIONS
151X1225	Cable
151X1225BE12WK01	Cable
151X1235BC01SA01	MODULE, INPUT
151X1235BC01SA41	Processor Assy.,UCSB/CSLA, 1066 MHZ
151X1235BE04SA03	ESys Module (Simplex)
151X1235DB15SA01	EX2100e, Power Bridge Assy.
151X1235DB15SA03	PCM Assembly, EX2100e, 35A, with ERSE
151X1235DB15SA04	35A PCM ASSEMBLY WITH ERSE
151X1235DG06SA01	BLOWER MODULE 115V

Starfish PPS - Complete Catalog

Part Number	Description
151X1235DG06SA03	Blower Assy, 115V, Drawer Type
151X1235MT01WK03	ASSEMBLY, THERMISTOR, 3 FEET
151X1235RM10SA01	REGULATOR PCM
151X1235RM10SA03	REGULATOR PCM
151X1236LTSA01	TERMINAL
151x1235be12wk01	
152P82C6NR413	Switch, Pressure, Adj.
152P82CC3418	SWITCH, PRESSURE
1538M42P01	Gasket
1539M73G03	Seal
1540M69P09	Cushioned Clamp
1540M69P206	CLAMP, ENGINE CABLE
1540M69P207	Clamp
1540M69P310	Cushioned Clamp
155-305998-112	HEATER, IMMERSION
155-500710-606	
	Turbine
	lube oil Tank Heater and Thermostat
155-554704-621	GENERATOR L/O TANK HEATER
155-700401-274	Heater
1554M38P01	Gasket
155D7946P0015	BOLT,HEX HEAD
155D7946P0029	Screw
156-700401-275	Heater
156-700401-276	HEATER
156-700401-472	HEATER
156A1076P013	UNION
156A1591P016	Body Bound Stud
156A1591P018	STUD: TURBINE,TYPE BODY BOUND,DIAMETER 1.5 IN, TPI,THREAD LENGTH 2.5 IN,LENGTH 11.1 IN,MATERIAL
156B915F01	DIODE
15830-1061A	VALVE, SOLENOID
15830-1061D	VALVE, SOLENOID
15830-1596A	VALVE, SOL
1585J-M8TBJM-1M9	AB Cable
158A3437P003	Plug, Spark – Replaceable Core assembly
158A3479P023	EXTENSION, TERMINAL
158A7433P040	VLV, NEEDLE, .500", LINE SCREW
158A7433P40	VLV, NEEDLE, .500", LINE SCREW
158A7444P001	Thermoswitch
158A7444P002	Thermoswitch
158A7569P001	Safety Valve
158A7569P010	Relief Valve
159A840	Seal
159C6704G02	Fan Blade
15D21G002	Coil
160P44C6	SWITCH, DIFFERENTIAL PRESSURE, ADJUSTABLE
160P44C6BRS	SWITCH, PRESSURE
160P46C6BNR	TLO Filters Differential Pressure Switch
160P46CC6B	SWITCH, PRESSURE
160P47C6BR	Differential Pressure Switch
160P4S36	Adj. Diff. Pressure Switch

## Starfish PPS - Complete Catalog

Part Number	Description
160P4S43	SWITCH, PRESSURE
1611-003	PSM-ME-RS232/RS485
161204-01	MODULE, EGD GATEWAY
161216-01	MODULE, I/O
161216-02	MODULE, I/O
1622M24P01	Plug, Borescope
162P42C6BHR	Switch, Press., Adj., Diff.
162P42C6BNR	Switch, Press., Adj., Diff.
163C4108G006	SEAL, STA, AIR-#2
163C4796G006	SEAL, AIR
163C4798G001	SEAL, OIL
163C4799G001	SEAL, BEARING
1640-00002	Kit, Clamshell
1642M98G01	VALVE, CHECK, AIR
1646M48P11	Nut
164871-01	Term Block
164877-01	Block, External Termination
164883-01	Block, Term
164C2354G001	PUMP
165858-01	Block, External Termination
165A159CD	BFP Turbine Thrust Shoes, Set
165A3856P0002	GASKET, .. VALVE, 7-5/16"1D X 10-1/2"OD, GARLOCK 30 ROUND, .256" THK, S1NGLE
16710-17	Extension Cable
1689-1106	Sensor-Scalable, Pressure Transmitter
1689-1112	SENSOR, SPRING LOADED TEMP
1689-1126	Rotary Valve Position Sensor
1691M81P08	T48 Thermocouple
16925-20	SEIS/ACCL CABLE
169459-01	MODULE, I/O
169459-02	MODULE, I/O
1696M81P10	
1696M81P13	T/C; T48
1696M86P01	
1697M73P02	Wire, Retaining
1699-1322	Pressure Sensor
16RNP8-316	SWAGELOK REDUCING NIPPLE 1" NPT X 1/2" NPT
16SB1BB3B79SSS4PP4	Type SB-1 Switch
1700-1148	AMS 3302 Silicone Rubber Strip, 50 Duro, 0.015" thick x 7/8" long, Adhesive on one side
1700R12ABAEZZZ	TRANSMITTER
1702169	Plastic Frame Pre-Filter, M5,w/o downstream gasket
1704M61P03	Sleeve
1704M62P05	WASHER
1704M63G07	ARM
1704M63G08	ARM
1704M63G09	ARM
1704M63G10	ARM
1704M63G15	ARM
1704M63G16	ARM
1704M68P09	Bushing
1710F-18	Valve, Check
1710F18AEM29	Valve, Check

Starfish PPS - Complete Catalog

Part Number	Description
1711-1047	Switch, Prox
1712F-18	Valve, Check
172A5150P003	IGV Actuator
172A5150P004	IGV Actuator
172C9090P003	3RD STAGE SHROUD SEAL
172C9090P004	2nd Stage Shroud Seal
172C9091P003	Seal, Dogbone Shroud
1730D24001	Igniter
17343-124-725	Detector
1738D57G01	IGNITOR, ASSEMBLY
173C8443AKG04	SCR ASSEMBLY EX2000
173C9123BB003	ASSEMBLY,TERMINATION BLOCK
173C9123BB004	ASSEMBLY,TERMINATION BLOCK
1743155	desc check filter
1746-NI8	MODULE, INPUT, ANALOG, 8 CH
1746-NR8	MODULE, INPUT, RTD, 8 CH
1751-147	MODULE
1751-6058	Module, Transformer
1751-6091	MODULE, 16 CHAN
1751-6091-AR	MODULE, AS REMOVED
1754M91P02	RING
1756-ENBT	ETHERNET / IP
1756-IRT8I	THERMOCOUPLE, RTD, CONTROL LOGIX
1756-OF4	MODULE, 4 PT A/O, I OR V
1756-PB75R	POWER SUPPLY, CONTROL LOGIX, REDUNDANT
1756IB16I	MODULE, 30VDC INPUT
1761864	Filter
176449-01	MONITOR, PROXIMITOR
176449-02	MONITOR, PROX/SEISMIC
176449-03	MONITOR, AERODERIVATIVE
176449-05	MONITOR, DYNAMIC PRESSURE
1769-ECL	AB End Cap, Left
1769-ECR	AB End Cap, Right
1769-IA16	AB Module
1769-L33ER	AB Module
1769-OA16	AB Module
1769-OF4	AB Module
1769-PA4	AB Power Supply
176A13/M005RL	Sensor, Dynamic
176B2050P0002	GASKET, PRESSURE SEAL HEAD
1771-ASB	Remote I/O Adapter Module
1771-CT	I/O Chassis Cable
1771-DB	BASIC Module
1771-IBD	DC (10-30V) Input Module
1771-IL	MODULE, ISOLATED ANALOG INPUT
1771-IR	MODULE, INPUT, RESISTANCE TEMP DETECTOR
1771-OBDD	MODULE, OUTPUT, 10 TO 60 VDC
1771-P5	Power Supply Module
1774M59P01	Gasket
177897-01	Output Relay Module
178195	Hose, Assembly, Sprint System
178196	Hose, Assembly, Sprint

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
1784-1028	Converter - Isolated Linearized
1784-575	CONVERTER
1784-653	INPUT, TC, TYPE K
1784-655	RTD Input
1784-659	Converter - Non-Isolated Pass Through
1784-675	RTD, 200 OHM
1785-KE	Communication Interface Module
178850-00	PROXPAC XL REPLACEMENT PROX AND COVER
178850-05	PROXPAC XL REPLACEMENT PROX AND COVER
178C6072G002	IGNITOR ASSEMBLY
1792M79P01	PLATE, ORIFICE
1792M79P02	PLATE, ORIFICE
1792M79P03	PLATE, ORIFICE
1792M79P04	PLATE, ORIFICE
1792M79P05	PLATE, ORIFICE
1792M79P06	PLATE, ORIFICE
1792M79P07	PLATE, ORIFICE
1792M79P08	PLATE, ORIFICE
1792M79P09	PLATE, ORIFICE
1792M79P10	PLATE, ORIFICE
1792M79P11	PLATE, ORIFICE
1792M79P12	PLATE, ORIFICE
1792M79P13	PLATE, ORIFICE
1792M79P14	PLATE, ORIFICE
1792M79P15	PLATE, ORIFICE
1792M79P16	PLATE, ORIFICE
1792M79P17	PLATE, ORIFICE
1792M79P18	PLATE, ORIFICE
1794-7	Water Filler Cap
1794-IRT8	AB Module, Thermocouple RTD
1794-OB32P	Flex I/O 1794 Module
1797-01	CABLE, T5:4, FOR 2 PROBES
1797M98P01	Pressure Probe
1798-01	CABLE, T5.4, FOR 3 PROBES
1800M58P01	Clamp, Coupling
1800R005ON /-V-KB	Element, Filter, MLO
1800SCREEN-PERF	Screen Insert
1800SCREEN/PERF	Screen Insert
1801262AFSM2	VALVE, BALL, 3 IN, 150 LB
180P44C6NR	Switch, pressure
180P44C6R	SWITCH, VACUUM
180SHT-301	Transformer, Current
181D5816G0001	Seal, air
181D5816G0002	Seal, Gas
181D5816G001	Seal, air
181D5816G002	Seal, Gas
181D5816G01	Seal, air
181D5816G02	Seal, Gas
181P42C6	Vacuum Switch
181P42C6NR	Switch, Pressure
181P42C6R	Switch
1821M49G01	Anti-Clocking Pin

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
1826M46G01	TUBE, AIR, HPT COOLING
1826M46G01-OH	TUBE, AIR, HPT COOLING
1826M47P02	Pin
182888	Gasket
182A2017P0009	Screw, Socket Head
184389-01	MODULE, I/O
184684-01	MODULE, ENHANCED KEYPHASOR
1847M57P03	Wire, HPT
18484	KIT, FASTENER, NOX COUPLING
184A9809P001	SHIM, GEARRACK
185-SS 2"	BASKET, STRAINER
185-SS 3"	BASKET, STRAINER
185-SS 3"-GSKT	GASKET
185-SS-2"-GSKT	Gasket
1851195-007	MIST ELIMINATOR 5-1/4" x 12-1/8" x 72"
1854M45G02	HPC Blade Retainer
1855M35P08	Bolt
185A1117P011	Sensor
185A1117P012	Sensor
185A1343P210	O-RING
185A1354P036	O-RING
185A1354P214	O-RING
185A1354P219	O-RING
185A1354P222	O-RING
185A1354P237	O ring
185A1354P245	O-RING
185A1354P271	O-RING
185A1364P001	Hydraulic Actuator
185A1526P003	Check Valve
185A1527P001	Air Bleed Valve
185A1632P005	Screen, Gas Strainer
185A1632P5	Screen, Gas Strainer
18697-199	Shaft, Step, 316SS, 2 7/16" x 35
186C1916P008	Bolt, Hex Head
186C1916P013	Bolt
186C1916P014	BOLT
186C1916P022	Bolt
186C1916P029	Bolt
186C1980G001	SEAL, BOTTOM, TRANSITION TUBE
186C1981G001	SEAL, TOP, TRANSITION TUBE OUTER
186C6386P0001	DISC, CRV STOP, 20IN
18745-03	Proximity Sensor
18745-04-00	PROXIMITOR 7200
1879430000	POWER DISTRIBUTION BLOCK
187C7986G001	DEFLECTOR, OIL
1885M58P02	SPR, Wire - Flat
1886-5039	Servo Valve
1886-557	Trip Servo Valve
1886-7034	LVDT
188C9483G001	Deflector
188CP-025-0300	PIN, COTTER 1/4 X 3" SS

Starfish PPS - Complete Catalog

Part Number	Description
188D4719G001	TUBE, CROSSFIRE
188D7278G001	Seal, Oil
188D7918G001	Crossfire (Xfire) Tube Retainer
188D7967P001	Clip
188D9489G008	Spark Plug Assembly
18L0009WH	CAPACITOR, PROTECTIVE, SURGE, 13.8KV
190B1704G01	Handle
1912F-18-30	VALVE, GLO
1916F-18	VALVE, CHECK
191775	Washer - Lock,.173X.280X.03
191776	WASHER-LOCK, .1995X.323X.03
192B3452P003	GASKET
192B3815P001	GASKET
192B3816P001	Flex Seal
192B3817P001	CLAMP SEGMENT
193-ESM-VIG-60A-T	AB Module
194D7733P0001	Valve Stem
194D7737P0001	Valve Seat
194D7874P0001	Stem
1950-00-2F	Pressure Switch
1950-10-2F	Differential Pressure Switch
1950-5-2F	Pressure Switch
1957M62P01	SLEEVE
1962M86P01	PROBE
1962M86P02	T48 Thermocouple
1962m886p02	
1962m886p023	
1967M28P01	BRACKET, FWD CLG
196B1714P005	RETAINER, CROSSFIRE TUBE
196B6753P0001	Limit Switch
196C8768P0003	Transducer, LVDT
196D1204P006	Seal
196D1204P007	Seal
196D1204P012	Seal
196D1204P022	Seal
196D1985G002	Spark Plug Assembly
196D1985G004	Spark Plug Assembly
1978M21G01	Check Valve Overhaul Kit
1978M21P01	Check Valve, FLAPPER
197C3155G002	End Seal
199A7160P0008	Lock Plate
199C4740P001	Deflector
199D3157P116	Seal
199D3180P005	SEAL
199D3180P007	SEAL
199D3474P001	Crossfire (X-fire) Tube
199D3477P001	Crossfire (X-fire) Tube
1C2888	Valve, Check
1C2890	Valve, Check
1C31203G01	REMOTE I/O NODE CONTROLLER, EMERSON OVATION
1C31233G04	Ovation Module
1C3569G02	PUMP, HYDRAULIC, ACTUATOR

Starfish PPS - Complete Catalog

Part Number	Description
1C3569G03	PUMP, HYDRAULIC, ACTUATOR
1C3569G03-AM	PUMP, HYDRAULIC, ACTUATOR
1C3569G03-RENTAL	PUMP, HYDRAULIC, ACTUATOR
1C3569G3	PUMP, HYDRAULIC, ACTUATOR
1C484540-63	HOUSING, FILTER
1C6096	Tooling, ignitor depth gauge
1C6138G01	Tool, Drill Guide, LM2500
1C6361G01	TOOL SET, RADIAL DRIVE
1C6905G01	Clamping Set, O-Ring Installation
1C6953	Puller, oil and tube
1C8018G01	GT Lift Fixture, LM2500+G4
1C8039G02	Fixture, Raise and Support
1C8182G01	Tooling, Seal Removal
1C8200G02	Lift Fixture, LM2500GG
1C8340G01	GG Lift Fixture, LM2500+G4
1C8343G01	Fixture, Top Halve LM2500+ HP Compressor Case
1C8353G01	Lift Fixture
1C8400G02	Fixture, Check-Actuator, VSV
1C8481	LM2500 Lift Fixture
1C8505P04	TOOL
1C9353G02	Tooling
1C9353P02	Tooling
1C9359G02	Tooling, VIGV
1C9381G01	BRACKET, SHIPPING, FUEL/STEAM MANIFOLD
1C9381G02	BRACKET, SHIPPING, FUEL/STEAM MANIFOLD
1C9393G01	Adapter Set, Pressure Test Rig
1C9403G01	Fixture, Check, VSV/VIGV Actuators
1C9408G01	Fixture, Torque Measuring - VSV Assembly
1C9412P01	Fixture, Retention, HPC VSV
1C9450G01	Tool, Closure Set Nozzle – Fuel Gas System
1C9621G01	Fixture, DLE Manifold
1CPT4466TSEA12	VALVE, DRAIN
1D106G18A	Coil
1D3TR	Pump, Jacking
1F725902192	Diaphragm
1INCH-S8000	Valve, Ball
1SVDK7	Pump, Water Wash
1SVDK7-AR	Pump, Water Wash, As Removed
1U2216X0012	Piston Ring
1U221946172	Seat Ring
1U6768X0022	Packing
1X00416H01-AR	POWER SUPPLY, AS REMOVED
2 010271016-686-0000	Diaphragm
2 DFT 905H1C4D3	Valve, Check
2-114	O-RING, HIGH TEMP
20-0122-001	Sensor
200-0452-005 H0057 34222	CABLE, RTD, J2 BEARING TEMP
200091-106	GASKET, COVER
200091-297	ASSEMBLY: SEAL
200565-15	CLOSURE
200728-126	STUD
200752-7	NUT

Starfish PPS - Complete Catalog

Part Number	Description
2007NBY2B2M0200	SSOV Limit Switch
2008M74G01	Plug, Borescope, S2
20095TY16	Flow Divider
2010C	GAUGE, MAGNAHELIC
201B222P34	CABLE, IGNITION
201B2626G009	Stud, Coupling
201B2635P001	LOCK NUT
201B2636P001	Lock Nut
201B2780P001	DOWEL PIN
201B3363G001	SEAL, ASSEMBLY
201J995002	Probe Assy
2024-14326-2 24-1512	Impeller
2024-14326-3 24-1512	Impeller
20285-11	ELEMENT, AIR / OIL
20285.11	ELEMENT, AIR / OIL
202D2317P0001	Stem
20317V	O-RING
20345V	O-RING, GLO FILTER HOUSING
20359V	O-RING
203D4523P0001	DISC, MAIN STEAM CONTROL VALVE
203D4532P0001	DISC
2040K-31B-3-JE24	Fan Cooled Heat Exchanger
2043-3385-000	Centrifugal Clutch, complete
204B1146P001	Stem, Valve
204D3251G001	Probe Holder
204D5128	MOUNT
204D5128P001	Mount, Turbine
204D5128P002	Mount, Turbine
2051CG3A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2051CG4A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2051CG5A22A1AB4M5DFQ4	Coplanar Pressure Transmitter
2051TG4A2B21AE5Q4	In-Line Pressure Transmitter
20600694	WASHER, INSULATION
2062-6-6C	Fitting, Elbow
2063951	ELEMENT, FILTER
207C3512G003	Ball Joint, Assy, SS, W/ 3/4" Compression Tubing Connection,
207C3558P001	Crossfire (Xfire) Tube Retainer
20820	Expansion Joint
2085020	ACTUATOR, VALVE
208B8585P0020	1.25" , 7 TPI , Swivel Eyet Bolt
208D3803P0001	Valve Disc
208D5458P0001	Cabinet, Woodward, Micronet
208D9845P0021	Power Supply
2091907	Element, Filter, MLO
2092M71P01	Nut
2092M71P02	Nut
20A6128X102	Plug/Stem
20ET	FUSE
20F39SNV96	F39 Series Pnuematic Actuator

## Starfish PPS - Complete Catalog

Part Number	Description
20S16PX0505	CABLE GLAND, APPLETON 1/2" NPT
20ST30505	CMP CABLE GLAND T3CDS
21000-16-05-00-105-03-02	Proximity Probe
21000-28-05-00-041-03-02	Booster, LMS100
21000-28-05-00-119-03-02	Probe
21000-28-05-30-25-03-02	HOUSING ASSY RELATIVE PROBE, 3300 XL 8mm
21000-XX-10-00-050-XX-02 Mod 174232-02-01	Probe, Vib
210664	SAFETY BARRIER, ZENER
2108B2101N	GAS DETECTOR
2108B4100N	GAS DETECTOR
21160-02	CABLE, IGNITER
21160-03	CABLE, IGNITER
2117M48P01	WASHER
2117M48P02	WASHER
211A9053P001	Pin, Lock
211D4318P0003	Cable
211D4318P0008	CABLE-MICRONET HIGH DENSITY
211D4321P0004	CABLE
2120015	Wire. 1.0 mm2 (18 AWG), 3 conductor, twisted, shielded ca wire, 50'
21236	CABLE, IGNITER
2126T68G01	Ignitor Assembly
214C7152P001	STUD
214CRTSMB1S3M0065SL	Temperature Sensor
214CRTSMB1S4E0047SL	RTD
214CRWSMB1D3E0027SL	Temperature Sensor
214CRWSMB1D3E0042SLE6AT1C3B1WDG3XW	Temperature Sensor
214CRWSMB1D3E0042SLKAAT1C3B1WDG3XW	Temperature Sensor
214CRWSMB1D3E0042SLKDAT1C3B1WDG3XW	RTD
214CRWSMB1D3E0122SLE6AT1C3B1WDG3	Sensor, temp
214CRWSMB1D3E0152SLE6AT1C3B1WDG3XW	Temperature Sensor
214CRWSMB1D3E0152SLKD	Element, Temp
214CTJSMT1SGE0050SLKAAT1C3WD	Temperature Sensor
21504-0-060-10-02	8MM PROXIMITY PROBE -- 3/8-24
21504-0-32-10-02	8MM PROXIMITY PROBE -- 3/8-24
21504-0-60-10-02	8MM PROXIMITY PROBE -- 3/8-24
21504-00-60-10-02	8MM PROXIMITY PROBE -- 3/8-24
21508-02-12-10-02	7200 8MM PROXIMITY PROBE
215A2462P001	Washer
215A3192G001	Key
215A4218P003	PIN, BUCKET, SEAL SHANK
215A4218P005	PIN-SHANK SEAL .185-.180 DIA.
216A3107P0001	VALVE
216A3111P0001	ADAPTER
216A3112P0001	O-Ring
216A3155P0001	CABLE, T2/T25 RTD
216A3156P0001	CABLE, VBV/VSV/IGV
216A3157P0001	CABLE, IGV/LVDT/XN2, LEFT
216A3158P0001	CABLE, IGV/LVDT, RIGHT
216A3159P0001	CABLE, XN25 SPEED
216A3160P0001	CABLE, CHIP DETECTOR, A/B
216A3161P0001	CABLE, VBV/VSV/LVDT

Starfish PPS - Complete Catalog

Part Number	Description
216A3162P0013	CABLE, TEMP LUBE & SCAVENGE
216A3163P0001	CABLE, TEMP LUBE RTD, D&E SUMPS
216A3164P0001	CABLE, VBV/VSV-LVDT, RIGHT SIDE
216A3165P0001	CABLE, CRF ACCELEROMETER
216A3166P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
216A3167P0001	CABLE, UV FLAME DETECTOR
216A3168P0001	CABLE, XNSD SPEED
216A3169P0001	CABLE, TRF ACCELEROMETER
216A3170P0001	CABLE, OFF-ENGINE, T/C, T48 - LOWER
216A3171P0001	CABLE, EGT THERMOCOUPLE, RIGHT
216A3248P0001	CABLE, STAGING VALVES, LEFT
216A3298P0002	Detector, Gas
216A3298P0003	DETECTOR, GAS
216A3299P0002	IR GAS DET
216A3299P0003	IR GAS DET
216A3315P0001	ELEMENT, TEMP, RTD, DUAL
216A3333P0001	Filter, H2O Injection Skid
216A3346P0001	Controller, Servo Position
216A3462P0001	Relay, GE
216A3468P0001	Gasket
216A3526P0001	SENSOR, GAS
216A3598P0001	600 DEGREE DET
216A3600P0001	CABLE, RTD
216A3600P0001-40	CABLE, CLUTCH OIL DRAIN RTD
216A3604P0001	CABLE, NPT SPEED
216A3605P0001	CABLE, T/C T4.8
216A3606P0001	CABLE, MAG CHIP DETECTOR
216A3607P0001	CABLE, CRF ACCELEROMETER
216A3608P0001	CABLE, TRF ACCELEROMETER
216A3609P0001	CABLE, STAGING VALVE, LEFT
216A3628P0001	ASSEMBLY: BRUSH, EARTHING
216A3629P0001	ASSEMBLY: BRUSH, EARTHING
216A3685P0001	Element, Vibration
216A3693P0001	Gasket
216A3740P0001	SWITCH, FLOAT, GEN, COOL WATER LEVEL
216A3741P0001	Bearing, Brush
216A3744P0001	BUSHING, BEARING
216A3753P0001	Valve, Check
216A3759P0001	FLOW METER
216A3766P0001	Flow Meter
216A3802P0001	CABLE, IGV/LVDT/XN2, RIGHT
216A3803P0001	CABLE, IGV/LVDT, RIGHT
216A3804P0001	CABLE, VBV/VSV/IGV
216A3821P0001	Pump, Hyd
216A3822P0001	Filter, Make up, Norway
216A3832P0001	GEN PROTECTION SYSTEM COMPR
216A3838P0001	VALVE, CHECK
216A3842P0001	LQ25T
216A3844P0001	Valve, Bypass, Liquid Fuel
216A3847P0001	EXCHANGER
216A3848P0001	Air/Oil Separator, SLO
216A3848P0002	Air/Oil Separator, SLO

Starfish PPS - Complete Catalog

Part Number	Description
216A3864P0001	CABLE, DYNAMIC PRESSURE SENSOR
216A3912P0001	NOZZLE, SIZE 5
216A3927P0001	Safety Cable Terminator
216A3984P0001	CURRENT OUTPUT & RELAY
216A4050P0001	Clutch
216A4051P0001	Gasket, Clutch to Starter
216A4052P0001	Seal, Brush, NDE, Outer
216A4056P0001	Filter, Air
216A4087P0001	Fire Panel
216A4095P0001	Check Valve
216A4096P0001	Check Valve
216A4342P0001	Intercooler Control Valve
216A4378P0001	Pump, lube oil
216A4396P0001	CABLE, OFF-ENGINE
216A4414P0002	Pump, Cooling Water
216A4416P0002	LMS100 Intercooler Pump Assembly
216A4416P0002-AR	AS REMOVED LMS100 Intercooler Pump Assembly
216A4430P0001	Valve, Check
216A4431P0001	Return Line Filter
216A4454P0001	VALVE, CHECK
216A4470P0001	TRANSMITTER
216A4471P0001	RTD
216A4501P0001	Power Supply, Micronet
216A4546P0001	QUAD BOX
216A4554P0001	CABLE, THRUST SENSOR SIGNAL CONDITIONER
216A4555P0001	CABLE, THRUST SENSOR SIGNAL CONDITIONER
216A4560P0001	REPEATER, HART
216A4604P0002	LUBE PUMP
216A4605P0001	Mineral Lube Pump
216A4619P0001	ASSEMBLY: METER, FLOW
216A4619P0002	Meter, Flow
216A4620P0001	RTD
216A4653P0001	HEATER
216A4690P0001	VALVE, SOLENOID,
216A4694P0001	GEARBOX, ROTOJET
216A4705P0001	CABLE, STAGING VALVE, RIGHT
216A4842P0001	WOODWARD, MICRONET+
216A4843P0001	WASHER, SEAL, SET OF 4
216A4979P0001	HEATER
216A4980P0001	HEATER; TMSS-18315E2T2T36XX,400V/480V,21.5/31KW,1-3PH,15
216A4982P0001	Heater, 2-1/2 NPT
216A4982P0002	THERMOSTATICALLY CONTROLLED HEATER
216A5020P0001	HEATER
216A5032P0002	Exchanger
216A5033P0001	LIGHT FIXTURE, 24V, 50W
216A5060P0001	GSOV, Woodward
216A5068P0001	Nozzle, Size 2
216A5069P0001	Nozzle, Size 8+
216A5103P002	Pump, Hydraulic
216A5118P0001	Y Strainer
216A5118P0001GSKT	Y Strainer

Starfish PPS - Complete Catalog

Part Number	Description
216A5129P0002	AMPLIFIER, DYNAMIC
216A5169P0001	Heator, Stator
216A5179P0002	CO2 MANUAL PULL
216A5213P0001	VALVE, CHECK
216A5227P0001	COUPLING, ASSY
216A5254P0001	Transducer, Proximity
216A5257P0001	NUT, HEX, FLEX LOCK
216A5266P0001	CABLE, RESOLVER
216A5267P0001	CABLE, MOTOR FEEDBACK
216A5268P0001	CABLE, ELECTRICAL, POWER
216A5269P0001	VALVE, THERMO, CONTROL
216A5270P0001	WASHER, FLAT, WIDE, STANDARD
2170-3305-000	Ring
21747-080-00	EXTENSION CABLE
2178-3375-000	Bearing cover
2178-3400-010	Worm Wheel Shaft
2181-1488	SWITCH, TEMPERATURE
218A4483P23	TRANSFORMER
218A4609P007	Connector, Pin
219B6607G007	Stud Assembly Set
219B6614P001	Seal
219B6635P001	Locating Dowel
219B6702P001	Plate, Lock
219B6733P003	Bolt
219B6745P003	Plug, Spark – Replaceable Core assembly
219B6763P001	Lockplate
219B6763P006	Lockplate
219B6854P005	DOWEL PIN-UNPLATED
219B6854P006	DOWEL PIN-UNPLATED
219B6854P007	DOWEL PIN-UNPLATED
219B6854P008	DOWEL PIN-UNPLATED
219B6863G001	Shim
219B6863G002	Shim
219B6890P001	SEALING RING
22-32-0-024-1420	RELAY, FINDER, MODULAR CONTACTOR
22-32-0-230-1320	RELAY, FINDER, MODULAR CONTACTOR
2202-19T016F01	1PR/22 AWG, SHD, PLENUM, GRY JKT
221952-001	Contact
2227	VALVE, GLO
223B8237P0001	Key
224B3215P0007	Thermowell, Thermocouple
224B9719P001	Lockplate
224B9719P002	Lockplate
224C5607G0003	CABLE
224C5607G0006	CABLE
224C6763P0201	Hydraulic Cylinder
22512-107	Igniter Cable
225130-001	KIT, Calibration
225130-015	Calibration Gas Kit
225269	DETECTOR, ELECTRONIC
225312-001	COVER, DUST
225S71-2.000-2.250-5.00	Coupling, water inj

## Starfish PPS - Complete Catalog

Part Number	Description
226166-001	GAS CYLINDER, 50%LEL METHANE
226365-119	QUAD-BOX, TERMINAL
226365-131	QUAD BOX
226365-132	BOX, JUNCTION, QUAD
226365-520	CONDULET B
226555-101	TRANSMITTER, COMBUSTIBLE
226585-001	Detronics transmitter
226A1359P0001	SCANNER, FLAME
226A1501P002	VALVE, SOLENOID
226A2436P001	Thermowell, integral housing
226A2436P1	Thermowell, integral housing
227B6059P003	Seal, Flex (Exhaust Frame)
227B6059P004	Seal, Flex (Exhaust Frame)
227B6077P002	Borescope Plug
227B6087P002	Plug, Borescope
227B6088G003	Plug Assembly, borescope
227B608G002	Plug Assembly, borescope
227B6112G001	SCREW, SET
227B6112G003	NUT, SET
227C9178G003	Brush Seal Assembly
227C9753P002	SEAL, GLAND
227C9753P004	SEAL, GLAND
227C9753P006	SEAL, GLAND
228C7374P0001	CHAMBER, BALANCE GE STM TURB MAIN STOP VLV I L24+
229A8000P0024	CABLE, RELAY15P14C-24IN
229A8001P0108	CABLE, RELAY15P15C-108IN
229A8229P0150	CABLE, CI37P36C-150IN
231-11-137	SEAL, BUFFALO PUMP, VOLUTE
231D5541P002	Double Hole Lockplate
2320-600	Clamp
2320-ZR	Valve
232P4S134-124	Switch, Pressure
233C2501G001	SITE TUBE
2351	VALVE, CHECK
23546-000	CABLE, SPEED, XN25
235A5998P001	Pump, Fuel
235A9598P011	Gland, T/C
235C4350P0004	Gasket
236B3493P004	Gasket
236B3494P038	Gasket
236B6391P0004	Bushing
236C1115P004	Bolt
236C1187G001	ASSEMBLY,BULL HORN WEAR COVER
236C1248G010	Flame Detector
236C1302P018	Shim
23732-01	ACCELEROMETER
23733-03	MODULE, ACCEL
23870-14	LEAD, FLEXIBLE, SPARK PLUG IGNITION
23970-13	CABLE, IGNITER
239A5124P003	

## Starfish PPS - Complete Catalog

Part Number	Description
	Pin-Dowel
239A5601-4	Switch
239A5601-5	Switch
239A5622G001	DEFLECTOR, SEAL
239A5892P1	Pressure Switch
239B5942P001	Lockplate
239B5958G003	PLUG ASSY
239B5959P002	Plug, Borescope Hole
239B9455P004	Crossfire Tube
239B9719P007	Plug, Borescope
239B9719P010	BOLT, CLEARANCE METER PLUG
239C7201G001	GAS TIP ASSY-FUEL NOZZLE
24-296	SOLENOID VALVE
240833EXPB	225 Degree Thermal Spot Detector
240835EXPB	450 Degree Thermal Spot Detector
241C2842G001	Measurement Tip
24204B	SWITCH ROTARY
24302B	ELECTROSWITCH
24304B	SWITCH ROTARY
24305B	ELECTROSWITCH, ROTARY, 2 DECK
2435M99P01	O-RING, HIGH TEMP
243C1369P001	Bolt/Plug
243C1369P002	Bolt/Plug
243C2835P001	BEARING, SPHERICAL
244A2827P0001	Screw
245C5731P0001	RING, VALVE, THREADED
246B2323AAG02	Circuit, Breaker, Exciter
24765-02-00	SENSOR, CASE EXPANSION TRANSDUCER
24765-02-01	Sensor, CASE EXPANSION TRANSDUCER - DC LVDT
247B5782P001	PIN DIAPH 2ND NOZ F7(THREADED)
247B7273P002	Keys
247C5083P11	LMS Dolly front Mount Pin
247C5168G01	Fixture, Holding Actuating System
247C5168G02	Fixture, Holding Actuating System
247C5168G03	Fixture, Holding Actuating System
247C5194G01	Gage Set, RIG-IGV Clevis
247C5194G02	Gage Set, RIG-IGV Clevis
247C5209G01	Tool, Drill Guide, Fuel Nozzle, LMS100
248A5904P001	Hydraulic Cylinder
248A5904P001-KIT	HYDRAULIC CYLINDER SEAL KIT
248A5943P001	TRANSDUCER, ROTARY
248A6140P001	Lock Plate
2497M46P01	CLAMP
249A2536P0001	Valve Positioner, Digital
249A2662P0001	Pump, Jacking Oil
249A4019P0001	Release Module
249A4031P0001	VALVE, SOLENOID
249A4071P0001	BOLT, HEX
249A4125P0001	Module, Alarm

## Starfish PPS - Complete Catalog

Part Number	Description
249A4139P0001	CABLE,NETCON LAYOUT LOW DENSITY DISCRETE,GR
249A4202P0001	CPU, MICRONET
249A4202P0002	Module, Micronet plus CPU5200
249A4262P0001	Coupling, GLO
249A4292P0001	FLANGE KIT, SPLIT, 1-1/2 IN, 6000LB, S
249A4310P0001	Module, FTM HDVIM
249A4398P0001	HOSE, ASSEMBLY
249A4446P0001	PUMP, FUEL
249A4446P0001-AR	Pump, Fuel-As Removed
249A4465P0001	VALVE, GS16
249A4476P0001	CABLE, T/C
249A4652P0001	Temp Detector
249A4667P0001	VALVE, CHECK
249A4695P0001	TRANSMITTER
249A4696P0001	TRANSMITTER
249A4697P0001	TRANSMITTER
249A4698P0001	TRANSMITTER
249A4699P0001	TRANSMITTER
249A4700P0001	FOD SOCK
249A4733P0001	Transmitter, Level
249A4747P0001	CABLE, EGT THERMOCOUPLE, RIGHT
249A4751P0001	CABLE, OFF-ENGINE, T/C, T48 - LOWER
249A4756P0001	SWITCH, VIBRATING FORK, LIQUID LEVEL
249A4854P0001	CLAMP, U
249A4904P0001	POWER SUPPLY, 24VDC INPUT
249A4906P0001	Pump Assembly
249A4931P001	Pump, VG
249A4931P002	PUMP, VG
249A4959P0001	Cycle release module
249A4992P0001	Detector, gas
249A9153P0001	Vaneaxial Direct Drive Fan w/Motor, Generator Fan, Estima Weight: 2,463 lb
249A9216P0001	Cable, 9-Way D-Type, Female/Female VSR100 / VSR175
249A9250P0001	RECTIFIER MODULE
249A9364P0001	Belt
249A9404P0001	Board, PC, 505, 500OHM
249A9532P0001	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
249A9533P0001	Valve, Thermostatic
249A9597P0001	Bellows
249A9862P0001	AL8001440DEV:38 DEVIATED MODULE
24G0877004	Igniter Cable
250A1155P0001	Pump, Jacking
250A1407P0001	VALVE, CHECK
250A1429P0001	Filter Element
250A1563P0001	BEARING, SHELL TE
250A1564P0001	BEARING, SHELL CE
250A1565P0001	SEAL, RING, INSIDE TE
250A1566P0001	SEAL, RING, OUTSIDE TE

Starfish PPS - Complete Catalog

Part Number	Description
250A1567P0001	SEAL, RING, INSIDE CE
250A1568P0001	SEAL, RING, OUTSIDE CE
250A1569P0001	DIODE-MODULE, POSITIVE
250A1570P0001	DIODE-MODULE, NEGATIVE
250A1572P0001	HEATER, GENERATOR
250A1573P0001	HEATER, EXCITER
250A1574P0001	AIR THERMOMETER
250A1575P0001	THERMOMETER, BEARING SHELL
250A1576P0001	THERMOMETER, OIL DRAIN
250A1577P0001	Grounding brush holder
250A1580P0001	PRESSURE TRANSMITTER AIR
250A1585P0001	SET OF GASKET FOR SILENCER
250A1635P0001	INDICATOR
250A1787P0001	Solenoid Valve
250A1787P0001-AR	Solenoid Valve
250A1971P0001	Filter, Element
250A2005P0001	IR Gas Detector
250A2617P0001	Filter, inlet
250A2624P0001	Relay
250A2632P0001	20 HP Motor
250A3285P0001	GASKET, SPIRAL WOUND
250A3778P0001	Current Transformer
250A3795P0001	Current Transformer
250A3818P0001	Ground Brush
250A4075P0001	Filter Element
250A4318P0001	CABLE, RTD
250A4590P0001	CONTROL BOARD(PCB94), VSR100 / VSR175, M2
250A4726P0001	Velcro
250A4727P0001	VALVE, SOLENOID
250A4968P0001	Motor
250A5079P0001	MOTOR, STARTER

Starfish PPS - Complete Catalog

Part Number	Description
250A5079P0001-AR	MOTOR, STARTER AS REMOVED
250A5080P0001	Kit, Flange (Metric)
250A5155P0001	Filter Element
250A5313P0001	O-RING
250A5314P0001	O-RING
250A5399P0001	
	Grounding brush holder
250A5768P0001	SENSOR, GAS
250A5892P0001	Velcro
250A6119P0001	Gasket, Cover
250A6852P0001	Valve, USOV
250A6978P0001	Switch, Pressure
250A7060P0001	
	Gas Transmitter
250A7197P0001	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
250A7958P0001	FILTER, GLASS FIBER, ANDRITZ A03 GENERATOR, LEVEL 1, FINAL FILTER SET
25100SS04TXCG	Diaphragm Seal
2511A	RTD, Dual
25192-009	CABLE, ACCELEROMETER
251B2004P010	PIN
252-PVUU-PQBX-C6-EB	RELAY, OUTPUT
25200-001-040-T00	CABLE, ACCEL, CRF/TRF
25200-003-020-T36	CABLE, RTD
25200-003-030-T36	CABLE, RTD
25200-003-040-T36	CABLE, CLUTCH OIL DRAIN RTD
25200-003-050-T36	CABLE, RTD
25200-003-065-T36	CABLE
25200-003-140-T36	
	CABLE, RTD
25200-012-040-T36	CABLE, NGG2 SPEED
25200-014-030-T36	CABLE, NPT SPEED
25200-014-040-T36	CABLE, NPT SPEED
25200-014-050-T36	CABLE, PT SPEED NPT
25200-014-075-T36	CABLE, NPT SPEED
25200-014-135-T36	CABLE, HYD STARTER CLUTCH OIL
25200-014-140-T36	
	CABLE, ELEC, NPT SPEED
25200-019-045-T36	CABLE, T2 DUAL
25200-019-050-T36	CABLE, DUAL ELEMENT, T2
25200-020-040-T36	CABLE, T5:4
25200-020-050-T36	CABLE, T5:4
25200-021-030-T36	CABLE, T/C T4.8
25200-021-035-T36	CABLE, T/C, T48
25200-021-050-T36	CABLE
25200-021-055-T36	CABLE, T/C
25200-021-065-T36	CABLE, T4.8
25200-022-035-T36	CABLE, UV FLAME SENSOR

Starfish PPS - Complete Catalog

Part Number	Description
25200-024-040-T36	CABLE, CHIP DETECTOR
25200-030-025-T36	CABLE, T3 COMP DISCHARGE
25200-030-030-T36	CABLE, T3
25200-030-040-T36	CABLE, TC, DUAL, T3
25200-030-050-T36	CABLE, TC, DUAL
25200-030-055-T36	CABLE, T3
25200-030-070-T36	CABLE, T/C, DUAL, T3
25200-031-040-T36	CABLE, TEMP, FUEL MANIFOLD
25200-031-045-T36	CABLE, FLAME DETECTOR
25200-031-060-T36	CABLE
25200-036-040-T36	CABLE, BLEED VALVE
25200-036-050-T36	CABLE, BLEED VALVE
25200-039-025-T00	CABLE, ACCELEROMETER
25200-039-045-T00	CABLE, ACCELEROMETER
25200-039-050-T00	CABLE, ACCELEROMETER
25200-040-025-T36	CABLE, DUAL RTD/VSV LVDT, T2 SENSOR
25200-040-050-T36	CABLE, DUAL RTD/VSV/LVDT
25200-040-100-T36	CABLE, DUAL RTD/VSV/LVDT
25200-041-030-T36	CABLE, MAG CHIP DETECTOR
25200-041-040-T36	CABLE, CHIP DETECTOR
25200-041-050-T36	CABLE, CHIP DETECTOR
25200-041-060-T36	CABLE, CHIP DETECTOR
25200-041-085-T36	CABLE, CHIP DETECTOR
25200-041-130-T36	CABLE, CHIP DETECTOR, SCAVENGE
25200-044-035-T36	CABLE, STAGING VALVE, LEFT
25200-044-050-T36	CABLE, STAGING VALVE, LEFT
25200-046-030-T36	CABLE, VSV SERVO
25200-046-040-T36	CABLE, VSV
25200-046-045-T36	CABLE, SERVO VALVE
25200-046-050-T36	CABLE, VSV
25200-046-130-T36	CABLE, SERVO VALVE, VSV
25200-060-050-T36	CABLE
25200-A01-030-T00	CABLE, CRF ACCELEROMETER
25200-A01-040-T00	CABLE, ACCELEROMETER
25200-A07-030-T36	CABLE, ELECTRICAL CONTROL
25200-A07-050-T36	CABLE, NGG1 GG SPEED
25200-A07-060-T36	CABLE, ELEC, NGG1 GG SPEED
25200-A07-x050-T36	CABLE
25200-A13-040-T00	CABLE, TRF ACCELEROMETER
25200-A13-075-T00	CABLE, ACCELEROMETER
25200-A14-050-T36	CABLE, NPT SPEED
25200-A36-045-T36	CABLE, ELECTRICAL
25200-A45-035-T36	CABLE, STAGING VALVE, RIGHT
25200-A45-050-T36	CABLE
25200-A45-070-T36	CABLE, STAGING VALVE
25200-B40-040-T36	CABLE, OFF-ENGINE
25200-CDP-030-T36	CABLE, CDP
25200-D03-100-T36	CABLE, RTD
252588	VBV Boot, Norway

Starfish PPS - Complete Catalog

Part Number	Description
25361-04	Ignition Lead
25362-34	CABLE, IGNITION SYSTEM
25363-10	Lead, Ignition
25363-11	Lead, Ignition
25363-12	Lead, Ignition
25363-13	Lead, Ignition
25363-14	Lead, Ignition
25364-50	Lead, Ignition
25364-51	Lead, Ignition
25364-52	Lead, Ignition
25364-53	Lead, Ignition, Flexible, 32 foot
254A4695P0001	Key
254A4695P0003	Key
254A7229P0008	FILTER
255A4156G002	Weight
255A4167P001	Pin, Borescope
255A4309P001	THERMOCOUPLE, WHEELSPACE
255A4309P002	THERMOCOUPLE, WHEELSPACE
255A4309P003	THERMOCOUPLE, WHEELSPACE
255A4309P004	THERMOCOUPLE, WHEELSPACE
255A4330P001	Fitting, T/C
255A4332G004	T/C Tube
255A44928P007	Nut
255A4708P004	Thermocouple, Comp Discharge
255A4991P3	Gasket
25600-001-009-OE	CABLE, LPT, SPEED
25600-001-030-T36	Cable, T25
25600-001-040-T36	CABLE, T2/T25 RTD
25600-001-045-V36	CABLE, RTD, T2
25600-001-050-T36	CABLE, T2/T25 RTD
25600-001-050-V36	CABLE, RTD, T2
25600-001-055-V36	CABLE, RTD, T2
25600-002-006-OE	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT ON ENGINE
25600-003-006-OE	CABLE, ELECTRICAL, VBV/VSV/LVDT; RIGHT- ON ENGINE
25600-003-040-T36	CABLE, CLUTCH OIL DRAIN RTD
25600-004-005-OE	CABLE, TEMP, LIQUID MANIFOLD
25600-005-005-OE	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/COM
25600-005-030-T36	CABLE, VBV/VSV/IGV
25600-005-040-T36	CABLE, VBV/VSV/IGV
25600-005-050-V06	CABLE, TEMP, LUBE & SCAVENGE, SUPPLY
25600-005-050-V36	CABLE, TVBV/VSV/IGVO
25600-006-005-OE	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
25600-007-005-OE	CABLE, SPEED, GAS GENERATOR
25600-007-040-T36	CABLE, IGV/LVDT/XN2, LEFT
25600-007-050-T36	CABLE, IGV/LVDT/XN2, RIGHT
25600-007-050-V36	CABLE, IGV/LVDT, LEFT
25600-008-005-OE	CABLE, SPEED, GAS GENERATOR
25600-008-040-T36	CABLE, IGV/LVDT, RIGHT
25600-008-050-T36	CABLE, IGV/LVDT, RIGHT
25600-008-050-V36	CABLE, IGV/LVDT, LEFT
25600-009-007-OE	CABLE, CHIP DETECTOR, A/B/COM

## Starfish PPS - Complete Catalog

Part Number	Description
25600-010-008-OE	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
25600-010-040-T36	CABLE, XN25 SPEED
25600-010-050-T36	CABLE, XN25 SPEED
25600-010-050-V36	CABLE, XN25
25600-012-005-OE	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
25600-012-025-V36	CABLE, CHIP DETECTOR, A/B
25600-012-040-T36	CABLE, CHIP DETECTOR, A/B
25600-012-040-V36	CABLE, CHIP DETECTOR
25600-012-050-T36	CABLE, CHIP DETECTOR, A/B
25600-013-025-V36	CABLE, CHIP DETECTOR, C/D/E/COMM
25600-013-030-T36	CABLE, CHIP DETECTOR, C/D/E
25600-013-040-T36	CABLE, CHIP DETECTOR, C/D/E
25600-013-040-V36	CABLE, CHIP DETECTOR
25600-016-040-T36	CABLE, VBV/VSV/LVDT
25600-016-050-T36	CABLE, VBV/VSV/LVDT
25600-016-050-V36	CABLE, VBV/VSV/VDT, LEFT
25600-016-055-V36	CABLE, VBV/VSV/LVDT
25600-019-020-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-030-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-040-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-050-T36	CABLE, TEMP LUBE & SCAVENGE
25600-019-050-V36	CABLE, LUBE, RTD
25600-020-030-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-040-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-050-T36	CABLE, TEMP LUBE RTD, D&E SUMPS
25600-020-050-V36	CABLE, LUBE, RTD
25600-021-040-T36	CABLE, VBV/VSV-LVDT, RIGHT SIDE
25600-021-050-T36	CABLE, VBV/VSV-LVDT, RIGHT SIDE
25600-021-050-V36	CABLE, VBV/VSV/LVDT, RIGHT
25600-021-055-V36	CABLE, VBV/VSV/LVDT, RIGHT
25600-022-030-T00	CABLE, ACCELEROMETER
25600-022-040-T00	CABLE, CRF ACCELEROMETER
25600-026-040-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-026-050-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-026-055-V36	CABLE, T/C, T3
25600-026-060-T36	CABLE, TEMP COMPRESSOR DISCHARGE, T3
25600-027-040-T36	CABLE, UV FLAME DETECTOR
25600-027-043-T36	CABLE, UV FLAME DETECTOR
25600-027-060-T36	CABLE, UV FLAME DETECTOR
25600-027-120-T36	CABLE, UV FLAME DETECTOR
25600-029-040-T36	CABLE, MANIFOLD TEMPERATURE
25600-029-050-T36	CABLE, MANIFOLD TEMPERATURE
25600-030-030-T36	CABLE, XNSD SPEED
25600-030-040-T36	CABLE, XNSD SPEED
25600-030-040-V36	CABLE, XNSD
25600-030-050-T36	CABLE, XNSD SPEED
25600-031-006-OE	CABLE, LPT, SPEED
25600-032-040-T00	CABLE, TRF ACCELEROMETER
25600-034-030-T36	CABLE, OFF-ENGINE, T/C, T48 - LOWER
25600-034-040-T36	CABLE, OFF-ENGINE, T/C, T48 - LOWER
25600-034-050-T36	CABLE, OFF-ENGINE, T/C, T48 - LOWER
25600-036-030-T36	CABLE, EGT THERMOCOUPLE, RIGHT

Starfish PPS - Complete Catalog

Part Number	Description
25600-036-040-T36	CABLE, EGT THERMOCOUPLE, RIGHT
25600-036-050-T36	CABLE, EGT THERMOCOUPLE, RIGHT
25600-040-025-V36	CABLE, STAGING VALVE
25600-040-030-V36	CABLE, STAGING VALVE
25600-040-040-T36	CABLE, STAGING VALVES, RIGHT
25600-040-060-T36	CABLE, STAGING VALVES, RIGHT
25600-041-025-V36	CABLE, STAGING VALVE
25600-041-040-T36	CABLE, STAGING VALVES, LEFT
25600-041-060-T36	CABLE, STAGING VALVES, LEFT
25600-044-045-V36	CABLE, T/C T48, RIGHT
25600-044-060-V36	CABLE, T/C, T48
25600-045-045-V36	CABLE, T/C T48, LEFT
25600-045-060-V36	CABLE, T/C, T48
25600-048-040-T36	CABLE, TBV
25600-048-040-V36	CABLE, CDP, 16TH STAGE BLEED VALVE
25600-048-050-T36	CABLE, TBV
25600-048-050-V36	CABLE, XN25
25600-048-060-V36	CABLE, CDP
25600-049-040-T36	CABLE, 8TH STAGE BLEED VALVE
25600-049-060-V36	CABLE, 8TH STAGING BLEED VALVE
25600-049-065-V36	CABLE, STAGING BLEED VALVE
25600-056-040-T36	CABLE, TBV
25600-056-040-T36-AR	CABLE, TBV, AS REMOVED
25600-057-040-T00	CABLE, DYNAMIC PRESSURE SENSOR
25600-057-065-T00	CABLE, OFF-ENGINE
25600-058-045-T36	CABLE, LIQUID FUEL VALVES
25600-059-045-T36	CABLE, LIQUID FUEL VALVES
25600-060-025-V36	CABLE, STAGING VALVE, GAS SWITCH
25600-060-040-T36	CABLE, DRAIN VALVES
25600-060-045-T36	CABLE, DRAIN VALVES
25600-072-040-T06	CABLE, IGNITION TRANSFORMER
25600-072-040-V06	CABLE, IGNITION TRANSFORM
25600-072-055-V36	CABLE, IGNITION TRANSFORM
25600-A12-012-T00	CABLE, PATCH
25600-A29-040-T36	CABLE, MANIFOLD TEMPERATURE
25600-A29-045-T36	CABLE, LIQUID FUEL TEMPERATURE
25600-A29-050-T36	CABLE, MANIFOLD TEMPERATURE
25600-A58-045-T36	CABLE, LIQUID FUEL VALVES
25600-A59-045-T36	CABLE, LIQUID FUEL VALVES
25600-C42-040-T36	CABLE, STAGING VALVES
25890-40	Lead, Ignition
25890-41	Lead, Ignition
25890-42	Lead, Ignition
25890-43	Lead, Ignition
25890-44	Lead, Ignition
258A4439P001	Heater
258A4447P001	Gasket, immersion heater
258A4503P001	THERMOCOUPLE, WHEELSPACE
258A4784P006	Lock Plate
258A4784P007	LOCK PLATE
258A4784P008	Lock Plate
258A4784P013	PLATE, LOCK

Starfish PPS - Complete Catalog

Part Number	Description
258A4784P015	Plate, lock, bull horns
258A4784P020	Lock Plate
258A4860P002	Filter
25945-71	Lead, Ignition
25945-72	Lead, Ignition
25945-73	Lead, Ignition
259B2434ABP18	CABLE, MARK VI
259B2451BVP4	DIN Rail Mounting Clips
259B2451BYG01	FILTER, EMI
259B2451FCG07	PCNOH1B/SPID ASM DIN RAIL MTG
25FLFXS	NUT, 6 PT
26141812P002	AMPLIFIER, FLAME
261A1301P0001	Valve, relief
261A1812P003	Scanner, Flame
261A1812P004	Scanner, Flame
261A1812P005	Scanner, Flame
261A1812P006	Scanner, Flame
261A1812P007	Scanner, Flame
261A1812P008	Scanner, Flame
261A1812P009	Scanner, Flame
261A1812P010	Scanner, Flame
261A1812P011	Scanner, Flame
261A1812P012	Scanner, Flame
261A1812P013	Scanner, Flame
261A1812P014	Scanner, Flame
261A1812P015	Scanner, Flame
261A1812P3	Scanner, Flame
261A7349P003	LOCK PLATE
262A3561P002	PLUG, HEX HEAD
262A3716P001	THERMOCOUPLE, COMPRESSOR INLET
26387-000	Thermocouple T5:4
26490-000	T3 Sensor
264A6889P0002	Nut
264A6889P0005	NUT
26530-12-10-00-000-189-21-03-00	PROBE, BENTLY NEVADA
267218	RELAY, TRIPPING, AREVA
267B6699P0003	CABLE, POWER & JUMPER
267B6699P0009	CABLE, TDBS POWER
267B6699P0016	CABLE, POWER, 5-PIN PIGTAIL
267B7555P0002	IGNITION TRANSFORMER POWER
268642-120	Power Supply
268A1290P003	Switch, Pressure
268A1431P001	Lockplate
268A1439P001	Stretch Nut
2701-04-04-SS	90-Degree Stainless Adapter
2702-04-04-SS	45-Degree Stainless Bulkhead Adapter
270250	FOD Sock
2703-04-04-04-SS	Bulkhead Branch Tee Stainless Adapter
2708740	CONTACT, RS485
27112-005	CABLE, OFF-ENGINE, TM2500
27112-050	Cable
27112-065	Cable

## Starfish PPS - Complete Catalog

Part Number	Description
2711P-T10C22D8S	AB Panelview Plus 7
271256-28	BOLT HEX, 1/2" - 13NC X 1 1/2", 304
27210450	DETECT A FIRE UNIT
272A1721P0002	PIN, STEM/DISK
27304-000-060-T36	Cable, Hydraulic Starter Clutch Oil
27304-000-120-T36	CABLE, TEMP, HYD STARTER CLUTCH OIL
27304-001-030-T36	CABLE, THRUST SENSOR SIGNAL CONDITIONER
27304-002-030-T36	CABLE, THRUST SENSOR SIGNAL CONDITIONER
27304-101-040-T36	CABLE, OFF-ENGINE, VIGV
27304-101-045-T36	Cable, Off-Engine
27304-102-040-T36	Cable, Electrical, VIVG
27304-102-045-T36	Cable, Off-Engine
27304-105-045-T36	Cable, Off-Engine
27304-203-050-T36	CABLE, OFF-ENGINE
27304-204-050-T36	CABLE, OFF-ENGINE
27304-406-065-T36	CABLE, OFF-ENGINE
27304-407-075-T36	CABLE, OFF-ENGINE
27304-501-075-T36	CABLE, ELECTRICAL, VIBRATION
27304-503-075-T36	CABLE, XN44A LPC-IPT ROTOR SPEED
27304-509-085-T36	CABLE, OFF-ENGINE
27304-601-100-T36	CABLE, VIBRATION
27304-609-100-T36	CABLE, OFF-ENGINE
27304-701-040-T00	CABLE, DYNAMIC PRESSURE SENSOR
27304-701-065-T00	CABLE, OFF-ENGINE
27304-808-045-T00	CABLE, RESOLVER FEEDBACK
27304-813-050-T00	CABLE, ELECTRICAL, POWER
27304-813-070-T00	CABLE, ELECTRICAL, POWER
27304-814-045-T00	CABLE, MOTOR POWER
27304-851-070-T00	CABLE, ELECTRICAL, DRIVER
27304-853-070-T00	CABLE, ELECTRICAL, FEEDBACK
27304-855-070-T00	CABLE, MOTOR FEEDBACK
27304-857-070-T00	CABLE, RESOLVER
27304-901-120-T36	CABLE, CLUTCH HTVAS VIBRATION
273800	Clutch
27391C18 / EG8004	Brush, Grounding, Jeumont (2X)
275A8898P011	Thermocouple
277218	HOSE, TLO PUMP SUCTION L1
277219	HOSE, TLO PUMP L2
277220	HOSE, Lube oil Scavenge " L3
277222	Hose, Hydraulic
277A2906P001	Pump
278A2181VRP3	BOARD, ARKNET CONTROL
279A1347P001	Right Angle Bodied Switch
279A1396P001	SWITCH, LIMIT
279A1396P002	SWITCH, STRAIGHT, NORMALLY CLOSED
279A1396P005	Switch
279A1396P007	Switch
281854	Spacer, Front Clevis
281855	Clevis, Aft Mount
281856	Bearing
281857	BEARING, TURNBUCKLE
281857P0001	BEARING, TURNBUCKLE

Starfish PPS - Complete Catalog

Part Number	Description
281859	MOUNT, TURBINE, AFT
281859-ALT	MOUNT, TURBINE, AFT, ALTERNATE
281859-AR	MOUNT, TURBINE, AFTERMARKET, AS REMOVED
281859-OH	MOUNT, TURBINE, AFT, OVERHAULED
281860-1	Bearing, Rod
281860-2	Bearing, Rod
281860G0001	Bearing, Rod
281860G0002	Bearing, Rod
281860LH	Bearing, Rod
281860RH	Bearing, Rod
281861	Nut, Jam, aft mount
281862	Nut, Jam, aft mount
281863	Nut, Jam
281864	Nut, Jam
281865	Link, Engine Mount
281866	Bolt, Aft Mount, Top
281867	Bolt, Aft Mount, Bottom
281A6761P0001	Retainer
281B7946G1301	FIRE PROTECTION, 4X CONFIG, DIN (LFPI)
281B7946G1302	LFPI, TPIM CONFIG, DIN
28240-C00	CABLE, ASSEMBLY, DRIVER TO VALVE
28244-120	CABLE, FLAME SENSOR
283748	Starter Card
285-305120-024	Heater, Exciter, Set of 2
2866789	Power Supply
286A5443PR5	LED COLOR CAP TRANSLUCENT RED ET-16
286A6290P003	PLUG, SQUARE HEAD
286A6290P007	plug, pipe
286A6346P012	Heater
2873-250	E-SEAL, RING
2873-300	E-SEAL, RING
2873-400	E-SEAL, RING
2873-600	E-SEAL, RING
287783	FABRIC EXPANSION JOINT
287837	FABRIC EXPANSION JOINT ASSY
287A1397P001	LUBRICANT, HEAVY DUTY, ANTI-SEIZE
287A1399P003	Connector, Male
287A1399P023	FITTING, CONN,MALE,WITH STOP COLLAR
287A1496P003	Butterfly Valve
287A1496P101	VALVE, BUTTERFLY
287A1614P004	RING: TYPE PACKING, SIZE 107MM ID X 125MM OD, MA GRAPHITE
287A1692P001	Bolt, Hex Head, TP, Shoulder Bolt
287A7888G001	Tubing, Thermocouple
288005	FLANGE ADAPTER,TRF VENT,2
288055-01	MODULE, STANDARD TRANSIENT DATA INTERFACE
288056	Hose, Assembly, Sprint System
288057	Hose, Assembly, Sprint System (TW1)
288062-02	MODULE, TACHOMETER
2880641-12	Washer, Insulating
2880642-12	Washer
2883226	Nut

## Starfish PPS - Complete Catalog

Part Number	Description
2883343-07012	Bolt, Coupling
2883343-12014	Bolt, Coupling
2883395-4	Locknut
288822	FWD Mount Bolt
288870	FIXTURE, LIFT, LM6000
289172	Adapter, Flame Tracker
289173G0001	EXP. JOINT INLET VOLUTE ASSEMBLY
289174	Duct, VBV
289188	Manifold Sprint, Water
289189	Manifold, Sprint System
289195	Hose, Assembly, Sprint System
289196	Hose, Assembly, Sprint
289239	Hose, Assembly, Gas Supply
292A319G23	PLUG, TEST
293A0910P006	Bolt
293B254A20	RELAY, AUXILIARY
294A0151P004	Locking Plate
294A0151P006	Lock Plate
294A0151P007	Lock Plate
294A0151P022	Lockplate
294A4087P0001	Booster, LMS100
294A4118P0001	FILTER, AIR
294A4635P0001	SCREEN, REPLACEMENT, 100 MESH
294A4636P0001	SCREEN, REPLACEMENT, 100 MESH
294A4637P0001	Indicating Lamp, Red Lens
294A4639P0001	Lamp, Blue Lens
294A4654P0001	LAMP, INDICATING, GREEN LENS
294A4661P001	ASSEMBLY: LAMP HOLDER, RED
294A4662P0001	ASSEMBLY: LAMP HOLDER, GREEN
294A4725P0001	125A, 690V FUSE
294A4737P0001	FUSE, FAST ACTING, 22X58MM, 690V, 32A
294A4754PP0001	SENSOR, SPRING LOADED TEMP
294A4762P0001	Accumulator- Piston
2951TY8	Pump, Fuel
295A9131P001	Lockplate
295A9135P003	Plug
297A0559P003	THERMOCOUPLE
297A2331P0001	STRAP, GROUNDING, BRAID, 3/16"THK X 1-5/8"WD X 10"
297A2370P0004	Rupture Disc Diaphragm
298A0111P046	Key
298A0472P004	Seal, Fuel Nozzle
298A0530P0007	Right Angle Bodied Switch
298A0530P007	Right Angle Bodied Switch
298A8221P001	NUT, RETAINER, Fuel Nozzle
298A8224P003	Plug, Spark – Replaceable Core assembly
298A8252P001	PLATE, LOCK
298A8519P001	Pin
298A8989P002	Probe
299370-12C	BOLT, HEX
2A7408P0002	LIQUID FUEL
2BF0CF14002D	VALVE, THERMOSTATIC

Starfish PPS - Complete Catalog

Part Number	Description
2BOCT12001	3 Way Temperature Control Valve
2BOKIT-12001	Repair Kit, 3 Way Temperature Control Valve
2C14699	Fixture, Lift-Compressor stator Case upper
2C6103G08	Protractor Tool Set, Gas Generator Rigging
2C6103G09	Protractor Tool Set, Gas Generator Rigging
2C6183G01	No. 6 Bearing Outer Race Puller
2C6613G01	Gauge, Immersion Depth, Igniter
2C6613G01-RENTAL	Gauge, Immersion Depth, Igniter
2C6883G01	Tool, Drill Guide, Fuel Nozzle, LM6000
2C6883G01-DLE	Tool, Drill Guide, DLE Fuel Nozzle
2C6925G03	Gage Set
2C6925G05	Gage Set
2C6962G03	Gage Set, Sight - VSV Arms
2C6962G05	Gage, sight - VSV Actuation Arms
2C6966G05	Gage Set - Sight - VSV Arms
2C6966G07	Gage, sight - VSV Actuation Arms
2C8016G03	Gage, Sight
2C8102G02	Tooling, Torque Fixture
2C9512	Check Valve
2CC/TR	Pump, Jacking
2DFT955G1B4A3	VALVE, CHECK
2E859602202	Diaphragm
2FRM6B36-3X/16QMV	Valve, Assembly
2G-377P-800F	Filter Silencer
2GXY9	RTV SILICONE
2INCHS8000-LL	Valve, 2"
2K 405TTFS6564AN	MOTOR
2U219233272	Cage
2XV9450-1AR88-0AA0	Time synchronization device
3"GASKET F/764-SS	GASKET, INLET SCREEN, Y-STRAINER
3-298-8-00-901-15	Gasket
3-299-8-00-901-15	Gasket
3/3VX1180	Belt, Gates
3/3VXKB1180	Belt
3/5VX1060	BELT
3/5VX1500	3 Band Belt
3/8" S-8380-02-LL	Valve, Relief, ball full port
30.499815.1.202	BRUSH HOLDER AND CLAMP
3005290-CLA	Weight, Balance
3005290-CLB	Weight, Balance
3005290-CLC	Weight, Balance
300H-3-2-145/1160-8	Pressure Switch
301571254	AIR THERMOMETER
3016M78P03	Strap, Upper
301900901	Andritz Generator Filter Kit
301914	O-RING
302361001	BRACKET
3024084	Filter
302A1620P012	PLUG, PIPE

## Starfish PPS - Complete Catalog

Part Number	Description
302A1620P013	PLUG, PIPE
302A4006P001	Thermocouple
302A4010P002	THERMOCOUPLE, EXHAUST
302A4357P001	Lock Plate
302A4584P024	Terminal Board
302A4594P130	Gasket
302A4594P316	Gasket
302A4597P010	Gasket
302A4597P069	GASKET, FLANGE, FUEL NOZZLE, 1IN, 600LB
302A4597P070	Gasket
302A7341P001	SEAL STRIP
3032M38P48	Stud
3032M38P52	Stud
303A3530P0001	Spring
304661009	Heater
304661012	HEATER
304726	Filter Element
304FG 1/2	600# spiral wound
304FG 2	150# spiral wound
305136	Exciter
305192013	Heator, Stator
305193052	Heater
3051CD1A02A1AH2B3E5L4M5Q4	Coplanar Transmitter
3051CD3A22A1AK6	Filter Pressure Differential Transmitter
3051CG3A02A1AE5H2B1DF	Coplanar Transmitter
3051CG4A03A1JS5K5M5Q4T1	PRESSURE TRANSMITTER
3051CG4A22A1AB4E5M5Q4	Pressure Transmitter
3051CG5A02A1A	Pressure Transmitter
3051CG5A02A1AH2B1E5M5	Transmitter
3051S1CD1A2E12A1AKA	TRANSMITTER
3051S1CD1A2E12A2AKA	TRANSMITTER
3051S1CD1A2E12A2AKAA0229	TRANSMITTER
3051S1CD1A2E12A2AKD	Transmitter, pressure
3051S1CD1A2E12A2JB4KAQ4A0229	TRANSMITTER
3051S1CD1A2E12A2JKDA0229	TRANSMITTER
3051S1CD2A2E12A1AB4N1	Transmitter
3051S1CD2A2E12A2AKA	TRANSMITTER
3051S1CD3A2E12A2AKA	TRANSMITTER, PRESSURE
3051S1CD3A2E12A2AKAA0229	TRANSMITTER, PRESSURE
3051S1CD3A2E12A2AKAZ1	TRANSMITTER, PRESSURE
3051S1TA1A2E11A2AKA	TRANSMITTER, PRESS
3051S1TA2A2E11A1A	Transmitter, pressure
3051S1TA3A2E11A2AKA	Transmitter, pressure
3051S1TG3A2E11A2AKA	Fuel Gas Pressure Transmitter
3051S1TG3A2E11A2JKDQ4	Transmitter, pressure
3051S1TG3AE11A2AKA	TRANSMITTER
3051S1TG4A2E11A2AKA	SENSOR, PRESSURE
3051S2CG3A2E12A1AK5Q4	SCALABLE PRESSURE TRANSMITTER
3051S2TG3A2	Transmitter
3051S2TG3A2A11A1AB4M5Q4	Transmitter
3051S2TG3A2E11A1AB4M5Q4	Transmitter
3051S2TG4A2E11A1AB4E5M5	Scalable Pressure Transmitter

Starfish PPS - Complete Catalog

Part Number	Description
3051S3CD2A2A11A1AE5	Transmitter, Pressure
3051TA1A2B21AKD	TRANSMITTER
3051TA2A2A21AC6	Transmitter, pressure
3051TA2A2B21AKD	TRANSMITTER
3051TA3A2B21AC6	Inline Pressure Transmitter
3051TG-3A2B21A-S5-M5	Inline Pressure Transmitter
3051TG2A2A21AC6	TRANSMITTER, PRESSURE
3051TG2A2A21AK6	Compressor Discharge Pressure PS3
3051TG2F2B21AB4E5A01	Inline Pressure Transmitter
3051TG3	TRANSMITTER
3051TG3A2A21AB4C6	GLO Pressure Transmitter
3051TG3A2A21AB4K6Q4	GLO Pressure Transmitter
3051TG3A2B21AKD	TRANSMITTER
3051TG3A2B21AKDM5	Inline Pressure Transmitter
3051TG3A2B21AS5M5	Inline Pressure Transmitter
3051TG3A2B21KB4K7M6RK	GLO Pressure Transmitter
3051TG4A2A21AB4C6	Pressure Transmitter
3051TG4A2B21AKD	TRANSMITTER
305925014	HEATER
305U250	Jeumont Diode
305UR250	Jeumont Diode
3076/029	Pump
3076/029-Major RK	Major Repair Kit for 3076/029
3076/029-MinorRK	3076/029 Minor Repair Kit
307A9298PXX	CABLE; T2 INLET
3084308-001	PreFilter, 24x24x4 in.
308FX2-ST	SWITCH, ETHERNET
30EI60R0600/250F	Bimetal Thermometer
310-SP-1	VALVE, 310A, PRESSURE REGULATING
31000-16-10-0-133-03-02	PROXIMITY PROBE HOUSING
3102HA1FSCNAQ4ST	TRANSMITTER, LEVEL, ULTRASONIC
3105.339	HEATER, ENCLOSURE
310T0901P0001	Washer
310T0901P0002	Washer
3116682/01	BRUSH, CARBON
311735202	Key, Machine
311A5177P002	VALVE
311A5178P008	LVDT Transducer
311A5178P022	TRANSDUCER, LVDT
311A5178P023	SENSOR
311A5802P002	CABLE, IGNITER
311A5802P003	CABLE, IGNITER
3120D-125200	TAPE, DROP WARP, CERAMIC FIBER, 100'
312434	Synthetic Lube Oil Supply Filter
312A6077P004	Servo Valve
312A6077P005	Valve, Servo
312A6077P006	Valve, Servo
312A6077P009	Valve, Servo
312A6977P006	Valve, Servo
312A6977P009	Valve, Servo
3131744-01	DIODE

## Starfish PPS - Complete Catalog

Part Number	Description
3131745-01	FUSE, 250V, 1000A
313233	Hose, Gas
313233A	Hose, Gas
313233B	Hose, Gas
313234	ELBOW
313280	Hose Assy, Water Wash IntCon
313280A	Hose Assy, Water Wash IntCon
313291	HOSE, TLO SUPPLY L1
313291B	HOSE, TLO SUPPLY L1
313359A	Hose, Lube, GLO
313440A	Hose
313684	HOSE ASSEMBLY, 1", LIQUID, WATER
313684A	HOSE ASSEMBLY, 1", LIQUID, WATER
313686	Hose Assembly, HYDRAULIC START MANIFOLD BLOCK
313686A	Hose Assembly, HYDRAULIC START MANIFOLD BLOCK
313688	Hose Assembly, HYDRAULIC START PUMP DISCHARGE
313694	Hose Assembly, LIQUID, MINERAL LUBE OIL
313695	Hose Assembly, MINERAL LUBE OIL
313728	HOSE ASSEMBLY, FUEL SYSTEM FILTERSUPPLY
313728A	HOSE ASSEMBLY, FUEL SYSTEM FILTERSUPPLY
313754	Hose
313754A	Hose
313755	Hose
313755A	Hose
313760	HOSE, GENERATOR RUNDOWN TANK
313760A	HOSE, GENERATOR RUNDOWN TANK
313830101	Clamp Plate
313A7231P0008	DIAPHRAGM
313A7233P0016	SHIELD
314093901	Clamp Plate
314163901	Key
3144PD1A1KAP5C4	TEMP SENSOR
3144PD1A2E5M5U1Q4	Temperature Transmitter
3144PD6A1K7B5M5CNQ4QT	Rosemount 3144P Temperature Transmitter
314788501	Screw, Self Locking
314A4091P0001	GLAND, TC CABLE, GT GENERATOR BEARING
314A5030P01	SENSOR, FLAME
314A5051P1	SOLENOID VALVE
314A5196P003	Pin
314A5266P001	Valve
314A5977P001	Lock Plate
315A2660P003	FILTER, HYDRAULIC
315A2708P119	Gas Detector/Transmitter for IBH valve Position Transmitter
315A4045G001	Stop Seal
315A4147P4C	THERMOCOUPLE
315A4147P5B	THERMOCOUPLE
315A9175P001	Lock Plate
315A9191P023	BOLT
315A9636P001	Bolt
316255	Synthetic Lube Oil Scavenge Filter
316A4525P0001	GASKET
316B3767P0004	BOLT, HEX HEAD

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
316B4525P0001	GASKET
317362801	Stub Shaft
317947601	Clamp Plate
318078	Nut - Plain, Hex
318079	Nut - Plain, Hex
31830-1057	VALVE, SOLENOID
31830-1057A	VALVE, SOLENOID
31830-1063A	VALVE, SOLENOID
31830-1063E	VALVE, SOLENOID
31830-1147	VALVE, SOLENOID
31830-1147C	VALVE, SOLENOID
31830-1597E	VALVE, SOLENOID
31840-1058A	VALVE, SOLENOID
31840-1417	Valve, Drain
31840-1598A	VALVE, SOLENOID
31840-1598C	VALVE, SOLENOID
31840-1602	Fuel Manifold Drain Valve
31840-2001	VALVE, SOLENOID
31840-X	VALVE 24VDC
31861-1059A	VALVE, SOLENOID
31861-1059B	VALVE, SOLENOID
31861-1059C	VALVE, SOLENOID
31861-1140	VALVE, SOLENOID
31861-1140A	VALVE, SOLENOID
31861-1140B	VALVE, SOLENOID
31861-1599A	VALVE, SOLENOID
31861-1599C	VALVE, SOLENOID
31861-1600C	VALVE, SOLENOID
31861-1623A	VALVE, SOLENOID
31861-1623B	VALVE, SOLENOID
318A9711P001	Gasket
318A9713P027	Gasket
318A9713P038	Gasket
318A9713P056	Gasket
318A9800P002	PLUG, BOROSCOPE
318A9801P002	Plug, Borescope
31902-02	Woodward
32-24588SEB	Control Valve for SCR
320-A20-2-FFF-L-015	Valve, Flo-Tite
320B5226P0001	Cover
321-3275QV139	Filter Element
3215548-4	Valve, Bleed Air
3215548-4-AR	VALVE, BLEED AIR, AS REMOVED
3215548-4-OH	VALVE, BLEED AIR
3215552-5	Valve, Bleed Air
3215552-5-AR	VALVE, BLEED AIR, AS REMOVED
3215568-2	Valve
3215568-2-AR	VALVE, BLEED AIR, AS REMOVED
3215568-2-OH	VALVE, BLEED AIR, OVERHAULED
3225A	Universal Frequency Converter
323A1036P0003	Connector, Plug
323A2354P2	RESISTOR

Starfish PPS - Complete Catalog

Part Number	Description
323A2354P3	RESISTOR
323A2354P33	Resistor
323A2354P41	Resistor
323A2357P21	FUSE, 1.5A
323A2440P15	SHUNT
323A3347P14	Cable, Assembly, Mark VI, 14 ft, for T48
323A3347P16	Cable, Assembly, Mark VI, 16 ft, for T48
323A3347P18	Cable, Assembly, Mark VI, 18 ft, for T48
323A3347P20	Cable, Assembly, Mark VI, 20 ft, for T48
323A3348MF05	Cable
323A4747NZP50A	SWITCH
323A4747NZP53A	Switch, Ethernet
323A4747NZP53A-AR	SWITCH, AS REMOVED
323A4747UUP4	ETHERNET PATCH CABLE - 50 FT
323A5750P16	Cable, Assembly, Mark VI, 16 ft, for T48
323B5435P0001	Pin
323B5435P0003	Pin
323B7988P005	Carbon Brush
323B7989P002	BRUSH, GROUNDING
324A5325P005	Gasket
324A5700P001	Valve, Solenoid
324A5973P002	Hose
324A5973P022	HOSE- HYDRAULIC
324A9109P005	GASKET, RING
324A9109P006	GASKET, RING
324A9109P107	GASKET, RING
324A9109P111	Gasket
324B7453P0004	STUD, BODY BOUND
324B7453P004	STUD, BODY BOUND
3255455201-02	Plastic Frame Pre-Filter, M5,w/ downstream gasket
325B4830P001	Wear Shim
32810-867	VALVE, ATKOMATIC
32820 OH kit	Circle seal 1/2 OH kit
32820-002	Circle Seal "GAS"
32820-002PNAA1E	Circle seal 1/2 NO valve
32820-1111	Valve, Dump, Fuel
32840-1650	Valve
32840-1682	VALVE, SOLENOID
32861-1603	Nat Gas vent valve
32861-626	Nat Gas vent valve
328A6991P001	Gasket
328A7327P002	Ignition Transformer
328A8420P012	Locking Plate
328A8480P054	Thermocouple
328A8483P001	Thermocouple
328A8483P002	Thermocouple
328A8483P005	THERMOCOUPLE
328A8483P050	THERMOCOUPLE
328A8630P001	Thermocouple
328A8630P002	Thermocouple
328B691G0004	Holder, Brush

Starfish PPS - Complete Catalog

Part Number	Description
328B691G011	Brush Holder
329635-C102	Valve, Fuel Metering
329880090117	Gasket
329A3529P001	TRANSDUSER VIBRATION VELOCITY
329A3529P021	Vibration Cable
329A3529P029	Sensor, Vibration
329A3529P040	Probe, Vibration
329A3529P055	Cable, Vibration Sensor
329A3529P056	Cable, Vibration Sensor
329A3529P057	CABLE: TYPE VIBRATION
329A3529P058	Vibration Cable
329A3529P091	Vibration Sensor
329A3529P101	VIBRATION SENSOR
3300	RACK, BENTLY NEVADA
3300/01	System Monitor
3300/01-01	System Monitor
3300/03	System Monitor
3300/03-01-00	System Monitor
3300/03-02-01	MONITOR, SYSTEM
3300/11	Power Supply
3300/11-01-02-00	Power Supply
3300/12	Power Supply
3300/12-01-20-00	Power Supply
3300/14	Power Supply
3300/14-01-20-00	Power Supply
3300/14-02-20-00	Power Supply
3300/15	Dual Vibration Monitor
3300/15-02-01-02-00-00-00	Dual Vibration Monitor
3300/15-03-01-02-00-00-00	Dual Vibration Monitor
3300/16	Dual Vibration XY/Gap Monitor
3300/16-01-01-02	DUAL VIBRATION XY/GAP MONITOR
3300/16-02-01-01-00-00-01	Dual Vibration XY/Gap Monitor
3300/16-02-01-01-00-00-02	Dual Vibration XY/Gap Monitor
3300/16-02-01-02-01-00-01	Dual Vibration XY/Gap Monitor
3300/17	VIBRATION MONITOR
3300/20	Dual Thrust Monitor
3300/20-02-01-00-00-00	Dual Thrust Monitor
3300/20-02-01-02-00-00	Dual Thrust Monitor
3300/48-01-01-00	MONITOR, CASE EXPANSION
3300/48-01-01-01-00	MONITOR, CASE EXPANSION
3300/50-03-01-00-00	MONITOR, TACHOMETER
330100-90-00	3300 XL 8mm Proximitior Sensor
330100-90-05	3300 XL 8mm Proximitior Sensor
330101-0-20-20-11-00	PROBE 3300 8MM
330101-0-30-10-01-00	PROBE 3300 8MM
330101-0-32-10-02-05	PROBE 3300 8MM
330101-0-60-10-02-05	PROBE 3300 8MM
330101-00-08-10-12-05	PROBE, 3300, 8MM
330101-00-12-10-02-00	PROBE, 3300XL, 8MM
330101-00-16-10-02-00	PROBE, VIBRATION, 8MM
330101-00-20-10-02-00	PROBE, KEYPHASER
330101-00-20-10-02-05	PROBE, KEYPHASER

Starfish PPS - Complete Catalog

Part Number	Description
330101-00-24-10-02-00	PROBE, VIBRATION, 8MM
330101-05-25-10-02-00	PROBE 3300 8MM BENTLY 3/8-24 UNF
330102-00-20-10-02-00	CABLE, 3300 XL 8MM
330102-00-20-10-02-05	CABLE, 3300 XL 8MM
330102-00-20-50-02-00	Probe
330102-00-28-05-02-05	Proximity Probe
330102-00-28-10-02-05	Vibration Detector Probe
330102-00-68-05-02-05	Vibration Probe
330102-03-18-10-02-00	PROBE 3300 8MM BENTLY 3/8-24 ARM
330102-05-25-10-02-00	PROBE, VIBRATION, 8MM
330103-00-016-90-1200	Probe, Bently
330103-00-09-50-02-00	Probe, Bently Nevada
330105-02-12-05-02-00	Key Phaser or Vib Probe
330105-02-12-05-02-05	Key Phaser or Vib Probe
330105-02-12-10-02-00	PROBE, VIBRATION, REVERSE MOUNT
330105-02-12-10-02-05	PROBE, VIBRATION, REVERSE MOUNT
330105-02-12-20-02-00	Proximitior Sensor, 3300XL 8mm
330106-05-30-05-02-00	PROBE 3300 8MM RVS MNT
330106-05-30-05-02-05	PROBE 3300 8MM RVS MNT
330106-05-30-10-02-00	Transducer, Proximity
330106-05-30-10-02-05	PROBE 3300 8MM BENTLY RVS MNT
330106-05-30-20-02-00	
330130-040-00-00	CABLE, EXTENSION
330130-045-00-05	Extension Cable
330130-045-01-05	CABLE, EXTENSION, ARMOR
330130-045-11-00	CABLE, EXTENSION
330130-080-00-00	CABLE, EXTENSION
330130-080-00-05	CABLE
330130-080-01-00	CABLE, EXTENSION, ARMOR
330130-080-01-05	CABLE, EXTENSION, ARMOR
330130-080-02-05	CABLE, EXTENSION
330130-080-12-00	3300 XL 5/8mm Extension Cable
330130-080-12-05	3300 XL 5/8mm Extension Cable
330130-085-00-00	Probe
330130-085-00-05	Probe
330130-085-01-05	Cable, Proximitior
330130-085-11-00	CABLE, EXTENSION
330171-0-20-10-02-05	PROBE
330171-00-20-10-02-05	PROBE
330173-00-16-90-02-00	TRANSDUCER
330180-085-01-05	CABLE, EXTENSION
330180-12-05	PROXIMITOR 3300XL
330180-50-00	330180-50-00
330180-50-05	330180-50-00
330180-51-00	3300 XL Proximitior Sensor
330180-51-05	SENSOR, PROXIMITOR, 3300XL
330180-90-00	3300 XL 5/8mm Proximitior Sensor
330180-90-05	3300 XL 5/8mm Proximitior Sensor
330180-91-00	3300 XL 5/8mm Proximitior Sensor
330180-91-05	3300 XL 5/8mm Proximitior Sensor
330180-X0-05	SENSOR, PROXIMITOR, 3300XL, 5/8MM
330190-XXX-01-05	3300 XL 8MM

Starfish PPS - Complete Catalog

Part Number	Description
330195-02-12-05-05	Cable
330195-02-12-10-05	PROBE, REVERSE MOUNT
3301HA1S1V3AE0105RAE1M1	TRANSMITTER, LEVEL
3301HA1S1V3AE0109RAE1M1C1	TRANSMITTER, LEVEL
3301HA1S1V3AE0202RAE1M1C1	TRANSMITTER
3301HA1S1V3AE0207RAKAM1C1R3016	TRANSMITTER, LEVEL
3301HA1S1V3AE0305RAE1C1	TRANSMITTER, LEVEL, GUIDE WAVE RADAR
3301HA1S1V3AE0305RAKA	TRANSMITTER, GUIDED WAVE RADAR
3301HA1S1V3AE0401RAE1	Transmitter, Level
330400-01-00	ACCELEROMETER
330400-01-05	ACCELEROMETER
330400-02-05	ACCELEROMETER - 100mV/g
330425-01-05	ACCELEROMETER
330500-02-01	Velomitor, 2 wire
330500-03-04	Velomitor - 2 wire
330525-01	PROBE, VELOMETER
330701-0-15-50-01-05	PROBE, 11MM, 3300 XL
330701-01-41-10-02-00	PROBE 3300 XL 11MM - 1/2-20
330701-01-41-10-02-05	PROBE 3300 XL 11MM - 1/2-20
330705-02-18-10-02-00	PROBE 3300 XL 11MM 3/8-24 REVERSE
330707-0-22-10-02-00	PROBE 3300 XL 11MM 5/8-18
330708-00-20-50-02-00	PROBE, 3300 XL, ARMORED
330730-080-00-00	CABLE EXTENSION 3300 XL 11MM
330730-080-00-05	CABLE EXTENSION 3300 XL 11MM
330750-60	Transducer
330780-90-00	PROXIMITOR, 3300 XL 11MM
330780-90-05	PROXIMITOR, 3300 XL 11MM
330800-28-00-085-02-02	Probe, Vibration
330800-28-00-085-03-02	Probe, Vibration
330850-90-05	PROXIMITOR 25MM 3300XL
330851-04-0-40-50-00-05	PROBE, 25MM, 3300 XL
330851-04-00-27-10-01-00	3300 Probe XL, 25mm
330851-05-0-27-10-00-05	PROBE 25MM 3300 XL
330854-080-24-00	Cable, Extension
330854-080-24-05	EXTENSION CABLE 3300 XL 25MM
330876-03-10-00-00	PROBE 3300 XL 50MM
330876-03-90-01-00	PROBE, BENTLY NEVADA
330878-90-00	Proximitor Sensor 50MM 3300XL
330878-90-05	Proximitor Sensor
330880-28-0-136-03-02	PROXPAC XL
330880-28-0-85-03-02	PROXPAC XL
330880-28-00-085-02-02	Probe, Vibration
330880-28-00-085-03-02	Probe, Vibration
330880-28-00-105-02-02	Probe, Vibration
330880-28-00-105-03-02	PROBE, VIBRATION
330880-28-00-108-03-02	Element, Vibration
330880-28-00-136-03-02	VIBRATION PROBE ASSEMBLY
330881-16-00-050-00-02	Probe
330881-16-00-205-00-02	Probe, Proximity, 205mm long
330881-16-00-250-00-02	PROBE
330881-28-04-065-03-02	Bently Nevada   PROXPAC XL Proximity Transducer
330901-51-82-10-02-00	PROBE PROXIMITY 3300 NSV 1/4-28 UNF

## Starfish PPS - Complete Catalog

Part Number	Description
330902-00-60-10-02-05	3300 NSV PROXIMITY PROBE 1/4-28 ARMORED
330906-02-12-05-02-05	3300 NSV RVS MNT PROBE - 3/8-24 UNF
330930-040-00-00	CABLE, EXTENSION, 3300 NSV
330930-045-00-05	3300 NSV EXTENSION CABLE
330930-060-00-00	3300 NSV EXTENSION CABLE
330930-060-00-05	3300 NSV EXTENSION CABLE
330980-51-05	3300 XL NSV PROXIMITOR
331A1632P1	Handle
331B6301G0001	Cable
331B6303G0004	Cable
3332541	SEAL, RING, OUTSIDE CE
334A1012P0001	CABLE, RESOLVER
334A1018P0001	CABLE, ELECTRICAL, FEEDBACK
334A1019P0001	CABLE, MOTOR FEEDBACK
334A1020P0001	CABLE, ELECTRICAL, DRIVER
334A1064P0001	CABLE, TC, DUAL
334A1074P0001	Sprint Valve
334A1077P0001	Sprint Valve
334A1137P0001	MODULE, 16 CHAN
334A1216P0001	RELAY
334A1427P0001	CIRCUIT BREAKER, 440VAC/125DC, 2P
334A1434P0001	RELAY CONTACTS
334A1439P0001	Cooler
334A3725P0001	Woodward valve
334A3764P0001	Hose Assembly
334A3916P0001	ADAPTER, END A 1 1/2
334A3940P0001	SENSOR, GAS
334A4116P0001	Hose, Jacking
334A4117P0001	Hose, Jacking
334A4118P0001	Hose, Jacking
334A4842P0001	CONVERTER, 24VDC
334A4910P0001	NOx Water Pump+Motor Assembly, VFD (Overhauled)
334A4911P0001	NOx Water Pump+Motor Assembly, VFD (Overhauled)
334A4916P0001	POWER SUPPLY
334A4982P0001	FUSE
334A5052P0001	NUT, SS
334A5059P0001	CABLE, ELECTRICAL CONTROL
334A5061P0001	CABLE, VSV SERVO
334A5062P0001	CABLE, T/C, T48
334A5065P0001	CABLE, T3
334A5066P0001	CABLE, UV FLAME SENSOR
334A5077P0001	GEARBOX, ROTOJET
334A5110P0001	ADAPTER
334A5127P0001	VALVE, BUTTERFLY, ACTUATOR
334A5128P0001	VALVE, BUTTERFLY, ACTUATOR
334A5158P0001	Flow Transmitter
334A5160P0001	Valve, Gas, 3"
334A5197P0001	TRANSDUCER, LINEAR
334A5217P0001	FILTER
334A5251P0001	T20P Recep
334A5252P0001	3FT MALE RECEP -ORANGE

Starfish PPS - Complete Catalog

Part Number	Description
334A5262P0001	C20S Receptacle
334A5299P0001	CONNECTOR & CABLE
334A5320P0001	Cable, Interconnect
334A5336P0001	Cable, TM2500
334A5355P0002	FAN, VENTILATION
334A5370P0001	CABLE, DUAL ELEMENT, T2
334A5462P0001	ADAPTER, 90 DEG
334A5492P0001	CABLE, WOODWARD
334A5498P0001	Pump, Lube, DC
334A5498P0002	PUMP
334A5498P0002-AR	Pump, Lube, DC
334A5527P0001	BOLT
334A5528P0001	NUT, LOCK
334A5528PP0001	NUT, LOCK
334A5549P0001	Pin Cotter ¼" Dia 3" long 302ss
334A5557P0001	Nut, Hex, Slotted 1 1/2"-6unc, 316ss
334A5570P0001	WIRE, 10 AWG, STRANDED, GREEN/YELLOW
334A5578P0001	WIRE, 14 AWG, STRANDED, GREEN/YELLOW
334A5604P0001	Reservoir Heater and Thermostat
334A5641P0001	ASSEMBLY: GAS DETECTOR, 505, METRIC
334A5641P0002	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
334A5684P0001	WASHER, FLAT 1 1/2"
336A4929G1	Cable
336A4937AAG170	CABLE, PBUS POWER, JPDH TO TBCI-JE1, 170IN
336A4937ACG030	Cable
336A4937ARG070	Cable
336A4937BKG004	CABLE, MARK VI
336A4937BKG008	CABLE, MARK VI
336A4937BKG010	CABLE, MARK VI
336A4937BKG072	CABLE, PBUS POWER, JPDH TO PACK, BLK, 72IN
336A4937BKG084	CABLE, MARK VI
336A4937BKG216	CABLE, MARK VI
336A4937BKG264	CABLE, MARK VI
336A4937BUG004	CABLE, MARK VI
336A4937BUG010	CABLE, MARK VI
336A4937BUG084	CABLE, MARK VI
336A4937BUG168	CABLE, MARK VI
336A4937BUG180	CABLE, MARK VI
336A4937EAG010	CABLE, MARK VI
336A4937EDG060	CABLE, MARK VI
336A4937EDG120	CABLE, P03S, POWER SUPPLY TO JPDS, 120IN
336A4937EEG144	CABLE, MARK VI
336A4937EEG216	CABLE, MARK VI
336A4937EFG072	CABLE, MARK VI
336A4937EFG080	CABLE, PBUS POWER, JPDS/JPDM TO ETHERNET SW
336A4937EFG150	CABLE, MARK VI
336A4937EHG030	CABLE, MARK VI
336A4937EHG080	CABLE, MARK VI

## Starfish PPS - Complete Catalog

Part Number	Description
336A4937EWG065	WIRES, 65"JPDB-JACX/600W PS
336A4937EWG075	Cable, 28V PWR SOURCE 75 Inch
336A4937EWG085	Cable, 28V PWR SOURCE 85 Inch
336A4937FHG145	CABLE, PBUS POWER, JPDM-J1/TSVC-J28, 145IN
336A4937GNG030	CABLE, ACRO150W 28VDC OUT 9PIN MNL-30
336A4937RDG004	CABLE, MARK VI
336A4937RDG010	CABLE, MARK VI
336A4937RDG084	CABLE, MARK VI
336A4937RDG108	CABLE, MARK VI
336A4937RDG180	WIRES, 180IN PAC POWER-JPDL 20AW
336A4937RDG200	CABLE, MARK VI
336A4940CTP2	RACK
336A4940DNP508FX2M	SWITCH, ETHERNET
336A4940DNP508FX2M-S	SWITCH, ETHERNET, SURPLUS
336A4940DNP508TX	SWITCH, ETHERNET
336A4940DNP509FX	SWITCH, ETHERNET
336A4940DNP516TX	SWITCH, ETHERNET
336A4940DNP516TX-AR	SWITCH, ETHERNET, AS REMOVED
336A4940DNP517FX	SWITCH, ETHERNET
336A4940DNP517FX-S	SWITCH, ETHERNET, SURPLUS
336A4940DTP10BK	CABLE, MARK VI
336A4940DTP10BL	CABLE, MARK VI
336A4940DTP10RD	CABLE, MARK VI
336A4940DTP11BL	CABLE, MARK VI
336A4940DTP12BK	Cable, MARK VI
336A4940DTP12BL	CABLE, MARK VI
336A4940DTP12RD	CABLE, MARK VI
336A4940DTP14BL	CABLE, MARK VI
336A4940DTP14RD	CABLE, MARK VI
336A4940DTP15BK	CABLE, MARK VI
336A4940DTP15BL	CABLE, MARK VI
336A4940DTP18RD	CABLE, MARK VI
336A4940DTP20BK	CABLE, MARK VI
336A4940DTP4BK	CABLE, MARK VI
336A4940DTP4BL	CABLE, MARK VI
336A4940DTP4RD	CABLE, MARK VI
336A4940DTP5BK	CABLE, MARK VI
336A4940DTP5BL	CABLE, MARK VI
336A4940DTP5RD	CABLE, MARK VI
336A4940DTP6BK	CABLE, MARK VI
336A4940DTP6BL	CABLE, MARK VI
336A4940DTP6RD	CABLE, MARK VI
336A4940DTP7BK	CABLE, MARK VI
336A4940DTP7BL	CABLE, MARK VI
336A4940DTP7RD	CABLE, MARK VI
336A4940DTP8BK	CABLE, MARK VI
336A4940DTP8BL	CABLE, MARK VI
336A4940DTP8RD	CABLE, MARK VI
336A4940DTP9BK	CABLE, MARK VI
336A4940DTP9BL	CABLE, MARK VI
336A4940DTP9RD	CABLE, MARK VI
336A5026BGP4BL	Cable

## Starfish PPS - Complete Catalog

Part Number	Description
336A5026P01	CABLE, ADAPTER
336A5126AGP1	DIODE
336A5196AAP8	CARD, COMPACT FLASH MEMORY
3381-1000	ADJUSTER - PISTON STROKE
33N13070	WASHER, STEEL
341A2967P0002	Gasket
341A2967P0026	GASKET, SPIRAL WOUND, 7"ID X 8"OD, GRAPHITE FILL SS, ROUND
341A2967P0068	Gasket
341A2967P0071	GASKET
341A2967P0109	GASKET
341A2967P0132	Gasket, Spiral Wound, 24" ID x 25-1/2" OD, Flexitallic, Carb THK, 316L SS, Round, NS
341A2968P0025	GASKET, SPIRAL WOUND, 5-7/8"ID X 6-15/16"OD, GRAF 3/16" THK, SS, ROUND
341A2968P0072	Gasket
341A2968P0079	Gasket
341A2968P0128	GASKET
341A2968P0178	GASKET
341A4533G0001	Seal
341A5102P0001	Support
342A3647P480W28	Power Supply
342A3647P960W28	Power Supply
342A3647PD40A48	Diode
342A3648P240W28	Power Supply, 240W, 125DC>28DC
342A3648P480W28	Power Supply,480W 28VDC
342A3648P960W24	Power Supply
342A3648P960W28	Power Supply
342A4911P1	TRANSDUCER, CURRENT
342A4922P28V150DHNC	POWER SUPPLY, MARK VI
342A4922P28V150DL	POWER SUPPLY; MARK VI
342A4922P28V150DLA	POWER SUPPLY, MARK VI
342A4922P28V500DL	POWER SUPPLY; MARK VI
344A5938P008	GASKET
344A5942P001	O-RING METALLIC
344A9260P024	Probe
344A9322G005	Vibration Cable
344A9857P069	Hose
3474-12-12-NWO-SS	ADAPTER, ADJUSTABLE
347A5056P001	VALVE, SOL, BLEED AIR
347A5056P001COIL	VALVE, SOL, BLEED AIR, REPLACEMNT
347A5056P002	VALVE, SOL, BLEED AIR
347A5056P004	VALVE, SOL, BLEED AIR
35-35412-2-SS	Water Injection Valve Assembly
3500/05-01-01-01-00-00	Rack
3500/15-01-00-00	ASSEMBLY: POWER SUPPLY
3500/15-01-00-01	ASSEMBLY: POWER SUPPLY
3500/15-01-01-00	ASSEMBLY: POWER SUPPLY
3500/15-01-01-01	ASSEMBLY: POWER SUPPLY
3500/15-01-02-00	ASSEMBLY: POWER SUPPLY
3500/15-01-02-01	ASSEMBLY: POWER SUPPLY
3500/15-01-03-00	ASSEMBLY: POWER SUPPLY
3500/15-01-03-01	ASSEMBLY: POWER SUPPLY

Starfish PPS - Complete Catalog

Part Number	Description
3500/15-01-04-00	ASSEMBLY: POWER SUPPLY
3500/15-01-04-01	ASSEMBLY: POWER SUPPLY
3500/15-02-00-00	ASSEMBLY: POWER SUPPLY
3500/15-02-00-01	ASSEMBLY: POWER SUPPLY
3500/15-02-01-00	ASSEMBLY: POWER SUPPLY
3500/15-02-01-01	ASSEMBLY: POWER SUPPLY
3500/15-02-03-00	ASSEMBLY: POWER SUPPLY
3500/15-02-03-01	ASSEMBLY: POWER SUPPLY
3500/15-02-04-00	ASSEMBLY: POWER SUPPLY
3500/15-02-04-01	ASSEMBLY: POWER SUPPLY
3500/15-03-00-00	ASSEMBLY: POWER SUPPLY
3500/15-03-00-01	ASSEMBLY: POWER SUPPLY
3500/15-03-01-00	ASSEMBLY: POWER SUPPLY
3500/15-03-01-01	ASSEMBLY: POWER SUPPLY
3500/15-03-02-00	ASSEMBLY: POWER SUPPLY
3500/15-03-02-01	ASSEMBLY: POWER SUPPLY
3500/15-03-04-00	ASSEMBLY: POWER SUPPLY
3500/15-03-04-01	ASSEMBLY: POWER SUPPLY
3500/15-04-00-00	ASSEMBLY: POWER SUPPLY
3500/15-04-00-01	ASSEMBLY: POWER SUPPLY
3500/15-04-01-00	ASSEMBLY: POWER SUPPLY
3500/15-04-01-01	ASSEMBLY: POWER SUPPLY
3500/15-04-02-00	ASSEMBLY: POWER SUPPLY
3500/15-04-02-01	ASSEMBLY: POWER SUPPLY
3500/15-04-03-00	ASSEMBLY: POWER SUPPLY
3500/15-04-03-01	ASSEMBLY: POWER SUPPLY
3500/15-04-04-00	ASSEMBLY: POWER SUPPLY
3500/15-04-04-01	ASSEMBLY: POWER SUPPLY
3500/15-05-00-01	POWER SUPPLY, AC
3500/20-01-01-00	ASSEMBLY: RACK INTERFACE
3500/20-01-01-01	ASSEMBLY: RACK INTERFACE
3500/20-01-02-00	ASSEMBLY: RACK INTERFACE
3500/20-01-02-01	ASSEMBLY: RACK INTERFACE
3500/20-02-01-00	ASSEMBLY: RACK INTERFACE
3500/20-02-01-01	ASSEMBLY: RACK INTERFACE
3500/20-02-02-00	ASSEMBLY: RACK INTERFACE
3500/20-02-02-01	ASSEMBLY: RACK INTERFACE
3500/22-01-01-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-01-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-01-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-01-02-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-01-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-00	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-01	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22-02-02-02	ASSEMBLY: INTERFACE, TRANSIENT DATA
3500/22M	MODULE, STANDARD TRANSIENT DATA INTERFACE
3500/25-01-01-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-01-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR

<b>Part Number</b>	<b>Description</b>
3500/25-01-01-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-02-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-02-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-03-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-04-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-04-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-05-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-01-05-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-01-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-01-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-01-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-02-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-02-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-03-02	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-04-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-04-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-05-00	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25-02-05-01	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
3500/25M	MODULE, ENHANCED KEYPHASOR
3500/32-01-00	MODULE, 4-CHANNEL RELAY
3500/32-01-01	MODULE, 4-CHANNEL RELAY
3500/32-01-02	MODULE, 4-CHANNEL RELAY
3500/40-01-00	ASSEMBLY: MONITOR, PROXIMITOR
3500/40-01-01	ASSEMBLY: MONITOR, PROXIMITOR
3500/40-02-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-02-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40-03-02	ASSEMBLY: MODULE, PROXIMITOR
3500/40-04-00	ASSEMBLY: MODULE, PROXIMITOR
3500/40-04-01	ASSEMBLY: MODULE, PROXIMITOR
3500/40M	MONITOR, PROXIMITOR
3500/42-01-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-01-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-02-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-02-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-03-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-03-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-04-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-05-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-06-02	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-07-00	ASSEMBLY: MONITOR, PROX/SEISMIC

<b>Part Number</b>	<b>Description</b>
3500/42-07-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-08-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-08-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-09-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-09-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-10-00	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42-10-01	ASSEMBLY: MONITOR, PROX/SEISMIC
3500/42M	MONITOR, PROX/SEISMIC
3500/44-01-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-01-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-01-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-02-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-02-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-03-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-03-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-05-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-06-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-06-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-07-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-00	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-01	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44-08-02	ASSEMBLY: MODULE, AERODERIVATIVE
3500/44M	MONITOR, AERODERIVATIVE
3500/50M	MODULE, TACHOMETER
3500/64-01-00	ASSEMBLY: DYNAMIC PRESSURE
3500/64-01-01	ASSEMBLY: DYNAMIC PRESSURE
3500/64-01-02	ASSEMBLY: DYNAMIC PRESSURE
3500/64-02-00	MODULE, I/O
3500/64-02-01	MODULE, I/O
3500/64-02-02	MODULE, I/O
3500/64M	MONITOR, DYNAMIC PRESSURE
3500/91-01-01-00	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-01-01	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-01-02	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-00	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-01	ASSEMBLY: GATEWAY COMMUNICATION
3500/91-01-02-02	ASSEMBLY: GATEWAY COMMUNICATION
3500/91M	MODULE, EGD GATEWAY
3500/92	MODULE, COMMUNICATION GATEWAY
3500/92-01-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-01-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-01-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-02-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-03-01-02	ASSEMBLY: COMMUNICATION GATEWAY

Starfish PPS - Complete Catalog

Part Number	Description
3500/92-04-01-00	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-04-01-01	ASSEMBLY: COMMUNICATION GATEWAY
3500/92-04-01-02	ASSEMBLY: COMMUNICATION GATEWAY
3500/93	ASSET, CONDITIONING MONITOR
3500/94M-03-00-01	3500 DISPLAY 10" PANEL MOUNT
350500-00-00-00-01-01	Amp, Dyn Pressure
350500-00-00-00-01-01 (mod 161472-01)	Amp, Dyn Pressure
350500-00-00-00-11-05	AMPLIFIER, PRESSURE, BENTLY NEVADA
3507594	FILTER, OIL
3507598	Filter, Element
3507603	FILTER, OIL MIST
350900-023	Accelerometer
350900-026	Accelerometer
350900-027	Accelerometer
350900-044	Accelerometer
350900-077	Accelerometer
350900-083	Accelerometer
350900-158	Accelerometer
350900-XXX (MOD177228-237)	HTVAS vibration sensor
350901-010	Cable, Bently Nevada
350A4013P0001	Key
351A3236P0001	Pick Up, Magnetic
351A3236P001	Pick Up, Magnetic
351A3236P103	PICK UP, MAGNETIC
351A3445P0002	Thermocouple
351A3445P024	Thermocouple
351A3488P003	Thermocouple type K.ext.
351A3488P005	THERMOCOUPLE, WHEELSPACE
351A3488P006	THERMOCOUPLE
351A3488P023	Wheel-space Thermocouple
351A3488P024	THERMOCOUPLE
351A3488P029	THERMOCOUPLE
351A3488P031	THERMOCOUPLE
351A3488P040	THERMOCOUPLE
351A3496P008	Thermowell, 316
351A7620P104	Kit, Servo
351A7620P105	VALVE, SERVO
351A9090P012	Pressure Switch
351A9091P002	Switch, Pressure
351A9091P002q	Switch, Pressure
351A9091P006	Switch, Pressure
351A9092P003	Switch, Temp
351A9092P014	Switch, Temp
351A9259P002	Gasket
351A9259P005	GASKET INCONEL MESH
351A9554P001	Hydraulic Pump
351A9623P302	PROBE: TYPE VIBRATION DETECTION
351A9623P502	3300 XL 8MM
351A9623P602	Cable, Proximito
351A9623P702	3300 XL 5/8mm Proximito Sensor
352A6633P002	

Starfish PPS - Complete Catalog

Part Number	Description
	Thrust Washer
353A4330P005	Pressure Transmitter
353B1135P002	Pin
353B1136P001	Pin
353B3535P001	Nut, Round
353B3535P004	Round Nut
3543-169	Ring, Spacer, valve
354A1400P001	Seal
354A1513P013	Igniter Lead Assembly
354A1513P014	LEAD, FLEXIBLE, SPARK PLUG IGNITION
354A1513P104	Ignition Lead
354A1513P110	Lead, Ignition
354A1513P111	Lead, Ignition
354A1513P112	Lead, Ignition
354A1513P113	Lead, Ignition
354A1513P114	Lead, Ignition
354A1513P134	CABLE, IGNITION SYSTEM
354A1513P140	Lead, Ignition
354A1513P141	Lead, Ignition
354A1513P142	Lead, Ignition
354A1513P143	Lead, Ignition
354A1513P144	Lead, Ignition
354A1513P150	Lead, Ignition
354A1513P151	Lead, Ignition
354A1513P152	Lead, Ignition
354A1513P153	Lead, Ignition, Flexible, 32 foot
354A1513P171	Lead, Ignition
354A1513P172	Lead, Ignition
354A1513P173	Lead, Ignition
354A1513P174	Lead, Ignition
354A1513P181	Lead, Extension
354A1513P184	Lead, Ignition
354A1513P185	Lead, Ignition
354A1513P186	Lead, Ignition
354A1513P187	Lead, Ignition
354A1513P188	Lead, Ignition
354A1513P189	Lead, Ignition
354A1617P001	VALVE, SOLENOID
354A1709P102	Exciter
354A1709P103	Exciter
354A3606P007	VALVE, CHECK
354B4114P0001	Lug
355A8234P0001	Valve
355B5883G001	Valve, Assembly
355B6801P001	Nut
355B7915P001	Stud
355B7917P006	Body Bound Stud
355B7917P018	Body Bound Stud
356A1933P002	Air Pressure Regulator
356A1957P001	Gasket
356A1961P001	Gasket

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
356A3211P001	Igniter, HT
356A3217P001	Igniter
356A3680P001	Ignition Transformer
356A3871P001	Bushing, IGV
356A3871P002	Bushing, IGV
356A3871P003	Bushing, IGV
357A1019P002	Lockplate
357A1233P106	Filter Assembly
357A2304P0001	Gasket
357B1004P011	Pin Dowel
357B1004P012	Pin Dowel
357B3815P001	12PT BOLT
358A6954P0001	Regulator
361A2285P007	Detector, Temp
361A2285P113	Detector
361A2289P010	Thermocouple - KK-316LSS12-U-THS(4")-110.0",- WITH A
361A2289P128	Thermocouple
361A2289P135	Thermocouple, Wheelspace
361A2289P148	Thermocouple, Wheelspace
361A2289P193	Thermocouple, Wheelspace
361A2289P327	THERMOCOUPLE, WHEELSPACE
361A2289P330	Thermocouple, Wheelspace
361A2289P332	THERMOCOUPLE, WHEELSPACE
361A2289P333	THERMOCOUPLE, WHEELSPACE
361A2289P335	Thermocouple, Wheelspace
361A2289P336	THERMOCOUPLE, WHEELSPACE
361A2289P337	Thermocouple, Wheelspace
361A2289P672	Thermocouple, Wheelspace
361A2289P766	Thermocouple
361A2327P024	CABLE, THERMOCOUPLE
361A2327P025	Thermocouple
361A2327P026	CABLE, THERMOCOUPLE
361A2327P031	Thermocouple
361A2373G001	RTD, Dual
361A2538P003	CLAMP
361A2558P002	CABLE, FLAME SCANNER
361A2943P004	Valve, Check
361A6207P006	VALVE
361A6233P0002	Regualtor
361B4929P0001	Controller, Servo Position
362A1052P004	Flame Sensor
362A1052P104	Flame Sensor
362A1052P404	Flame Sensor
362A1052P406	FLAME TRACKER
362A1053P001	CABLE, UV FLAME DETECTOR
362A1053P002	CABLE, UV FLAME DETECTOR
362A1053P031	CABLE, UV FLAME DETECTOR
362A1053P036	CABLE, UV FLAME DETECTOR
362A1102P017	Thermocouple, Exhaust
362A1102P022	Spring Loaded Thermocouple
362A1331P002	VALVE, CHECK
362A1344P011	Thermowell

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
362A1514P001	Seal, set
362A1577P003	Valve, Servo
362A1591P001	Hose, Flexible, Primary Can
362A1591P003	Hose
362A1739P001	GASKET
362A1885G001	RTD, Dual
362A1885G004	Thermocouple
362A1885G008	Thermocouple
362A1997P040	CABLE, SERVO
362A1998P040	CABLE, LVDT
362A2968P003	Switch
362A3342P0005	CABLE, FLAME SENSOR
362A3342P002	CABLE, UV FLAME DETECTOR
362A3342P010	CABLE
362A3345P103	CABLE, T/C
362A3345P105	CABLE, T/C
362A3345P106	CABLE, T/C
362A3345P203	CABLE, THERMOCOUPLE
362A3798P002	THERMOCOUPLE
362A3798P004	THERMOCOUPLE
362A3798P023	THERMOCOUPLE
362A3798P026	THERMOCOUPLE
362A3952P001	Igniter, HT
362A6563P001	Actuator
3638-036	FITTING, ROD PORT
363A5542P001	Pressure Switch
363A5542P003	Pressure Switch
363A5542P007	Pressure Switch
363A5542P008	Pressure Switch
363A5542P009	Pressure Switch
363A5542P023	Pressure Switch
363A5542P056	Switch, Pressure
363A5542P066	Switch, Pressure
363A5542P102	Switch, Pressure
363A5542P121	Switch, Pressure
363A5542P123	Switch, Pressure
363A5543P011	Switch, Pressure
363A5543P221	Switch, Pressure
363A5550P003	Vent Valve
364A7036P0003	KIT, REPAIR
365A3217P003	Igniter
365A3217P004	Igniter
366A2868P004	Butterfly Valve
366A772G2	COIL
368887	HOSE, ASSY, HYDRAULIC START RETURN
368A6037P0002	Filter Element
368A6037P001	Lube Oil Filter
368B4055P001	Carbon Brush
369B1369P0001	Relay
369B1444P0002	Power Supply, Micronet
369B1444P0011	Module, Transformer
36A167401AAP07	Brush, Electrical Set

## Starfish PPS - Complete Catalog

Part Number	Description
36A167402AAP08	Brush, Electrical Set
36C774345AAG01	ASSEMBLY, MFC
37-102-109	CABLE, 8AWG
371A6407P014	Valve
371A6408P003	Valve, 2 in
371A6408P006	Valve, 3 in
371A6417P001	Valve, Control
371A6421P002	VALVE, AUX GAS STOP
372A1159P008	Gasket
372A1159P100	Gasket
372A1159P109	GASKET, SPIRAL WOUND
372A1159P110	GASKET
372A2221P012	Thermocouple, Exhaust
372A2221P022	Thermocouple, Exhaust
372A2221P022-AR	THERMOCOUPLE, AS REMOVED
372A2287P010	Thermocouple
372A2287P332	Thermocouple
372A2287P333	Thermocouple
372A2287P336	Thermocouple
372A2287P766	Thermocouple
372A3188P002	Accelerometer
372A3281G001	RTD, Dual
377A1000P0001	MOTOR, LUBE, GLO AC
377A1000P001	MOTOR, LUBE, GLO AC
377A1001P0001	Motor, GLO
377A1001P001	Motor, GLO
377A1009P0002	Motor, Electric, Gen Enclosure Fan
377A1024P0000	Element, Filter
377A1047P0000	GASKET, SPIRAL WOUND
377A1072P0000	BOLT, HEX
377A1074P0000	NUT, HEX
377A1125P0000	ASSEMBLY: DOOR LATCH AND STRIKER
377A1125P0000-L	LATCH
377A1125P0000-S	STRIKER
377A1142P0000	Seal, Door
377A1151P0000	Filter Element
377A1151P0001	Filter
377A1152P0001	FILTER, ELEMENT, 3 MICRON, GLO
377A1164P0000	VALVE, CONTROL
377A1196P0001	Auto/Manual Release SOV
377A1196P0002	CABLE, ELEC, OPR CONTROL HEAD
377A2233P0001	Plain Nut Discharge Head
377A2245P0001	CO2 Hose
377A2245P0002	CO2 Hose
377A2300P0001	Valve, Ball, Kitz
377A2318P0001	Orifice
377A2326P0001	GAUGE, DIFFERENTIAL, 0-30
377A2365P0001	Tape
377A2435P0001	GASKET, SPIRAL WOUND
377A2452P0001	BASKET, STRAINER
377A2492P0001	GUARD, SWITCH RAMP
377A2522P0001	Coupling

Starfish PPS - Complete Catalog

Part Number	Description
377A2540P0001	SWITCH, FLOW
377A2560P0001	BOLT, HEX
377A2561P0001	BOLT, HEX
377A2564P0001	Coupling
377A2584P0001	Sprint Valve
377A2589P0001	VALVE, SOLENOID
377A2590P0001	VALVE, SOLENOID
377A2591P0001	VALVE, SOLENOID
377A2687P0001	VALVE, SOLENOID
377A2796P0001	Relay
377A6507P0001	CHARGE PUMP SUCTIONPRESSURE GAUGE
377A6542P0001	TRANSDUCER, VOLTS LM SERIES
377A6552P0001	Valve, Check
377A6553P0001	Signal conditioner
377A6580P0001	Transmitter
377A6581P0001	Compressor Discharge Pressure PS3
377A6583P0002	Transmitter, pressure
377A6585P0001	Compressor Discharge Pressure PS3
377A6712P0001	SOCKET, TEST BLOCK
377A6716P0001	Innova touch screen
377A6726P0001	MODULE
377A6813P0001	Transmitter, Level, GLO
377A6816P0002	MODULE, SYSTEM, SYNCHRONIZING
377A6847P0003	METER, FLOW
377A6857P0001GSKT	GASKET, 764-SS-2"
377A6857P0001STRN	Strainer Insert
377A6869P0001	Valve, 3-WAY
377A6869P0001 - AR	VALVE, 3-WAY
377A6870P0001	VALVE, 2-WAY
377A6870P0001 - AR	VALVE, 2-WAY
377A6887P001	Gas Fuel Check Valve
377A6899P0001	FUSE, MIDGET, 15A
377A6914P0001	PUMP, START
377A6914P0001-AR	PUMP, START
377A6914P0001-OH	PUMP, START
377A6927P0001	Amp, Dyn Pressure
377A6983P0001	Detector, Level
377A7011P024	Valve, Fuel Gas Stop Valve
377A7014P024	SRV,W/ 6 INCH FSHR VALVE, DUAL LVDT
377A7053P102	Element, Strainer Basket
377A7053P202	Gasket
377A7701P0001	VALVE, SOLENOID
377A7707P0001	Module, input, fire system
377A7711P0001	Accumulator
377A7725P0001	Cable, Process Control
377A7740P0001	VALVE, SOLENOID
377A7746P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
377A7762P0001	CURRENT OUTPUT & RELAY
377A7763P0001	Exchanger, Heat
377A7763P0002	Exchanger, Heat
377A7807P0001	RTD
377A7811P0001	Gasket

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
377A7813P0001	GSOV, Woodward
377A7814P0001	MANUAL PULL
377A7825P0001	Valve, Check
377A7852P0001	FOD Sock
377A7866P0002	THERMO VALVE
377A7873P0001	Turnbuckle
377A7898P0001	Y-STRAINER
377A7898P0001-GSKT	GASKET, Y-STRAINER
377A7898P0001-STRN	BASKET, MESH, Y-STRAINER
377A7898P0001A	Y Strainer Kit, Basket & Gasket
377A7898P0002	Y-STRAINER
377A7957P0001	SCREEN, INLET, Y-STRAINER
377A7957P0001GSKT	GASKET, INLET SCREEN, Y-STRAINER
377A8007P0001	Valve,fuel
377A8008P01	CABLE, ACCELEROMETER
377A8010P0001	CABLE, ACCELEROMETER
377A8017P0001	Valve
377A8054P0001	VALVE, GSOV
377A8134P0001	AC Unit
377A8153P0001	Manual Pull Module
377A9841P002	Filter
377A9841P003	Filter
378A1742P0001	VALVE, SOLENOID
3799-301	BRACKET
379A9681P001	Hex Head Bolt
379A9681P002	Hex Nut
379A9705P012	THERMOCOUPLE, WHEELSPACE
379A9705P053	Thermocouple
379A9716P001	Gland
379A9798P010	Transducer
379A9798P040	Transducer
37C75KSB	SCREW, COUNTERBORE
38-18604-2024-3	Screen ASSY
38-18604-2025-3	Screen ASSY
38-18604-2026-3	Screen ASSY
3813-08-003-C	Valve, Transfer
381A6159P315	Valve
381A6160P306	Valve
381A6160P307	Valve
381A6160P311	Valve
381A7058P004	Servo Valve
381A7058P005	Valve, Servo
381AG1G0P311	Valve
3820-11-001-A	FILTER, HYDRAULIC
3823C16G01	Fuse
382A1079P0001	Transmitter, pressure
382A1109P0001	Gasket, Spiral Wound
382A1201P0001	ISGH FILTER
382A1203P0001	Filter, Element, Sprint
382A1209P0002	Valve, Fuel Metering
382A1213P0001	MODULE, INTERFACE
382A1250P0001	E-SEAL, RING

Starfish PPS - Complete Catalog

Part Number	Description
382A1251P0001	E-SEAL, RING
382A1252P0001	E-SEAL, RING
382A1284P0001	WATER INJECTOR PUMP
382A1286P0001	BOLT, HEX
382A1294P0001	SWITCH, FLOW
382A1351P0001	Valve, Check
382A1357P0001	Transmitter
382A1367P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
382A1379P0001	Flame Sensor
382A1426P0001	GAUGE, DIFF PRESSURE
382A1450P0002	KIT: AERO PARTS, EX2100e
382A3006P0001	MOTOR, STARTER
382A3006P0001-AR	MOTOR, STARTER, AS REMOVED
382A3006P0001-OH	MOTOR, STARTER, OVERHAULED
382A3743P0001	RTD Module
382A3746	
382A3746P0001	Logic Fast Input, 16 Point, Grouped
382A3780P0001	VALVE, PRESSURE SAFETY
382A3780P0003	VALVE, PRESSURE SAFETY
382A3781P0001	VALVE, PRESSURE RELIEF
382A3782P0001	VALVE, PRESSURE SAFETY
382A3782P0003	VALVE, PRESSURE SAFETY
382A3791P0001	TRANSMITTER, ROTOR, EARTH FAULT
382A3800P0001	VBV Boot
382A3860P0100	MOTOR, STARTER
382A3860P0H1B	MOTOR, STARTER
382A3861P0100	Clutch
382A3918P0001	GASKET, SPIRAL WOUND
382A3918P6005	GASKET, SPIRAL WOUND
382A3945P0001	PLUG, C 8 WIRE
382A3946P0001	CONNECTOR, H-SHAPED
382A3947P0001	CAP
382A3948P0001	CABLE, TERMINAL BLOCK
382A4000P0001	450 Degree Thermal Spot Detector
382A4003P0001	Strobe Dual Listed ATEX, UL
382A4068P001	VALVE, SOLENOID
382A4102P0001	Relief Valve
382A4154P0001	FOD Sock
382A4161P0001	TLO Filters Differential Pressure Switch
382A4168P0001	Switch, pressure
382A4169P0001	Switch, Pressure, Adj.
382A4170P0001	Switch, Temperature
382A4171P0001	SWITCH, TEMPERATURE, ADJUSTABLE
382A4172P0001	Switch, Pressure
382A4173P0001	SWITCH, PRESSURE
382A4174P0001	Switch, Pressure
382A4198P0001	Switch, Differential Pressure
382A4441P0001	Low Pressure Liquid Fuel Filter Assembly
382A4449P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE, 505, ME
382A4454P0001	Gasket, FLG
382A4465P0001	Flame Sensor
382A4470P0002	BALL VALVE

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
382A4495P0001	CABLE, LIQUID FUEL VALVES
382A4496P0001	CABLE, LIQUID FUEL VALVES
382A4497P0001	CABLE, DRAIN VALVES
382A4501P0001	VICOR, DC CONVERTER
382A4506P0001	Pilot Valve
382A4521P0001	ADAPTER, 1 1/4IN MSAE
382A4544P0001	POWER SUPPLY
382A4546P0001	MODULE, RELAY
382A4652P0001	Detector, gas
382A4669P0001	SENSOR, FLAME
382A4670P0001	Flame Sensor Mounting Arm
382A4677P0001	VALVE, NEEDLE
382A4694P0001	FLOW METER,VORTEX
382A4695P0002	ASSEMBLY, METER/CONVERTER, FLOW, 2IN
382A4720P0001	SENSOR, GAS
382A4742P0001	Pump, Jacking Oil
382A4762P0001	A30 Con Complete
382A4774P0001	Generator/Gearbox DC Lube Pump
382A4775P0001	Motor, GLO Lube
382A4776P0001	Top mounted float switch
382A4821P0001	VALVE, FLOW CONTROL, WATER INJ.
382A4821P0001-AR	AS REMOVED VALVE, WATER
382A4828P0001	Woodward Driver
382A4828P0001-AR	WOODWARD DRIVER
382A4848P0001	Transmitter
382A4866P0001	PSM-ME-RS232/RS485
382A4891P0001	TBV Gasket
382A5230P0001	MOTOR, 25 hp
382A5237P0001	C10 Low Speed Detector
382A5248P0001	Switch, pressure
382A5249P0001	switch, pressure
382A5250P0001	Switch, Press., Adj., Diff.
382A5254P0001	VALVE, SOL
382A5275P0002	GSOV
382A5278P0001	Filter Element
382A5278P0001-KIT	Filter Kit for Liquid Fuel Filter Assembly
382A5291P0001	PRESSURE, DIFF
382A5322P0001	Gas Valve, Woodward
382A5323P0001	Valve, Control, LQ25
382A5340P0002	FLOWMETER AND CONVERTER ASSEMBLY
382A5340P0003	Flowmeter
382A5355P0001	TRANSMITTER, PRESSURE
382A5355P0003	TRANSMITTER, PRESSURE
382A5367P0001	Cap, Air Breather
382A5374P0002	Flow Meter - Nox Water
382A5374P0003	Flow Meter - Nox Water
382A5376P0001	TRANSMITTER, PRESSURE
382A5380P0001	Cable
382A5390P0001	Strainer, Y
382A5391P0001	450 Degree Thermal Spot Detector
382A5392P0001	450 Degree Thermal Spot Detector
382A5412P0001	SWITCH, HORN

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
382A5412P0002	SWITCH, HORN
382A5419P0001	STROBE
382A5426P0001	Gen Lube Pump
382A5454P0001	VALVE, BYPASS
382A5465P0002	VALVE, SOLENOID
382A5471P0002	VALVE, SOLENOID
382A5476P0002	VALVE, SOLENOID
382A5485P0001	Valve, Control
382A5488P0001	Washer
382A5489P0002	Fuel Manifold Drain Valve
382A5504P0002	VALVE, SOLENOID
382A5505P0002	VALVE, SOLENOID
382A5506P0002	Nat Gas vent valve
382A5507P0002	Heater
382A5508P0002	Heater, GLO
382A5509P0002	Heater
382A5510P0001	HEATER
382A5510P0002	Heater
382A5512P0001	Exchanger, Heat
382A5516P0001	GLO A/O Separator, Electronic Precipitator
382A5517P0001	Gland, cable
382A5519P0001	MOTOR, START, 200 HP 3600 / 3000 RPM
382A5524P0001	ASSEMBLY: GSOV
382A5526P0001	VALVE, DRAIN
382A5528P0001	Valve, Fuel, Liquid
382A5530P0001	Valve, USOV
382A5530P0001-OH	VALVE, USOV
382A5532P0001	Valve
382A5533P0001	Valve, Metering
382A5533P0002	Valve, Metering
382A5547P0001	Motor, GLO Lube
382A5578P0001	Pump, Water Wash
382A5578P001-AR	Pump, Water Wash, As Removed
382A5579P0001	CABLE
382A5582P0001	Relay
382A5582P01	Relay
382A5599P0001	Probe, Vibration
382A5610P0001	Heater
382A5616P0001	CABLE
382A5619P0001	NOZZLE, AMMONIA
382A5640P0001	VALVE, SOL
382A5646P0001	VALVE, SOLENOID
382A5648P0001	Fan, Generator
382A5652P0001	Sprint Pump
382A5653P0001	FILTER HOUSING ASSEMBLY
382A5653P0002	FILTER HOUSING ASSEMBLY
382A5655P0001	TRANSMITTER
382A5656P0001	TRANSMITTER
382A5656P0003	TRANSMITTER
382A5656P0004	TRANSMITTER
382A5657P0001	TRANSMITTER, PRESSURE
382A5658P0001	Fuel Gas Pressure Transmitter

Starfish PPS - Complete Catalog

Part Number	Description
382A5658P0003	Transmitter, pressure
382A5659P0001	SENSOR, PRESSURE
382A5660P0001	TRANSMITTER, PRESS
382A5661P0001	Transmitter, pressure
382A5662P0001	Transmitter, pressure
382A5669P0001	HEATER
382A5672P0001	Switch, Level
382A5673P0001	Transmitter, Diff
382A5677P0001	ISOLATOR, VIBRATION
382A6205P0001	AIR CONDITIONER
382A6206P0001	AIR CONDITIONER
382A6217P0001	IR Gas Detector
382A6219P0001	Pressure regulator
382A6227P0001	VALVE, CHECK
382A6229P0001	TRANSMITTER, LEVEL
382A6232P0001	SHAFT, GEN. VENT FAN
382A6235P0001	TRANSMITTER
382A6238P0001	MODULE. DCIO, DIN RAIL
382A6238P0001-AR	MODULE, DCIO, AS REMOVED
382A6241P0001	Dry Line Discharge Pressure Switch
382A6242P0001	SENSOR, FLAME
382A6242P0002	SENSOR, FLAME
382A6250P0001	SWITCH, DOOR
382A6265P0001	CO2, MANUAL PULL
382A6272P0001	PUMP, LIQUID
382A6280P0001	Valve, Check
382A6287P0001	Wire, CABLE, TRAY
382A6293P0001	CABLE
382A6294P0001	Cable
382A6294P001	Cable
382A6298P0001	4 WIRE (12AWG), 3 INS & 1 BARE
382A6317P0001	VALVE, LQ25
382A6329P0001	THREAD CONVERTER, 3 INCH TO 2 INCH
382A6332P0001	WIRE, SHIELDED
382A6335P0001	GLO Pressure Transmitter
382A6340P0001	VALVE, SOL
382A6342P0001	Term Block
382A6345P0001	4" Single Expansion Joint
382A6353P0001	Valve, CDP
382A6353P0001-OH	VALVE, CDP
382A6354P0001	Valve, CDP
382A6354P0001-AR	VALVE, CDP
382A6354P0001-OH	VALVE, CDP
382A6355P0001	VALVE, CDP
382A6355P0001-OH	VALVE, CDP
382A6356P0001	VALVE, DRAIN
382A6387P0001	CO2 Cylinder
382A6388P0001	Auto/Manual Release SOV
382A6389P0001	COUPLING, COMPLETE- MOTOR HUB, PUMP HUB, NEOPRENE
382A6389P0001-INSERT	INSERT
382A6389P0001-INSERT	Coupling Insert, Neoprene
382A6399P0001	VALVE, SOLENOID

## Starfish PPS - Complete Catalog

Part Number	Description
382A6400P0001	Valve
382A6402P0001	SWITCH, HORN
382A6406P0001	Block Valve
382A6459P0001	CABLE
382A6461P0001	VALVE, CHECK
382A6461P0002	Valve, Check
382A6517P0001	Pump, Start
382A6540P0001	CABLE, RTD
382A656548P0001	Fan, Generator
382A6600P0001	CABLE, NPT SPEED
382A6604P0001	CABLE, T3 COMP DISCHARGE
382A6621P0001	Valve, Check
382A6632P0002	Pump
382A6641P0001	Valve, Check
382A6646P0001	CABLE, DUAL RTD/VSV LVDT, T2 SENSOR
382A6647P0001	CABLE, ACCELEROMETER
382A6662P0001	BOLT
382A6668P0001	Valve, Control
382A6668P0001-KIT	Kit- overhaul
382A6674P0001	Valve, Check
382A6676P0001	Stud
382A6688P0001	TRANSMITTER, PRESSURE
382A6793P0001	WIRE
382A6798P0001	WIRE
382A7005P0001	TRANSFORMER, CURRENT
382A7010P0001	PUMP, MLO AC Pump
382A7010P0002	PUMP, MLO AC Pump
382A7010P0003	PUMP, MLO AC Pump
382A7013P001	Pump, Lube, DC
382A7014P0002	Element, Filter, MLO
382A7024P0001	Exchanger
382A7051P0001	NOx Water Pump+Motor Assembly, VFD (Overhauled)
382A7064P0001	Pump Motor Assembly
382A7067P0001	Valve, Check
382A7123P0001	VALVE, GAS SHUTOFF
382A7146P0001	Valve, External Gas Fuel Vent
382A7169P0001	Valve
382A7174P0001	Gauge
382A7180P0001	Transmitter, Level
382A7186P0001	VALVE, RELIEF
382A7186P0001-AR	VALVE, RELIEF, AS REMOVED
382A7186P001-OH	VALVE, RELIEF, OVERHAULED
382A7188P0001	VALVE, CONTROL, LQ25
382A7188P0001-AR	VALVE, AS REMOVED
382A7188P0001-OH	VALVE, OVERHAULED
382A7191P0001	VALVE, BALL, MANUAL, 3 IN, SCHEDULE 40
382A7191P0002	VALVE, BALL, MANUAL, 3 IN, SCHEDULE 40
382A7198P0001	VALVE, WATER
382A7198P0001-AR	VALVE, WATER, AS REMOVED
382A7198P0001-OH	Valve, Water, OVERHAULED
382A7203P0001	Y STRAINER, INLET SCREEN
382A7203P0001BSKT	SCREEN, REPLACEMENT, 100 MESH

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
382A7203P0001GSKT	Y STRAINER GASKET
382A7215P0001	Lube Pump
382A7236P0001	Valve, Drain, Manifold
382A7241P0001	WASHER, BEVELED
382A7257P0001	CABLE, OFF-ENGINE
382A7258P0001	Cable, Off-Engine
382A7259P0001	Cable, Off-Engine
382A7260P0001	Cable, Off-Engine
382A7261P0001	CABLE, OFF-ENGINE
382A7262P0001	Cable, Off-Engine
382A7264P0001	Cable, Off-Engine
382A7265P0001	Cable, Off-Engine
382A7266P0001	Cable, Off-Engine
382A7267P0001	Cable, Off-Engine
382A7268P0001	CABLE, OFF-ENGINE
382A7269P0001	Cable, Off-Engine
382A7270P0001	Cable, Off-Engine
382A7271P0001	Cable, Off-Engine
382A7272P0001	Cable, Off-Engine
382A7273P0001	Cable, Off-Engine
382A7274P0001	Cable, Off-Engine
382A7275P0001	Cable, Off-Engine
382A7276P0001	Cable, Off-Engine
382A7277P0001	Cable, Off-Engine
382A7278P0001	CABLE, OFF-ENGINE
382A7279P0001	Cable, Off-Engine
382A7280P0001	Cable, Off-Engine
382A7281P0001	Cable, Off-Engine
382A7282P0001	Cable, Off-Engine
382A7283P0001	Cable, Off-Engine
382A7284P0001	Cable, Off-Engine
382A7285P0001	Cable, Off-Engine
382A7286P0001	Cable, Off-Engine
382A7287P0001	Cable, Off-Engine
382A7291P0001	Filter Assembly
382A7292P0001	TRANSMITTER, PRESSURE
382A7293P0001	TRANSMITTER, PRESSURE
382A7296P0001	ASSEMBLY: METER, FLOW
382A7298P0001	METER, FLOW
382A7299P0002	Flow Meter, linear link
382A7300P0001	CABLE
382A7308P0001	Drain Trap
382A7308PP0001	TRAP, DRAIN
382A7311P0001	Motor, Hydraulic Starter
382A7312P0001	Nozzle, Size 10
382A7315P0001	ASSEMBLY: DETECTOR, GAS
382A7318P0001	ASSEMBLY: POWER SUPPLY
382A7319P0001	Block, External Termination
382A7322P0001	Valve, Fuel, Metering
382A7325P0001	VALVE, PURGE
382A7325P0001-AR	VALVE, PURGE, AS REMOVED
382A7326P0001	VALVE, VENT

## Starfish PPS - Complete Catalog

Part Number	Description
382A7326P0001-OH	VALVE, OVERHAULED
382A7327P0001	ASSEMBLY: INTERFACE, TRANSIENT DATA
382A7328P0001	ASSEMBLY: GATEWAY COMMUNICATION
382A7329P0001	ASSEMBLY: MODULE, ENHANCED KEYPHASOR
382A7330P0001	SENSOR, FLAME
382A7331P0001	ASSEMBLY: MONITOR, PROXIMITOR
382A7332P0001	ASSEMBLY: MONITOR, PROX/SEISMIC
382A7333P0001	Block, External Termination
382A7334P0001	Block, Term
382A7335P0001	RACK, INSTRUMENT
382A7345P0002	Valve, Check
382A7348P0001	FILTER
382A7352P000	CONTROLLER, PANEL MOUNT
382A7352P0001	CONTROLLER, PANEL MOUNT
382A7362P0001	ACCUMULATOR, HYDRAULIC
382A7363P0001	ACCUMULATOR, HYDRAULIC
382A7370P0002	Pump, Hydraulic
382A7370P0003	Pump, Hydraulic
382A7380P0001	VALVE, RELIEF
382A7393P0001	VALVE, PRESS CONTROL
382A7394P0001	VALVE, PRESS CONTROL
382A7395P0001	VALVE, SOLENOID
382A7408P0001	LIQUID FUEL
382A7408P0002	LIQUID FUEL
382A7408P0003	LIQUID FUEL
382A7409P0004	PUMP, WATER INJECTION
382A7422P0000	Pump, Water Wash
382A7422P0000-AR	Pump, Water Wash, As Removed
382A7450P0001	Valve, Shut Off
382A7451P0001	VALVE, CONTROL, ASSY
382A7487P0001	Valve, Check
382A7496P0001	Check Valve
382A7814P0001	Switch, Manual Release
382A9205P0001	Accelerometer
382A9206P0001	Accelerometer
382A9207P0001	Accelerometer
382A9208P0001	Accelerometer
382A9209P0001	Accelerometer
382A9210P0001	Accelerometer
382A9215P0001	Signal conditioner
382A9222P0001	Insert, Coupling
382A9223P0001	Coupling Half - Motor, Keyed
382A9224P0001	Coupling Half - Pump, Splined
382A9227P0001	PLATE, ORIFICE
382A922PV500DL	Accelerometer
382A9230P0001	Pump/Motor Adapter
382A9245P0001	HEATER 5KW CHROMALOX
382A9246P0001	HEATER
382A9250P0001	HEATER
382A9252P0001	FLAME ARRESTER
382A9253P0001	CABLE, WOODWARD
382A9254P0001	CABLE ASSEMBLY, LOW DENS. ANALOG,12FT

Starfish PPS - Complete Catalog

Part Number	Description
382A9255P0001	CABLE-MICRONET HIGH DENSITY
382A9258P0001	PUMP, STARTER
382A9258P0001-AR	STARTER, PUMP AS REMOVED
382A9260P0001	Probe, Vibration
382A9359P0001	Flow METER
382A9359P0002	METER, FLOW
382A9360P0001	Flow Regulator
382A9361P0001	Flow Regulator
382A9372P0001	STUD
382A9374P0001	STUD
382A9406P0001	Power Supply
382A9408P0001	Detector, Temp
382A9462P0001	VALVE, SOLENOID
382A9518P0001	TEMP, ELEMENT
382A9529P0001	Cable, Off-Engine
382A9540P0001	Filter, H2O Injection Skid
382A9594P0001	HEATER, IMMERSION, 3", 150 LB RAIS
382A9602P0001	DUPLEX, GAS, FUEL, 3" 3um
382A9606P0001	Filter Element
382A9622P0001	CABLE, ACCELEROMETER
382A9623P0001	CABLE, NPT SPEED
382A9625P0001	Cable, Electrical
382A9634P0001	Switch, Ethernet, 8 Port
382A9637P0001	RTD, MLO Tank
3830-11-XXXJ	Filter, Element, Sprint
3830-12-133	Natural Gas Filter
383543	Shaft, Fan, Gen
383A4156P0020	DIGITAL SPEED SENSOR
383A4156P0032	MODULE, I/O
383A4156P0058	Module, Micronet, Analog I/O
383A4156P0058-OH	MODULE, OVERHAULED
383A4156P0065	Module, Actuator Netcon CONT.2C
383A4156P0075	Woodward Micronet Simplex Power Supply
383A4205P0002	Diode Module
3840-01-021	Filter, H2O Injection Skid
3840-12-137	Filter Element
3840-12-148	Filter Element
3850-14-009	DUPLEX, GAS, FUEL, 3" 3um
3862-4	Kit, Clamshell
3862-5	Bolt Kit LPC Inlet Expansion
3862-6	KIT, BOLT, VBV DUCT
3862-7	KIT, BOLT, VBV DUCT, EXPANDED
386A3003P0001	450 Degree Thermal Spot Detector
386A3008P0001	225 Degree Thermal Spot Detector
386A3009P0001	THERMAL BET
386A3014P0001	4-20 mA Gas Module
386A3018P0001	Status Module
386A3089P0001	CHASSIS
386A3092P0001	450 Degree Thermal Spot Detector
386A3104P0001	Block Valve
386A3120P0001	Seal, Strip

Starfish PPS - Complete Catalog

Part Number	Description
386A3125P0001	HORN, DUAL
386A3126P0001	HORN
386A3126P0002	HORN
386A3127P0001	DETECTOR, THERMAL SPOT, 450 DEGREE
386A3136P0001	STROBE
386A3142P0001	Nozzle, Size 9+
386A3175P0001	VALVE, BLOCK, 2-WAY, COAX
386A3176P0001	Valve, 3 way
386A3188P0001	Element Kit, Filter
386A3206P0001	Cooler
386A3206P0002	EXCHANGER, HEAT
386A3227P0002	Pump, lube oil
386A3227P0003	PUMP, LUBE OIL
386A3312P0001	Gasket, Exciter
386A3318P0001	Gasket, Exciter (set of 2)
386A3319P0001	Gasket, Exciter (set of 2)
386A3384P0001	HORN
386A3385P0002	Woodward DRIVER
386A3537P0001	SIGHT GLASS
386A3567P0001	GAUGE, SIGHT
386A3568P0001	Fan, Vent
386A3568P0002	Fan, Vent
386A3582P0001	CABLE, CHIP DETECTOR
386A3587P0001	MODULE, I/O
386A3662P0001	Washer
386A3695P0001	SWITCH, LEVEL
386A3793P0008	VALVE, GLOBE, 2IN, 150LB, RAISED FACE
386A3796P0001	BOLT, HEX
386A3798P0001	BOLT, HEX
386A3811P0001	Valve, solenoild, J3 Pressurization
386A3904P0001	Module, Transformer
386A3985P0002	Motor, 200 HP
386A6008P0001	DETECTOR, TEMPERATURE
386A6008P0002	RTD
386A6387P0001	Cylinder, CO2
386A6401P0001	Manifold, inlet flow straightener
386A6409P0001	SIGHT GLASS
386A6434P0001	BOLT
386A6466P0001	Cable, Hydraulic Starter Clutch Oil
386A6527P0001	Relay; Basler;
386A6553P0001	Transmitter, Level
386A6581P0001	Filter
386A6632P0002	Pump Assembly
386A6636P0001	Water Injection Pump Discharge Filter
386A6676P0001	TRANSMITTER
386A6685P0001	Element, Filter, MLO
386A6687P0001	Filter
386A6687P0001-AM	FILTER, AFTERMARKET
386A6700P0001	TRANSMITTER, LEVEL
386A6701P0001	Transmitter, Level
386A6703P0001	Transmitter, Level
386A6778P0001	Nozzle, Size 9

## Starfish PPS - Complete Catalog

Part Number	Description
386A6796P0001	4 WIRE (10AWG), 3 NUMBERED INS & 1 BARE
386A6804P0001	VALVE
386A6857P0001	Valve, Fuel, 2"
386A6860P0001	CABLE, ASSEMBLY, DRIVER TO VALVE
386A6864P0001	CABLE, CLUTCH HTVAS VIBRATION
386A6873P0001	Accumulator
386A6874P0001	SENSOR, FUEL TEMP
386A6878P0001	Hose, Brush
386A6880P0001	Temp Sensor
386A6881P0001	HOSE
386A6889P0001	Clamp
386A6897P0001	ASSEMBLY: DETECTOR, GAS, COMBUSTIBLE, 505, ME
386A6925P0001	Regulator
386A6979P0001	NUT, HEAVY HEX
386A6981P0001	Valve, Check
386A6988P0001	TRANSMITTER, PRESSURE
386A6994P0001	CABLE, ACCEL, CRF/TRF
386A7026P0001	Bellows
386A7026P0001FAB	Expansion Joint
386A7026P0001FABRIC KIT	Expansion Joint
386A7028P0001	Filter, Element
386A7048P0001	VIBRATION PROBE ASSEMBLY
386A7049P0001	HTVAS vibration sensor
386A7054P0001	BATTERY CHARGER, 24VDC, 150 AMP, 230
386A7061P0001	CABLE, BLEED VALVE
386A7063P0001	CABLE, CHIP DETECTOR
386A7082P0001	POWER SUPPLY; MARK VI
386A7135P0001	Valve
386A7270P0001	Meter, Flow
386A7314P0001	Bolt
386A7315P0001	Washer
386A7361P0001	Pump, LMO
388A1370P0006	Module, Netcon Field Term.
388A1858P0001	Power Supply
388A1858P0006	P.S. QUNT4-PS/12-24DC/24DC/1.3/SC
388A1931P0001	Controller, Servo Position
388A2976P0092	CABLE, ANALOG9P2C
388A2977P0042	CABLE, ANALOG9P4C
388A2978P0076	CABLE, ANALOG9P6C
388A2979P0062	CABLE, ANALOG9P8C
388A2980P0102	CABLE, TC9P8C-102IN
388A2981P0132	CABLE, CI25P12C-132IN
388A2982P0064	CABLE, ANALOG25P18C-64IN
388A2983P0068	CABLE, TC25P20C
388A2984P0120	CABLE, CI25P24C-120IN
388A2985P0122	CABLE, TC37P24C-122IN
388A2987P0068	CABLE, ANALOG37P32C-68IN
388A2989P0048	CABLE, CI37P36C-48IN
388A2989P0084	CABLE, CI37P36C-84IN
388A2997P0156	CABLE, RELAY5P5C
388A2998P0108	CABLE, RELAY15P10C
389A4294P001	Gas Valve

## Starfish PPS - Complete Catalog

Part Number	Description
389A4294P301	Gas Valve
389A4510P0001	Board, PC, 505, 500OHM
389A4512P0001	SENSOR, GAS
389A4521P0001	Flame Sensor
389A4531P0001	CABLE, TC, DUAL, T3
389A4639P0001	PLATE, LOCKING, SET OF 20
389A4640P0001	GASKET, HEAT EXCHANGER
389A4658P0001	SEAL, WASHER
389A4827P0001	Stator Gasket Set
389A4853P0001	COMPOUND, LOCKING
389A4911P0001	HEATER, EXCITER, SET OF 3
389A5116P0001	KIT, FUSE, SET OF 5
389A5117P0001	GASKET, SET OF 2
389A5222P0001	ASSEMBLY, LOUVRE
389A5224P0001	FILTER, AIR, SET OF 2
389A5345P0001	GASKET, SET OF 2
389A5386P0001	FUSE, 80000 AMP
389A5447P0001	TRANSMITTER, PRESSURE
389A5449P0001	TRANSMITTER, LEVEL, GUIDE WAVE RADAR
389A5453P0001	Detector, gas
389A5471P0001	Heater
389A6592P001	Combustion Sensor
38R277	CGI Gasket, 2 1/2", 150#, 304SS
38R289	CGI Gasket, 3", 600#, 304SS
390A0081P0001	FITTING, FEED THROUGH ELECTRICAL
390A0086P0001	ADAPTER WIRELESS AP
390A0112P0002	VALVE, CONTROL
390A0117P0001	Filter Element
390A0185P001	Valve, Ball
390A0206	IP CAMERA
390A0206P0001	IP CAMERA
390A0211P0001	VALVE
390A0250P0001	Valve, Control
390A0415P0001	FLOW METER
390A0499P0001	VALVE, FUEL
390A0754P0001	DVP, 24VDC, IP30, TB Input
390A0756P0001	Cable, Electrical, GSOV
390A0826P0001	HORN
390A0885P0001	GASKET, SPIRAL WOUND
390A1043P0001	AEROSOL GENERATOR
390A1088P0001	FUSE
390A1214P0001	Flow Meter and transmitter
390A1251P0001	TRANSMITTER
390A1396P0001	Connector
390A1403P0001	LINKNET-HT
390A1404P0001	LINKNET-HT
390A1405P0001	LINKNET-HT
390A1406P0001	LINKNET-HT
390A1407P0001	LINKNET-HT
390A1408P0001	LINKNET-HT
390A1425P0001	Cable, Electrical, Resolver
390A1425P0002	Cable, Electrical, Resolver

Starfish PPS - Complete Catalog

Part Number	Description
390A1426P0001	CABLE, ELECTRICAL, POWER
390A1427P0001	Cable, Electrical, Resolver
390A1427P0002	Cable, Electrical, Resolver
390A1442P0001	Transformer
390A1448P0001	DETECTOR
390A1460P0001	SENSOR, TEMPERATURE
390A1528P0001	FLOW METER
390A1530P0001	FLOW CONVERTER
390A1532P0001	U-BOLT, 1/2-13NC, 4IN
390A1649P0001	Adapter
390A1652P0001	Coupling, Start System
390A1773P0001	Transmitter, pressure
390A1783P0001	Transmitter, pressure
390A1784P0001	TRANSMITTER, PRESSURE
390A1826P0001	NOx Water Pump+Motor Assembly, VFD (Overhauled)
390A1832P0001	VALVE, SOLENOID
390A1837P0001	Pre Amp
390A1891P0004	FLOW METER
390A1902P0001	E-MATCH DEVICE
390A1903P0001	CABLE GLANDS 1/2 NPT, ATEX.
390A1915P0001	SENSOR, TEMPERATURE
390A1925P0001	CABLE, VSV
390A1933P0001	AEROSOL SIGNS
390A1937P0001	Transmitter, Level
390A2022P0001	BLOWER
390A2026P0001	FLOW METER
390A2046P0001	Transmitter, Level
390A2089P0001	Transmitter, pressure
390A2096P0001	Filter, final
390A2102P0001	RTD, Dual
390A2115P0001	TRANSMITTER
390A2116P0001	VALVE, BALL, 2 INCH
390A2117P0001	VALVE, BALL, 2 INCH
390A2120P0001	VALVE
390A2121P0001	Valve, Gas Shutoff
390A2122P0001	Valve, External Gas Fuel Vent
390A2228P0001	VALVE, SOLENOID
390A2262P0001	ELEMENT TEMP, FTD PLATINUM
390A2284P0001	SWITCH, CONVERTER, ETHERNET TO FIBER
390A2319P0001	NUT, ZINC PLATED
390A2323P0001	Pump, H2O Injection Assembly
390A2357P0001	SENSOR
390A2365P0001	Pump
390A2365P0002	Generator DC Lube Oil Pump Assembly
390A2372P0001	BOLT, HEX
390A2434P0001	GAUGE VALVE
390A2438P0001	VALVE, FLOW CONTROL, ASSY
390A2451P0001	VALVE, BALL., 1 1/2IN
390A2451P0001-R0001	VALVE, BALL, 1 1/2 INCH 150 LB RF, S

## Starfish PPS - Complete Catalog

Part Number	Description
390A2478P0001	DETECTOR
390A2509P000	CABLE, 2 PAIRS SHIELDED
390A2567P0001	CABLE, 2 PAIRS, SHIELDED
390A2568P0001	CABLE, 1 PAIR, SHIELDED
390A2569P0001	CABLE, SHIELD, 2C/2.5MM, 600/1000V
390A2570P0001	CABLE, SHIELD, 3C/2.5 MM, 600/1000V
390A2581P0001	Calibration Gas Kit
390A2742P0001	Valve, Check
390A2757P0001	TRANSMITTER
390A2770P0001	Drain Valve
390A2771P0001	Valve, Shutoff
390A2986P0001	PUMP, STARTER
390A3018P0001	Filter
390A3020P0001	Element, Temp
390A3022P0001	RTD Sensor
390A3030P0001	ASSEMBLY: FLOW TRANSMITTER & CONVERTER
390A3083P0001	CABLE, 3 FT
390A3095P0001	VALVE, CHECK
390A3117P0001	Detector, Level
390A3130P0001	Valve, Solenoid
390A3135P0001	Valve, Solenoid
390A3139P0001	VALVE, CHECK
390A3140P0001	Turbine Enclosure Fan - Direct Drive
390A3140P0001-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED
390A3140P0001-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
390A3185P0001	Conduit
390A3192P0001	PRESSURE TRANSMITTER
390A3311P0001	Filter
390A3330P0001	DISPLAY, DCU
390A3347P0001	Element, Temp
390A3383P0001	MODULE, EDIO
390A3384P0001	MODULE, EDIO
390A3392P0001	Horn
390A3393P0001	CO2, MANUAL PULL
390A3394P0001	CO2 MANUAL PULL
390A3396P0001	Coupling
390A3400P0001	Pump, Jacking oil
390A3400P0002	Pump, Jacking oil
390A3459P0001	ASSEMBLY: DETECTOR, GAS
390A3505P0001	Switch
390A3536P0001	VALVE, RELIEF
390A3543P0001	SWITCH, ETHERNET
390A3559P0001	CABLE
390A3581P0001	Level Transmitter
390A3665P0001	BOOSTER, PNEUMATIC. GENERATOR TRAIL
390A3705P0001	HORN ACK KEYSWITCH
390A3707P0001	EMERGENCY KEYSWITCH
390A3742P0001	TRANSMITTER, PRESSURE
390A3771P0001	GLO FILTER
390A3776P0001	INVERTER, DC-AC
390A3786P0001	GLO Filter Assembly

Starfish PPS - Complete Catalog

Part Number	Description
390A3786P0001-ELEMENT	Filter Element
390A3791P0001	FIREWALL 3000
390A3793P0002	HIGH-DENSITY MEDIA CONV
390A3801P0001	INVERTER, DC-AC
390A3808P0001	KIT, POWER CABLE
390A3958P0001	Breaker
390A3973P0001	Heater
390A4087P0001	TRANSMITTER, FLOW
390A4088P0001	Flow meter
390A4229P0001	MOTOR, 7.5 HP
390A4269P0001	RELAY, SYNC
390A4349P0001	CONVERTER, ANALOG
390A4351P0001	POWER SUPPLY, 24V DC, 5A
390A4361P0001	Pump, H2O Injection Assembly
390A4361P0002	Pump, H2O Injection Assembly
390A4362P0001	AMPLIFIER, PRESSURE, BENTLY NEVADA
390A4366P0001	Fan Assembly, Turbine
390A4389P0001	CABLE GLAND, 1/2", NPT ENTRY THREAD
390A4404P0001	Motor
390A4413P0001	Regulator
390A4415P0002	Regulator
390A4416P0001	Water Injection Pump Relief Valve
390A4429P0002	Regulator, Press
390A4517P0001	Motor
390A4518P0001	Motor
390A4545P0001	TEST MATCH
390A4768P0001	CABLE, 16AWG, NICKEL PLATED COPPER TRIAD
390A4918P0001	Fan, Generator
390A4963P0001	Expansion Joint
390A4990P0001	SUPPLY,POWER,24VDC,20A,24VDC
390A4991P0001	DIODE
390A4997P0001	BRIDGE,FIXED,TB
390A5291P0001	EXTERNAL GAS FUEL SHUTOFF AND VENT VALVE
390A5390P0001	Heater
390A5552P0001	NETWORK ADAPTER
390A5553P0001	Module, RSTi-EP Digital Input, 16 Points, Positive Logic, 24VDC, RSTi-EP 1
390A5559P0001	Module
390A5560P0001	Module
390A5561P0001	Module
390A5564P0001	Module
390A5565P0001	Filter, Element
390A5684P0001	Liquid Fuel Heater
390A5698P0001	Level Gauge
390A5701P0001	FILTER, GLASS FIBER, ANDRITZ A03 GENERATOR, LEVEL 1, FINAL FILTER SET
390A5709P0001	Cable, Power
390A5750P0001	Module
390A5751P0001	Module
390A5752P0001	Module
390A5772P0001	Module
390A5808P0002	Pump

Starfish PPS - Complete Catalog

Part Number	Description
390A5889P0001	Transmitter, Level
390A5967P0001	Heater
390A6076P0001	Solenoid Valve, Sprint, Supply, LM6000
390A6076P0003	Solenoid Valve, Sprint, Vacuum, LM6000
390A6077P0003	Solenoid Valve, Sprint, Drain, LM6000
390A6183P0001	Connection, Cross
390A6221P0002	Fan Assembly
390A6232P0001	Turbine Lube Oil Tank Demister Assembly
390A6248P0001	Bolt, Diffuser
390A6249P0001	Nut; diffuser
390A6355P0001	TRANSMITTER, PRESSURE
390A6356P0001	TRANSMITTER, PRESSURE
390A6357P0001	TRANSMITTER, PRESSURE, PS3
390A6360P0001	TRANSMITTER, PRESSURE
390A6394P0001	Clutch, Over-Running
390A6455P0001	ASSEMBLY: FILTER, TURBINE LUBE OIL
390A6455P0001-ELEMENT	Filter Element
390A6522P0001	Diffuser Rope Seal
392851-INFB490S1	Fan Funnel
392851-WHEEL	WHEEL TSL 490
392A5229P0001	FILTER
393A1237P0001	TRANSMITTER
393A1281P0001	Transmitter, pressure
393A1305P0001	Trap, Drain
393A1321P0001	16-Slot Rack
393A1329P0001	Transmitter, pressure
393A1365P0001	Level Gauge
393A1367P0001	PUMP, GLO
393A1422P0001	BARRIER, CONTROLLER
393A1539P0001	NUT
393A1711P0001	FILTER, ELEMENT
393A1716P0001	FUSE-LINK, 32A 500V
393A1809P0002	RTD, Thermowell, Clutch
393A1898P0001	HEATER, IMMERSION
393A1929P0001	14" FLOW METER
393A1945P0001	Woodward valve
393A1945P0001-AR	Woodward valve
393A1960P0001	TRANSMITTER
393A1986P0001	ETHERNET RING SWITCH, 4-10/100
393A1996P0001	HEATER, IMMERSION, 2.5", NPT SS, 2
393A2032P0001	Switch, Ring, Ethernet
393A2033P0002	SIXNET SWITCH, ETHERNET
393A2058P0001	BUSHING, HEX, REDUCING 1/2 MNPT X 3
393A2077P0001	Accelerometer
393A2078P0001	Accelerometer
393A2079P0001	Accelerometer
393A2080P0001	Accelerometer
393A2081P0001	Accelerometer

Starfish PPS - Complete Catalog

Part Number	Description
393A2082P0001	Accelerometer
393A3019P0001	Element, Temp
393A3340P0001	Regualtor
393A3341P0001	Regualtor
393A3347P0001	TRANSMITTER
393A3386P0001	SCREW, SELF TAP, SS, 1/4 - 20 X 1"
393A3396P0001	VALVE, SOLENOID
393A3415P0001	Pump, Cooling Water
393A3446P0001	TRANSMITTER, LEVEL
393A3553P0001	EMERGENCY STOP
393A3609P0001	GSOV HT
393A3611P0001	Valve, solenoid
393A3611P0001-OH	Valve, solenoid
393A3643P0001	DETECTOR
393A3645P0002	Heater
393A3663P0001	Gasket
393A3678P0001	MOTOR, 20hp, ELECTRIC
393A3699P0001	CABLE, IGNITION TRANSFORMER
393A3704P0001	Transformer
393A3776P0001	NOZZLE, WATER WASH
393A3794P0001	KIT, CUSTOMER TERMINAL BLOCKS
393A3837P0001	DRIVER, DVP
393A3865P0001	Cable, Fuel Valve Feedback
393A3866P0001	Cable, DVP Feedback
393A3890P0001	GASKET, SPIRAL WOUND
393A3951P0001	Sensor, Temp
393A4027P0001	Transmitter, pressure
393A4066P0001	RTD
393A4067P0001	JOINT, EXPANSION
393A4069P0001	RTD
393A4117P0001	Regulator, Water Inj
393A4135P0001	VALVE, BUTTERFLY, 24 INCH
393A4268P0001	Pump assembly
393A4805P0001	Regulator
393A4908P0001	TRANSMITTER, PRESSURE
393A5044P0001	Pump, Starter
393A5044P0001-OH	Pump, Starter, Overhauled
393A5081P001	SLO A/O Separator Part Kit for LMS100 SB 105
393A5082P001	MLO A/O Separator Part Kit for LMS100 SB 105
393A5124P0001	VALVE, BALL, 1-1/2, 600 LB
393A5208P0001	Valve, 3 way
393A5385P0001	PROXIMITOR 3300XL
393A5417P0001	Alarm Module (Horn & Strobe Driver) PSW
393A5459P0001	SENSOR, FLAME
393A5534P0001	Bracket, Foot
393A5565P0001	QUAD BOX
393A5614P0001	VALVE, BLOCK, 2-WAY, COAX
393A5647P0001	Element, Vibration
393A5648P0001	Element, Vibration
393A5737P0001	GASKET, LOUVER
393A8832P0330	Filter
395040	Nut-S-L, Double Hex Opt. (IC)

Starfish PPS - Complete Catalog

Part Number	Description
39708466	FILTER
397A1119P0001	VALVE, LSOV
397A1120P001	Transmitter
397A1141P0001	TRANSMITTER, PRESSURE
397A1144P0001	Transmitter, pressure
397A1151P0001	Transmitter, pressure
397A1158P0001	Pressure Transmitter
398000	Hose, Assembly, Kit
398000-50.5	Hose Assembly, Size - 1-1/2", Length - 50.5", Connection Type
398001	Hose, Assembly, Kit, Heat Exchanger, RH
398001-50.5	Hose Assembly, Size - 2", Length - 50.5", Connection Type
398002	Hose, Assembly, Water Wash Kit
398003	Hose, Assembly, Kit, Interconnect 3
398003-69	Hose Assembly, Size - 1-1/2", Length - 69", Connection Type
398004	Hose, Assembly, Kit, Interconnect 5
398004-72	1IN X 72IN OVER ALL LENGTH, 1IN STRAIGHT CODE 61 W/ 37 DEG JIC FEMALE SWIVEL (FC195-16), TP (SUPPLY WITH FF687-16 Flange Kit 1IN SAE Code 61 W/ aeroquip)
398005	Hose, Assembly, Kit, RH, Main Skid, Interconnect 78
398005-69	HOSE
398006	Hose, Assembly, Kit, Interconnect 2
398006-81	HOSE
398007	Hose, Assembly, Kit, Aux Skid
398007-56	Hose Assembly, Size - 1-1/2", Length - 56", Connection Type
398008	Hose, Assembly, Kit
398008-56	Hose Assembly, Size - 2", Length - 56", Connection Type -
398010	HOSE
398010-56	Hose Assembly, Size - 1", Length - 56", Connection Type -
398011	Hose, Assembly, Hydraulic
398012	HOSE
398013	HOSE
398014	HOSE ASSEMBLY, Turbine Hydraulic
398015	Hose, Assembly, Starter Case Drain
398017	Hose, Assembly
398018	Hose, Assembly
398019	Hose, Assembly
398020	Hose, Assembly
398021	Hose, Assembly, Oil Scavenge
398022	Hose, Assembly
398024	Hose, Assembly, Exhaust Collector Drain
398025	Hose, Assembly
398026	Hose
398027	Hose, Assembly, Hydro Start Return Main Skid
398027P0001	Hose, Assembly, Hydro Start Return Main Skid
398028	Hose, Assembly, Starter, Supply
398029	Hose, Assembly
398030	HOSE ASSEMBLY, LIQUID FUEL VALVE
398031	Hose, Primary Header
398032	Hose, Secondary Header
398037	Hose, Assembly, Oil Cooling
398038	Hose, Suction Jacking
398039	HOSE, JACKING PUMP DISCHARGE

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
398041	Hose, Assembly, GLO, Relief
398041P0001	Hose, Assembly, GLO, Relief
398045	Hose, Assembly
398046	Hose, Assembly
398048	Hose, Cooler to Tank
398049	Hose, Assembly
398050	Hose, Assembly, Hydraulic Start Return
398057	Hose, Assembly, Hydraulic
398058	Hose, Assembly
398070	Hose, Assembly
398071	Hose, Assembly
398074	HOSE, GLO SUPPLY TO GEARBOX
398078	HOSE, RUNDOWN TANK TO GEARBOX
398084	Hose, Water Inject Pump Discharge
398085	Hose
398086	Hose, Assembly
398090	Hose, Aux Skid
398091	Hose, Aux Skid
398092	HOSE, RETURN FILTER OUTLET
398093	Hose, Aux Skid
398094	Hose, Aux Skid
398095	Hose, Assembly
398096	Hose, Aux Skid
398097	Hose, Aux Skid
398098	Hose, Aux Skid
398099	Hose, Aux Skid
398100	Hose, Aux Skid
398101	Hose, Aux Skid
398102	Hose, Aux Skid
398103	Hose, Aux Skid
398104	Hose, Aux Skid
398105	Hose, Aux Skid
398106	Hose, Aux Skid
398107	Hose
398108	Hose, Aux Skid
398109	Hose, Aux Skid
398110	HOSE
398111	HOSE
398113	Hose, Assembly
398114	Hose, Assembly, Hydraulic
398115	Hose, Assembly, GLO Suction
398116	Hose, Assembly, GLO Discharge
398117	HOSE
398131	Hose, Assembly
398134	Hose, Assembly
398135	HOSE, HYD STRT, RETURN FILTER OUTLET
398150	Hose, 3/8
398151	Hose, TLO
398158	Hose, Assembly
398161	Hose; F1 Main fuel supply
398167	Hose, Gen Pump Discharge
398168	HOSE, GENERATOR RUNDOWN TANK

Starfish PPS - Complete Catalog

Part Number	Description
398171	HOSE, HYDRAULIC START
398208	
	HOSE, ENGINE CONNECTION D5
398208P0001	
	HOSE, ENGINE CONNECTION D5
398209	Hose, Assembly
398210	Hose, Assembly
398255	Kit, Door Seal Replacement
398A2029P0001	GASKET, EXCITER, SET OF 2
398A2058P0001	VALVE, EGMV, 3"
398A2059P0001	Valve, Fuel, Metering
398A2060P0002	VALVE, EWMV UNPLATED, 2"
398A2078G0001	Kit, Lubrication, Actuation, Woodward, Linear, LMS100
398A2119P0001	QUAD-BOX, TERMINAL
398A2145P0001	FILTER, ELEMENT
398A2224P0001	Switch, Vibration
398A2443P0001	Indicator, Moisture
398A2530P0001	Discharge Pressure Switch
398A2537P0001	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
398A2617P0001	Gen Lube Pump
398A2651P0001	Woodward GS6 valve
398A2651P0001-OH	Woodward GS6 valve
398A2674P0001	BARRIER, CONTROLLER
398A2715P0001	Switch, Float
398A2727P0001	Borescope, Kit
398A2749P0001	TRANSMITTER, PRESSURE
398A2753P0001	Servo, LPC-IGV
398A2753P0001F	KIT: FILTER, SERVO, LPC-IGV
398A2821P0001	Valve, Relief
398A2893P0001	Woodward GS6 valve
398A3394P0001	CO2 MANUAL PULL
398A3585P0003	Air / Oil Separator
398A4365P0001	TRANSMITTER
398A4411P0002	UR319 SUCTION FILTER
398A4411P0002-ELEMENT	Filter Element
398A4497P0001	Fan, Turbine Enclosure
398A4497P0001-OH	Fan, Turbine Enclosure
398A4497P0002	Fan, Turbine Enclosure
398A4537P0001	Hydraulic Filter Element
398A4555P0001	VALVE, HIGH PRESSURE
398A4569P0002	HEAT EXCHANGER, COOLING
398A4575P0001	BOLT, HEX, 3/8 - 16NC X 4 1/2, 316SS
398A4662P0001	AC
398A4664P0001	AC, Panel
398A4664P0002	AC, Panel

## Starfish PPS - Complete Catalog

Part Number	Description
398A4665P0001	AC, CABINET
398A4665P0002	AC, CABINET
398A4665P0003R01	AC, 8000 BTU
398A4665P0003R02	AC, 6000 BTU
398A4667P0001	Switch, Ethernet, 8 Port
398A4705P0001	Valve, Globe
398A4800P0001	Discharge Pressure Switch
398A4871P0002	Valve, Bleed Air Control
398A4891P0001	Fin Fan Xchanger
398A4950P0001	Valve, butterfly
398A5066P0001	METER, SYNCHROSCOPE, 50/60HZ
398A5093P0001	SENSOR, TEMPERATURE
398A5099P0001	Woodward GS6 valve
398A5099P0001-OH	Overhauled Woodward GS6 valve
398A5136P0001	LINKNET-HT, MODULE
398A5137P0001	LINKNET-HT
398A5138P0001	LINKNET-HT
398A5139P0001	LINKNET-HT
398A5140P0001	Valve, Relief, ball full port
398A5155P0001	LINKNET-HT
398A5198P0001	Cooler, turbine oil, Assy
398A5199P0001	HEATER
398A5222P0001	VALVE
398A5226P0001	GASKET, SPIRAL WOUND
398A5234P0001	GASKET, SPIRAL WOUND
398A5278P0002	FAN, CENTRIFUGAL, SINGLE INLET, Blower
399A1038P0001	Manual Pull
399A1039P0001	Manual Release Station
399A1278P0001	CABLE, 16AWG
399A1278P0002	CABLE, 16 AWG
399A1278P0003	CABLE
399A1278P0007	CABLE, 12 AWG
399A1278P0008	CABLE
399A1278P0009	CABLE
399A1278P0010	CABLE, 22 AWG
399A1278P0011	CABLE
399A1278P0012	CABLE, 10 AWG
399A1281P0001	PUMP, GOULDS
399A1282P0001	Pump Assembly
399A1284MTR	PUMP, GOULDS
399A1440P0001	LQ25T
399A1495P0001	REPEATER, HART
399A1507P0001	ETHERNET MODULE, 10/100MBITS
399A1507Pus0001	
399A1521P0001	ADAPTER, COUPLING, HALF, 1 1/4 IN FN
399A1524P0001	Pump, Water
399A1535P0001	TRANSMITTER
399A1538P0001	NUT, 6 PT, SILVER PLATED
399A1560P0001	Pump, Lube, DC
399A1583P0001	VERSAMAX PROFINET SCANNER
399A1638P0001	WIRE, 16 AWG, 2 PAIR, SHIELD CABLE
399A1759P0001	ISOLATOR REPEATER

## Starfish PPS - Complete Catalog

Part Number	Description
399A1781P0001	CO2 Discharge Switch Station
399A1800P0001	MOTOR, 15 Hp
399A1858P0001	NOx Water Pump+Motor Assembly, VFD (Overhauled)
399A1908P0001	ELEMENT, TEMP
399A1928P0001	VALVE, DRAIN
399A1959P0001	Probe, Regulator
399A2108P0001	Clamp, Coupling
399A2206P0001	Ethernet ring switch
399A2235P0001	Pump assembly
399A2309P0001	METER, FLOW
399A2321P0001	VALVE, SOL, LIQUID FUEL DRAIN
399A2321P0002	VALVE, SOLENOID
399A2361P0001	TRANSMITTER
399A2418P0003	TRANSMITTER, TEMPERATURE
399A2433P0005	3 HP Direct Current Motor
399A2446P0001	Clamp, tube
399A2476P0001	Valve, pressure relief
399A2546P0001	Pump Assembly
399A2591P0001	Thermo Valve
399A2591P0001-KIT	Repair Kit
399A2605P0001	ASSEMBLY: GAS DETECTOR, 505, METRIC
399A2614P0001	PUMP
399A2689P0001	Valve, Fuel
399A2700P0002	VALVE, ANTI-ICE
399A2704P001	PUMP, WATER
399A2787P0001	VALVE, CHECK
399A2808P0001	PULL BOX, 4-1/2 IN
399A2814P0001	PUMP, SPRINT
399A2817P0001	Pump Motor Assembly
399A2838P0001	Valve, Globe
399A2857P0001	VALVE CHECK, BALL 1/4
399A2881P0001	BOX, CONDUIT, EABX
399A2955P0001	STRAIGHT SWIVEL HOSE FITTING, 1/2NPT
399A2957P0001	STRAIGHT SWIVEL HOSE FITTING, 1NPT
399A2967P0001	VALVE, CHECK
399A2974P000	RELAY, GENERATOR PROTECTION
399A2994P0001	Level Gauge
399A2J00106967P0001	VALVE, CHECK
399A3042P0001	Element, Filter, MLO
399A3063P0001	CABLE, TEMP, HYD STARTER CLUTCH OIL
399A3069P0001	CABLE, HYD STARTER CLUTCH OIL
399A3093P1	VALVE
399A3106P0001	Pump/Motor Assembly
399A3115P0001	GASKET, SPIRAL WOUND
399A3121P0001	Filter Element
399A3134P0001	CO2 Discharge Switch Station
399A3180P0001	
399A3225P0001	Filter
399A3293P0001	Fan
399A3320P0001	Driver, Woodward
399A3466P0001	Valve, Fuel
399A3511P0001	DETECTOR, GAS TRANSMITTER

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
399A3567P0001	LAMP, INDICATING
399A3568P0001	LAMP, MINIATURE
399A3609P0001	SET, BALANCED FASTENER
399A3815P0001	Filter, inlet
399A3816P0001	Filter, inlet
399A3873P0001	PCA Base, I/O
399A3909P0001	Pressure switch, carrier
399A3910P0001	Surge Suppressor RJ45
399A3913P0001	Filter
399A4301P0001	Positioner, Valve
399A4340P0001	Propeller, Gen Fan
399A4395P0001	Filter, Inlet Air
399A4663P0007	UNION, ALUMINUM, 1/2"
399A4729P0001	Filter, inlet
3BA1830-7AT16	Regenerative Blower
3EA-AD25999-01	CELL, CONDUCTIVITY
3M764	TAPE, VINYL
3R1500050M	NH3 (Ammonia) Sensor
3R1600050M	CO Sensor
3RB2026-1QB0	RELAY
3RB2036-1UB0	RELAY, OVERLOAD
3RG4011-0AB00	Inductive Sensor
3RH1921-1EA11	CONTACT, AUXILIARY
3RT1036-1BG40	CONTACTOR, MAGNETIC
3RV1021-4BA10	BREAKER, CIRCUIT
3RV1031-4FA10	BREAKER, CIRCUIT
3RV1031-4GA10	BREAKER, CIRCUIT
3SB30010AA21	ASSEMBLY: LAMP HOLDER, RED
3SB30010AA41	ASSEMBLY: LAMP HOLDER, GREEN
3SV9NA30DX	Pump Assembly
3SVDK10-GE	Sprint Pump
3VL4731-2DK36-0AB1	BREAKER, CIRCUIT
3VL47402AA360AA0	Circuit Breaker
3VX1320	GATES SUPER HC POWERBAND BELT
4-036-15-315-001	Bonnet
4-4CBTX-SS	90 DEGREE FITTING
4-F09152-S27	Mounting Kit
4/3VX1320	Belt, 4 wide
40-00901A1-01	DP Indicator Plug
40-01165-01	Differential Pressure Gauge
40113-02	CONNECTOR PROTECTOR KIT - 8mm
4012-00-0101-02-06	GASKET, RING
4012-00-0101-02-08	GASKET, RING
4012-12-1014-04	GASKET
4013-00-0101-01-06	GASKET, RING
4013-00-0101-01-08	GASKET, RING
4013-12-1014-01	GASKET
4018-00-0005-00-08	O-RING
4018-00-0011-00-06	O-RING, BUNA
4018-00-0011-00-08	O-RING
4025088	Drain Valve
4036J25P001	Stem

Starfish PPS - Complete Catalog

Part Number	Description
4058T39P01	Seal Ring
4058T39P02	Seal Ring
4058T39P04	Seal Ring
405TTFS16837AN W	MOTOR
408D694H6HEASAA	STARTER, COMBINATION ENCLOSED
410197591	IND HEX WASHER TYI E F SLOT
41095	PUMP
413193-001	Shaft, Coupling LM2500
4151-1460	O-RING
41535-4	SEAL
416055325	PIN
416B605P4	NUT
416G-20VN	Filter Element
41C632667G1	HOLDER, BRUSH
420666E	Sprint Valve
4211C69004	SCREW
423915F	Flow Transmitter, Burkert
424/1.32.0.0.S5	VALVE, SOLENOID
42694-8001	Valve Overhaul Kit
427A3863P0901	
	OBS:
	VLAN Switch, AT8624, EDGE Configuration
427A8353G0003	Switch Assembly
42B Motor Base Plate	Fan Motor Mount
42B725 COVER PLATE	PLATE, COVER, FOR 42B725
42B725-FBG-SS	Fan Belt Guard
42B725-Motor	Motor, Electric, Gen Enclosure Fan
42B725-VABD	Fan, Generator
42B725-VABD-AR	Fan, Generator, As Removed
42B725-VABD-V	Fan, Generator
42D725-VJ-1762-100	Fan, Generator
4326GG-20VN	Filter Assembly
4326GG20VN	Filter Assembly
432B570P0001	Piston
433465-017	SET, BALANCED FASTENER
439309-502	Power Supply
43L38 20TU-2 20TU-3	Solenoid Valve
44203	Filters - Box of 12
4452-17	PUMP, LUBE AND SCAVENGE
4452-9	PUMP, LUBE AND SCAVENGE
447628	Coupling
448Z-6	Gauge, Immersion Depth, Igniter
44A724527-001	GE FANUC;BATTERY, Li
44B5964X012	CAGE, WHISPER
450-M-200	FILTER
450M200	FILTER
451279SS02BXNH10000#	Pressure Gauge, 0-10,000 PSI
451279SSL02BXNH600BR	Pressure Gauge, 0-600 bar
4524-3402	Transducer, Displacement
45358-09	CABLE, ACCELEROMETER
4550-400-S	Male Flange, V-Band, 4", SS
4560-400-S	Female Flange, V-Band, 4", SS
46143	Fiberoptic Cleaning Wipes

Starfish PPS - Complete Catalog

Part Number	Description
466624	Hose, Liquid Fuel
46770X272-BMF	6GPDFBB0N-AA BODY/ROTOR ASSEMBLY - NO ACTUA
46994	NUT, ZINC PLATED
47116	BOLT, HEX
473-527-227	Cable Assembly, RTD
473-527-228	Cable assembly, XN25
473-527-229	Cable assembly, EGT
473-527-230	Cable assembly, T2
473-527-231	Cable assembly, CDT
473-527-232	Cable Assembly, PT Speed
48-0089-001	FITTING, CONN,MALE,WITH STOP COLLAR
4850-005-M1067	Cable, Vibration Sensor
4850-010-M1067	Cable, Vibration Sensor
4900159-23	Diffuser Rope Seal
4900159-38	Diffuser Rope Seal
4900159-48	Diffuser Rope Seal
490AMX-1200	Turbine Enclosure Fan - Direct Drive
490AMX-1200-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED
490AMX-1200-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
490TSL	Fan, Turbine Enclosure
490TSL Direct Drive	Turbine Enclosure Fan - Direct Drive
490TSL Direct Drive-AR	Turbine Enclosure Fan - Direct Drive - AS REMOVED
490TSL Direct Drive-OH	Turbine Enclosure Fan - Direct Drive - OVERHAULED
490TSL SHAFT	U2 TURBINE EXH FAN SHAFT
490TSL-AR	Fan, Turbine Enclosure (As Removed)
490TSL-FBG-SS	Guard, Belt, TSL490
490TSL-OH	Fan, Turbine Enclosure, OVERHAULED
494610	Hose, Conn W6A
49TSL Motor	Motor, TCF Aerovent
49TSL Motor-OH	OVERHAULED Motor, TCF Aerovent
4BOCF14002D	VALVE, THERMOSTATIC
4HOSJ12001	4HOSJ THERM VALVE - 120F
4J6588	Mag Chip Detector
4J7316	Mag Chip Detector
5/5VX1030	BELT, GENERATOR EXHAUST FAN
5/5VX1060	Belt, 5 Row Banded
50-0045-008-210	Thermowell, integral housing
50-0049-011	Thermowell
50-PS-120-2430AC/24DC	Power Supply
500055	APPLETON 3/4" ALUMINUM ELBOW
500710605	Generator Lube Oil Tank Heater
500710606	Turbine lube oil Tank Heater and Thermostat
501239J43P0003	Thermocouple
501505-1	SENSOR, SPEED, DUAL
501644	Flange
501645	Flange
50239251	AMBIENT AIR THERMOSTAT EXM
5032M27P04	Strap
505353-1	HARNES, TC, UPPER

## Starfish PPS - Complete Catalog

Part Number	Description
505354-1	HARNESS, LOWER, T48
505A3A2A1W	Transmitter, combustable gas
505A3A2B1W	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
505A3C2B1W	TRANSMITTER, COMBUSTIBLE, W/ JUNCTION BOX
5069-IF8	CompactLogix 5069
506913-2	Sensor, Speed
506913-3	Sensor, Speed
506913-4	Sensor, Speed
50730	Socket
508FX2-A-SC	SWITCH, ETHERNET
509079-1	Lead, Extension
50960G04	Charging Motor ASSY
50CLFXS	NUT, SS
50CLFXZ	NUT, ZINC PLATED
50N150WFES	WASHER, FENDER, 1/2 X 1 1/2, S/S
5100-243	Snap Ring
5106AB A	REPEATER, HART
5106AB B	REPEATER, HART
5106AB2A	REPEATER, HART
5106BB2B	REPEATER, HART
510H0005P001	NUT, HEXAGONAL, 1/2 -13
5115005	MOTOR, STARTER
5132T-6MP-60	Valve, relief
51372	WASHER
51658	Tempering Air Fan Assembly
51658-SHIMPACK	Shim pack for 51658
516686	Hose, Starter
516698	HOSE, LIQUID FUEL F9
516C-1-25	VALVE, RELIEF
516C-1-50	VALVE, CHECK
51V110	MOTOR, STARTER
51V1101RF1N	MOTOR, STARTER
521251	Hose, L-2
521252	Hose, L-3
521253	Hose, L-5
521254	Hose, L-6
521255	Hose
521256	Hose, L-9
521257	HOSE, L10
521258	Hose, L-11
521259	Hose, D-1
521260	Hose, D-2
521261	Hose, D-4
521262	Hose, D-5
521263	Hose, D-6
521274	Hose, A-5
521275	Hose, A-9
521280	Hose, A-23
521281	Hose, A-24
521282	Hose, A-25
521284	Hose, P-3
521285	Hose, A-32

## Starfish PPS - Complete Catalog

Part Number	Description
521297	Hose, B-10
521298	Hose, B-11
521299	Hose, D-7
521362	Hose, D-8
521367	Hose, A-11, comp disch press (P3)
521368	Hose, A28
521645	HOSE, BALANCE PISTON PRESS VALIDATION
521647	HOSE ASSEMBLY, W2
52200024	O2 Probe Membrane Kit
52200899	QD ANODE/CATHODE, INPRO 6800
522219	Hose, B1/B2
522220	Hose, B-3
522288	Hose, W-3
522428	HOSE, TW1
522431	PIPE, TA4-P
522505	HOSE, B4
52312-521204095	Hilliard Duplex Filter Housing (takes 2 PH312-11-CG filters)
527-401	Tooling, ignitor depth gauge
527737	Gasket, Air/Oil
528603	Hose, Liquid Fuel
528604	Hose, Liquid Fuel
529287	KIT, DISK PACK, REXNORD NOX COUPLING
5299-1008	Accumulator - Piston
5299-1009	Accumulator- Piston
5301HA1S1E3AE00206RAKA	Detector, Level
5301HA1S1V3AE00109RAKAM1J1	Guided Wave Radar
5301HA1S1V3AE00203RAKAM1C1	TRANSMITTER, LEVEL
5301HA1S1V3AE00207RAKAC1R3016	TRANSMITTER
5301HA1S1V3AE00307RAKAM1	TRANSMITTER
5302001	PreFilter, 24"x24"x4", G4
5315	RTD Temp Sensor
5316-1	Sensor, T3
5317-2	THERMOCOUPLE, T48
531X111PSHAXG2	BOARD, TERMINAL
531X170TBSAGG1	Control
531X307LTBAKG1	BOARD, TERMINAL, LAN, EX2000
537L308	RTD, Detector, Resistance Immersion
537L317G06	KIT, TUBE, A/O
53932	Seal
53WK35004	Starter
53WK57017	Starter
5402-6	HeliCoil Professional Thread Repair Kit
5416-338	Cable, Woodward
5416-351	Cable, Woodward
5417-026-AR	CABLE, AS REMOVED
5417-027	CABLE, WOODWARD
5417-028	CABLE
5417-029	CABLE, WOODWARD
5417-031	Cable, Woodward
5417-037	CABLE, WOODWARD
5417-038	CABLE, WOODWARD
5417-038-AR	CABLE, AS REMOVED

## Starfish PPS - Complete Catalog

Part Number	Description
5417-039	CABLE, WOODWARD
5417-040	CABLE, WOODWARD
5417-040-AR	CABLE, AS REMOVED
5417-041	CABLE,NETCON LAYOUT LOW DENSITY DISCRETE,GR
5417-041-AR	CABLE, AS REMOVED
5417-042	CABLE, WOODWARD
5417-042-AR	CABLE, AS REMOVED
5417-044	Cable, Woodward
5417-045	CABLE ASSEMBLY, LOW DENS. ANALOG,12FT
5417-045-AR	CABLE, AS REMOVED
5417-1109	CABLE, WOODWARD
5417-1128	CABLE, WOODWARD
5417-117	CABLE, WOODWARD
5417-1281	CABLE, WOODWARD
5417-171	CABLE, WOODWARD
5417-172	CABLE, WOODWARD
5417-172-AR	CABLE, AS REMOVED
5417-173	Cable
5417-173-AR	CABLE, AS REMOVED
5417-174	CABLE, WOODWARD
5417-175	CABLE, WOODWARD
5417-175-AR	CABLE, AS REMOVED
5417-176	CABLE, WOODWARD
5417-177	CABLE-MICRONET HIGH DENSITY
5417-178	CABLE-MICRONET HIGH DENSITY
5417-217	CABLE, WOODWARD
5417-394	CABLE, WOODWARD
5437-281	Module - Analog Field Term
5437-419	MODULE, NETCON, 24 CHANNEL
5437-523	Module - Analog Field Term
5437-523-AR	MODULE, AS REMOVED
5437-524	MODULE - ANALOG FIELD TERMINAL
5437-525	WOODWARD, MODULE, ANALOG FIELD TERM (ACT)
5437-672	Module, Netcon Field Term.
5437-672-AR	MODULE, AS REMOVED
5437-687	Module, Netcon 24 Channel Field
5437-687-AR	MODULE, NETCON, AS REMOVED
5437-845	Notch Filter
5437-845-AR	FILTER, AS REMOVED
5439-629	505 Power Supply
5441-413	32 CHANNEL RELAY INTERFACE
5441-419	MODULE, RELAY, 16 CHANNEL
5441-693	MODULE, HD DISCRETE I/O
5441-693-AR	MODULE, AS REMOVED
5441-695	Module, Simplex FTM
5441-695-AR	MODULE, AS REMOVED
5441-695-OH	Module, Simplex FTM - OVERHAULED
5448-906	SYNCHRONIZING SYSTEM
5450-1094.40	Cable, Fuel Valve Feedback
5450-1095.40	Cable, DVP Feedback
5450-1096	CABLE, ASSEMBLY, DRIVER TO VALVE
5450-1096.20	Cable, Power

Starfish PPS - Complete Catalog

Part Number	Description
5450-1155	CABLE, ELECTRICAL, POWER
5450-1206	CABLE, ELECTRICAL, FEEDBACK
5453-278	Cabinet, Woodward, Micronet
5453-750	ETHERNET INTERFACE FTM
5453-754	INTERFACE, ETHERNET, FTM
5453-759	CHASSIS, MICRONET PLUS
5453-829	Cabinet, Woodward, Micronet
5461-644	Module Assembly - DCS II 4-20 Current Out
5461-650	T/C Input
5461-651	Board/Module
5461-975	Power Supply DCS 2 LV
5462-085	Final Driver Module
5462-117	Position Transducer
5462-268	Mother Board for 505
5462-446	Module - DCS II - DPS3/DT
5462-718	Speed Sensor
5462-750	Secondary Power Supply - 501
5462-757	28 Channel Discrete Input Module
5462-758	28 Channel Discrete Output Module
5463-034	Power Aux. N.C.
5463-473	SIO Module - VER4.4 OPSYS
5463-604	Woodward
5463-605	Woodward
5464-213	SIO
5464-213-AR	SIO, AS REMOVED
5464-333	ISOL T/C FH
5464-337	RTD Input Module
5464-338	200 ohm RTD
5464-338-AR	RTD, AS REMOVED
5464-340	CARD, RTD
5464-340-AR	RTD, AS REMOVED
5464-553	Woodward module
5464-554	2 Channel Actuator Driver
5464-555	Woodward Moduke
5464-555-AR	MODULE, AS REMOVED
5464-643	Woodward I/O
5464-643-AR	I/O MODULE, AS REMOVED
5464-644	Woodward module
5464-645	2 Channel Actuator Driver
5464-646	Woodward module
5464-646-AR	MODULE, AS REMOVED
5464-647	2 Channel Actuator Driver
5464-654	Module, D.O.64 Channel w/Watch
5464-654-AR	MODULE, AS REMOVED
5464-654-OH	Module, D.O.64 Channel w/Watch
5464-658	DIGITAL SPEED SENSOR
5464-658-AR	MODULE, AS REMOVED
5464-658-OH	MODULE, OVERHAULED
5464-660-AR	MODULE, AS REMOVED
5464-697	40 Mhz CPU
5464-780	Remote XCVR
5464-780-AR	XCVR, AS REMOVED

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
5464-834	MODULE, SPEED SENSOR
5466-031	MODULE
5466-031-AR	MODULE, AS REMOVED
5466-031-OH	MODULE, OVERHAULED
5466-045	MODULE, PRESSURE XDUCER INTERFACE
5466-045-AR	MODULE, PRESSURE, AS REMOVED
5466-1000	Power Supply, Micronet
5466-1000-AR	Power Supply, Micronet
5466-1001	Power Supply, Micronet
5466-1035	CPU, MICRONET
5466-1035-AR	CPU, MICRONET, AS REMOVED
5466-1035-OH	CPU, MICRONET, OVERHAULED
5466-1036	WOODWARD, MICRONET+
5466-1036-AR	MODULE, AS REMOVED
5466-1036-OH	MODULE, MICRONET, OVERHAULED
5466-1045	Module, Micronet plus CPU5200
5466-1046	Module, Micronet plus RTN
5466-1046-AR	MODULE, AS REMOVED
5466-1050	Discrete input Module 48 Channel
5466-1141	CPU
5466-1158	Simplex Discrete I/O Module
5466-1245	CPU
5466-1245-OH	CPU, overhauled
5466-1511	MODULE - MICRONET PLUS P1020 CPU
5466-258	MODULE, I/O
5466-258-AR	MODULE, AS REMOVED
5466-258-OH	MODULE, OVERHAULED
5466-315	Module, High Density Analog I/O
5466-315-AR	MODULE, AS REMOVED
5466-316	Module, Analog Combination
5466-316-AR	MODULE, AS REMOVED
5466-316-OH	Module, Analog Combination
5466-326	Module, Pressure Input
5466-328	Module, Netcon IIIB
5466-332	MODULE, I/O, ANALOG
5466-348	WARD SIO
5466-348-AR	MODULE, AS REMOVED
5466-353	Module, Main Transceiver
5466-355	Transceiver
5466-358	WARD SIO
5466-408-AR	MODULE, AS REMOVED
5466-409	Micronet CPU
5466-419	Module, Pentium 233 Mhz CPU
5466-425	Module, Micronet, Analog I/O
5466-425-AR	MODULE, AS REMOVED
5466-425-OH	MODULE, OVERHAULED
5466-5000	Module, speed
5466-5000-AR	MODULE, AS REMOVED
5466-5001	MODULE_CTRL, DIGITAL SPEED SENSOR MODULE (4I
5466-5027	Module, Micronet, Analog I/O
5466-654	Discrete Out
5466-654-AR	MODULE, AS REMOVED

Starfish PPS - Complete Catalog

Part Number	Description
5466-658	Digital Speed
5466-658-AR	MODULE, Digital Speed
546622	HOSE, BLEED AIR, 8TH STAGE
5485C-008	Sensor, Vibration
5485C-959	Sensor, Vibration
55-154607G041	Contact Kit
5500-159	505 Relay Board
5501-1432	Module, Actuator
5501-1432-AR	MODULE, AS REMOVED
5501-367	Module, Micronet Discrete FTM
5501-371	Module, Micronet Simplex MPU & AIO FTM
5501-371-AR	MODULE, MICRONET, AS REMOVED
5501-376	Module, Analog, High Density, Simplex
5501-432	Module, Actuator Netcon CONT.2C
5501-432-AR	MODULE, AS REMOVED
5501-437	Woodward
5501-465	Power Supply
5501-465-AR	POWER SUPPLY, AS REMOVED
5501-466	Woodward Micronet Simplex Power Supply
5503-279	Board, Micronet HDVIM
5503-279-AR	BOARD, AS REMOVED
5503-282	Module, FTM HDVIM
5503-282-AR	MODULE, AS REMOVED
5503-335	CPU, Motorola 5200, Micronet Plus
554636	HOSE, TLO
554637	Hose, TLO
554637P0001	Hose, TLO
554638	Hose Assembly
554644	Hose
554677	Hose, Primary Manifold Drain
554678	Hose, Exhaust Drain
554687	HOSE, PRIMARY FUEL SUPPLY
554688	Hose, 2nd Manifold Supply
554704321	GENERATOR L/O TANK HEATER
554729563	HEATER; TMSS-18315E2T2T36XX,400V/480V,21.5/31KW,1-3PH,15
5566-258	High Density D. I/O
5566-315	High Density A I/O
570008	HOSE, CDP PURGE CONNECTION
570392	HOSE, CDP PURGE CONNECTION 850
571-217-10	DIGIMATIC DEPTH GAUGE; 0-40"
571065	HOSE, ASSEMBLY, UNIVERSAL MANIFOLD
571219	Exciter
571328G0001	Fan, Turbine Enclosure
571486	HOSE,, HYD STARTE, MANIFOLD BLOCK TO PUMP DIS
571900	Hose, Hydraulic, Manifold
5747.2	ADAPTER, TERMINAL BLOCK
580-544-002F	Cable, VSV feedback
581-SS-40M	BASKET, MESH, Y-STRAINER
584623	HOSE, GLO MECHANICAL PUMP DISCHARGE
584627	HOSE, GLO SYSTEM
584628	HOSE, GLO SYSTEM

Starfish PPS - Complete Catalog

Part Number	Description
584630	HOSE, GLO
584683	Hose, Fuel, F1
584686	Hose, Liquid Fuel Supply
584716	HOSE
584717	HOSE, HYDRAULIC START SYS
584718	CHARGER PUMP OUTLET TO TANK
584719	HOSE, HYD STR COOLER SUPPLY
584720	HOSE, HYDRAULIC START SYS
584722	HOSE
585C1843P0001	RING, THREADED
586A2229P114	VALVE, FUEL GAS STOP RTIO S1-4
586A2268P001	Servo, LPC-IGV
593083	SOCKET, 7 WAY, SOLID PINS
59501-510028-1	SENSOR, SPEED
5BY556ZD817C800	Motor, 15.5 KW DC
5C2B-CC7	PUMP, GLO
5C2GV-CC	PUMP, GLO
5C81	Bracket, Foot
5K519	Seal Kit
5K6248XH3001A	Electric Motor, 60HP, 3PH, 230/460V
5KS143BAA205	Motor
5KS143SAA2067	Motor, Electric
5KS145SAA205	Electric Motor, 2HP, 4P, 145T, 230/460V, TEFC
5KS213RSP226	MOTOR, LUBE, GLO AC
5KS447SAA2085W	MOTOR
5R5V103	Motor Sheave
5R5V85	Fan Sheave
5SY6102-7	BREAKER, CIRCUIT, MINI
5SY6202-7	BREAKER, CIRCUIT, MINI
5VX1000	BELT, TURBINE ENCLOSURE
5VX1030	BELT
5VX1060	BELT
5VX1500	BELT, TURBINE ENCLOSURE
5VX570	BELT, FAN COOLER
5VX710	BELT, VENT/COMB FAN
5VX780	BELT, TURBINE ENCLOSURE
5VX830	BELT, FAN COOLER
6-6CBTX-SS	90° FITTING
6/5VX1250	Belt, 6 Bands
6/5VX1500	6 Band Belt
60200501	Heater, Strip
60662	Seal
607208-00	CABLE, ACCELEROMETER
607208-04	Cable
608214-03	CABLE, T2/T25 RTD
608214-04	CABLE, T2/T25 RTD
608214-4036	CABLE, T2/T25 RTD
608214-5036	CABLE, T2/T25 RTD
608219-02	CABLE, T3
608219-03	CABLE, TC, DUAL, T3
608219-04	CABLE, TC, DUAL

## Starfish PPS - Complete Catalog

Part Number	Description
608220-01	CABLE, T44
608919-03	CABLE, VBV/VS/LVDT, RIGHT SIDE
608919-04	CABLE, VBV/VS/LVDT, RIGHT SIDE
608919-4036	CABLE, VBV/VS/LVDT, RIGHT SIDE
608920-03	CABLE, VBV/VS/LVDT
608920-04	CABLE, VBV/VS/LVDT
608920-4036	CABLE, VBV/VS/LVDT
608920-5036	CABLE, VBV/VS/LVDT
608926-03	CABLE, IGV/LVDT, RIGHT
608926-04	CABLE, IGV/LVDT, RIGHT
608926-4036	CABLE, IGV/LVDT, RIGHT
608926-5036	CABLE, IGV/LVDT, RIGHT
608927-03	CABLE, IGV/LVDT/XN2, LEFT
608927-04	CABLE, IGV/LVDT/XN2, RIGHT
608927-4036	CABLE, IGV/LVDT/XN2, LEFT
608927-5036	CABLE, IGV/LVDT/XN2, RIGHT
608928-02	CABLE, VBV/VS/IGV
608928-03	CABLE, VBV/VS/IGV
608928-3036	CABLE, VBV/VS/IGV
608928-4036	CABLE, VBV/VS/IGV
608929-03	CABLE, MANIFOLD TEMPERATURE
608929-04	CABLE, MANIFOLD TEMPERATURE
608929-4036	CABLE, MANIFOLD TEMPERATURE
608929-5036	CABLE, MANIFOLD TEMPERATURE
608930-04	CABLE, CHIP DETECTOR, A/B
608930-4036	CABLE, CHIP DETECTOR, A/B
608930-5036	CABLE, CHIP DETECTOR, A/B
608931-02	CABLE, CHIP DETECTOR, C/D/E
608931-03	CABLE, CHIP DETECTOR, C/D/E
608931-3036	CABLE, CHIP DETECTOR, C/D/E
608931-4036	CABLE, CHIP DETECTOR, C/D/E
608932-01	CABLE, TEMP LUBE & SCAVENGE
608932-02	CABLE, TEMP LUBE & SCAVENGE
608932-03	CABLE, TEMP LUBE & SCAVENGE
608932-04	CABLE, TEMP LUBE & SCAVENGE
608932-4036	CABLE, TEMP LUBE & SCAVENGE
608933-02	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-03	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-04	CABLE, TEMP LUBE RTD, D&E SUMPS
608933-4036	CABLE, TEMP LUBE RTD, D&E SUMPS
608934-03	CABLE, XN25 SPEED
608934-04	CABLE, XN25 SPEED
608934-4036	CABLE, XN25 SPEED
608935-02	CABLE, XNSD SPEED
608935-03	CABLE, XNSD SPEED
608935-04	CABLE, XNSD SPEED
608935-3036	CABLE, XNSD SPEED
608935-4036	CABLE, XNSD SPEED
608935-5036	CABLE, XNSD SPEED
608937-02	CABLE, OFF-ENGINE, T/C, T48 - LOWER
608937-03	CABLE, OFF-ENGINE, T/C, T48 - LOWER
608937-04	CABLE, OFF-ENGINE, T/C, T48 - LOWER

## Starfish PPS - Complete Catalog

Part Number	Description
608937-3036	CABLE, OFF-ENGINE, T/C, T48 - LOWER
608937-4036	CABLE, OFF-ENGINE, T/C, T48 - LOWER
608938-02	CABLE, EGT THERMOCOUPLE, RIGHT
608938-03	CABLE, EGT THERMOCOUPLE, RIGHT
608938-04	CABLE, EGT THERMOCOUPLE, RIGHT
608938-3036	CABLE, EGT THERMOCOUPLE, RIGHT
608938-4036	CABLE, EGT THERMOCOUPLE, RIGHT
608938-5036	CABLE, EGT THERMOCOUPLE, RIGHT
608939-00	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
608940-00	CABLE, ELECTRICAL, IGV, LVDT, XM
608942-00	CABLE, TEMP, LIQUID MANIFOLD
608942-01	CABLE, TEMP, LIQUID MANIFOLD
608945-00	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
608946-00	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
608947-00	CABLE, SPEED, GAS GENERATOR
608947-01	CABLE, SPEED, GAS GENERATOR
608950-00	Cable, T48 Lower Thermocouple Harness
608951-00	Cable, T48 Upper Thermocouple Harness
608952-00	CABLE, ELECTRICAL, VBV/VSV/LVDT; RIGHT- ON ENGI
609500-00	CABLE
609508-00	CABLE
609527-00	CABLE, T4.4
609549-03	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-05	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-4036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-5036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609549-6036	CABLE, TEMP COMPRESSOR DISCHARGE, T3
609975-09	CABLE, CRF ACCELEROMETER
609975-12	CABLE, ACCELEROMETER
609975-40	CABLE, CRF ACCELEROMETER
609976-40	CABLE, TRF ACCELEROMETER
609976-4036	CABLE, TRF ACCELEROMETER
610146-00	CABLE, CHIP DETECTOR, A/B/COM
610147-00	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
610148-00	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT ON ENGINE
611388-00	Cable, T/C, 20ft
61218-UA-2100	HARNESS, ELECTRICAL
6133G4Y	Valve, Vent
6182FEM01-AKM0200	Bronze Safety Relief Valve
6182FEM01-KM0200	Bronze Safety Relief Valve
619E223P9	REDUCER
62102-1	SWITCH, LIMIT
62102-2	SWITCH, STRAIGHT, NORMALLY CLOSED
62105-3	Right Angle Bodied Switch
62105-5	Switch
62176	Coil, 24VDC
62185	Coil, 120VAC
621891750HHCSB16STUN	Bolt, 5/8-18 UNF-2A x 1-3/4", B16
62212-2	COIL, 24 VDC
62213-1	Coil, 115VAC
6221342000	Drain Valve

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
62215	Coil, 18VDC
62216-2	Coil, 24VDC
62216-8	Coil, 125VDC
6240M43	Accelerometer
6240M46	ACCELEROMETER, CRF
6240M49	Accelerometer
6240M51	Accelerometer
6240M52	Accelerometer, LM2500
6240M56	ACCELEROMETER, CRF
6240M57	ACCLRMTR
6240M58	TRF Accelerometer
6240M60	ACCELEROMETER, CRF
6333B1B	2-WIRE PROGRAMMABLE TRANSMITTER
634	Brush, Carbon
6353-1105-31680	Regulator, Assembly
6354-225	Clamp, Coupling
6354-400	Clamp
635E901P03	Nut
636D685G0002	Collector Assembly
638516	Shaft, Fan, Gen
638A433-001	BUSHING, OVERSPEED
6401-08-08-O-SS	FITTING, ADAPTER MORB/MNPT STRIAGHT
6405-20-12-O-SS	ADAPTER, 1 1/4IN MSAE
642-107700-110	TRANSDUCER, LINEAR
642GH498	Pressure Switch
644SAKADCJ6M4	Temperature Transmitter
646GEM1	SWITCH, PRESSURE, ADJUSTABLE
647928	Bearing Thrust Plate
64G5600-004	RELAY, 24VDC, DPDT, 20A
6500-16-16-SS	FITTING
6500-24-24SS	Adapter
650097-1	CABLE, IGNITER
655-EZ-1"	Exhaust Collector Drain Flow Control Valve
655R-EDR	Valve, Lube
655R-EDR-2	2" Valve
6601-01-015-D	Clutch
6601-01-019-C	Clutch
6601-01-071-D	Clutch
6601-01-071P1	Clutch
6601-01-071P3R4	Clutch
6601-01-074-0	Clutch
6601-01-074-0SP	Clutch
6601-01-089-D	Clutch
6601-01-090-D	Clutch
6601-01-098	Clutch / Starter Assembly
6601-01-099-0	Clutch
6601-01-099-0-AR	Clutch; AS REMOVED
6601-01-099-0-OH	CLUTCH
6601-01-103-D	Clutch, Overrunning
6601-01-109-0	Clutch
6601-01-109-0-AR	CLUTCH, AS REMOVED
6601-01-109-0-OH	CLUTCH, OVERHAULED

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
6601-01-113-0	Clutch
6601-01-146	Clutch
6601-01-152	Clutch (with RTD and speed Probe) with start motor (shell
6601-01-175	Clutch, Over-Running
6601-02-019-D	Clutch
6601-02-175	Clutch, Over-Running
6601-09-009	RTD, Thermowell, Clutch
6601-10-009	Gasket, Clutch to AGB
6601-10-010-B	Gasket, Clutch to Starter
6601-10-010B	Gasket, Clutch to Starter
6601-10-023	Gasket, Clutch to AGB
6601-10-10B	Gasket, Clutch to Starter
6601-3D-081-0	HYDRAULIC STARTER MOTOR
6601-3D-081-0SP	HYDRAULIC STARTER MOTOR
6601-3D-119	Dual Element RTD
6601-95-001	Plug, Orifice
6601-RTD-KIT-100	RTD Kit, Hilliard
6601-RTD-KIT-30	RTD Kit
6601-RTD-KIT-50	Dual Element RTD Kit, Hilliard
6601RTD030-CBL	CABLE, RTD
6601RTD040-CBL	CABLE, CLUTCH OIL DRAIN RTD
6601RTD050-CBL	CABLE, RTD
6601RTD060-CBL	Cable, Hydraulic Starter Clutch Oil
6601RTD120-CBL	CABLE, TEMP, HYD STARTER CLUTCH OIL
662395-200	Coupling, water inj
663A90-0049-2	E-SEAL, RING
6667621	Filter, Fuel
670-3/4x4	GASKET, WEATHERSTRIPPING
670A-1/8 X 1-1/2	Gasket/Weatherproofing Material
670A-1/8X15	Gasket/Weatherproofing Material
670A-1x4	Gasket, Weatherstripping
670A-3/4x4	GASKET, WEATHERSTRIPPING
678714	HOSE, HYDRAULIC START
67CFSR-239	PRESSURE REGULATOR
6801-04-04-NWO-SS	FITTING, ADP, MORB/MJIC 90 DEG SS
6801-16-12-NWO-SS	FITTING
6802-04-04-NWO-SS	45-Degree Stainless Adapter
6803-04-04-04-NWO-SS	Branch Tee Stainless Adapter
682L241G02	Kit, fuel pressurization
682L244G02	8th Stage Bleed Air Kit
682L407G04	Kit, VSV Position LVDT Assembly and Installation
682L565G03	Chip detector
682L879G02	KIT, ORIFICE PLATE
68514444190	Coupling
68A7803P5C	LAMP, BULB, ALARM PANEL - OBSOLETE
6900GZE18	SWITCH, PRESSURE
6900GZEM14-7066	SWITCH, PRESSURE
6900GZEM16-7066	SWITCH, PRESSURE
6900GZEM18-7066	SWITCH, PRESSURE
692201	Hose, L-1
692202	Hose, L-2
692203	Hose, L-3

## Starfish PPS - Complete Catalog

Part Number	Description
692204	Hose, L-5
692205	Hose, L-6
692206	Hose
692207	Hose, L-9
692208	HOSE, L10
692209	Hose, L-11
692210	Hose, D-1
692211	Hose, D-2
692212	Hose, D-4
692213	Hose, D-5
692214	Hose, D-6
692220	Hose, B-5
692225	Hose, A-5
692226	Hose, A-9
692231	Hose, A-23
692232	Hose, A-24
692233	Hose, A-25
692236	Hose, A-32
692237	HOSE, BALANCE PISTON PRESS VALIDATION
692248	Hose, B-10
692249	Hose, B-11
692250	Hose, D-7
692259	Hose, D-8
692260	Hose, B-1
692310	Hose, A2-1
692311	Hose, B-2
692312	Hose, A2-2
692320	Hose, A-11, comp disch press (P3)
692321	Hose, A28
692323	Hose, F-73
692324	Hose, W-1
692325	Hose, F-4
692326	Hose, F-5
692327	Hose, P-3
692334	HOSE ASSEMBLY, W2
692340	Hose, W-3
692406	Hose, B1/B2
692408	PIPE, TA4-P
692410	HOSE, TW1
692418	Hose, B-3
692419	HOSE, B4
692B656G02	BRUSH HOLDER
6945-1053	REGULATOR
6945-1053 Rebuild Kit	Rebuild Kit for Fisher 1301F Regulator
698300P0009	Fitting
698300P0013	Fitting
698300P0025	ADAPTER
698300P0097	Adapter
698300P0098	Adapter, 90 Deg
698300P0157	ADAPTER
698300P0158	ADAPTER
698300P0320	ADAPTER, 90

Starfish PPS - Complete Catalog

Part Number	Description
698300P0340	ADAPTER
698300P0417	ADAPTER
699423	HOSE, HYDRAULIC STARTER, CASE DRAIN
6995-1017	VALVE, VENT, FUEL SYSTEM, DLE - 15 PPM
6995-1063	KIT, CUSTOMER TERMINAL BLOCKS
699500	8'-6"X 8'-9.13/16"X 12.5/8"F/F PLENUM-TURBINE ENCL
6BRDF14008D	Valve, Thermostatic
6DR5210-0EN01-0AA0	Positioner
6ES7314-1AG13-0AB0	Processor Module
6ES7315-2AG10-0AB0	CPU
6ES73217BH010AB0	Digital Input Card
6ES7331-7PF01-0AB0	Analog Input Module
6ES73317TF010AB0	MODULE, INPUT, ANALOG
6ES73328TF010AB0	MODULE, OUTPUT, ANALOG
6ES7414-4HR14-0AB0	Simatic S7 CPU 414-4H PG Processor Module w/ FW: 4.5
6ES7416-5HS06-0AB0	Processor Module
6ES7417-4HL04-0AB0	CPU
6GK1503-3CB00	Optical Link Module
6GK6021-0AS23-0DC0-Z A05+B05+C05+D05+E00+F00+G01+H01+J00+K00	Ethernet Switch
6GK7443-1EX20-0XE0Q	MODULE, SIEMENS ETHERNET
6SL3210-1PE28-8AL0	SINAMICS Power Module
6SL3210-1PE31-1AL0	SINAMICS Power Module
6SL3224-0BE33-7UA0	SINAMICS PM240 Power Module
6SL3243-0BB30-1FA0	SINAMICS Control Unit
6SL3255-0AA00-4JA2	SINAMICS G INTELLIG.OPERAT.PANEL IOP-2
6SL3256-0AP00-0JA0	SINAMICS Door Mounting Kit
70-751-14663	RESISTOR, STARTER
70-ASMD-250	DIODE
700005	Hose Assembly, Oil Drains
700099G0001	VALVE, RELIEF
70085-1010-404	PICK UP, MAGNETIC
700851010081	Pick Up, Magnetic
700DC-PH400DZ24	RELAY, CONTROL
701689G0001	MOTOR, STARTER
701691	Boot, inlet, outer
701692	Boot, inlet, inner
701764G0001	GLASS, WIRED
7017M64G03	Valve, Pressure
7017M64G03 - AR	VALVE, PRESSURE
701849601	Key, T shape 4MM
701849602	Key, T shape 6MM
701PBKKF	SmartPower Module
702039	HOSE
702054	HOSE, COMBUSTOR DRAIN, DLE
702167	Belt, Fabric
702186	GASKET, RD
702186-GAR	GASKET, RD, GARLOCK
702186-GAR-KIT	KIT, GASKET, RUNDOWN
702236	Hose, Assembly
702237	Hose, Assembly
702238	Hose, Assembly

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
702239	Hose, Assembly
702248	Hose, Assembly; Water Inj
702286	Hose, Assembly
702637	Hose, Nat Gas Supply
702800	HOSE
702820	HOSE ASSY INLET VOLUTE DRAIN
703-1403-02	Power Supply
703033	FABRIC EXPANSION JOINT
704B139P8	Pin Straight Headless
705-510A-310	LEVEL, TRANSMITTERS
705B276P4	Ring, Retaining
705B276P5	Washer
705B276P6	Washer
705B734P13	Washer
705B813P2	NUT
706-512A-110/7AT-1100-A10-20-02	TRANSMITTER, LEVEL
706906065P0001	CABLE, T4.8
706B788P6	Nut
70A158A06048	Exchanger, Heat
70A163A08060	Cooler, turbine oil
7100G03	FAN, MOTOR COOLING
710605200000	INSERT, JACKING OIL COUPLING
7113000	Ground Rail
7118D16H01	Diode (FWD)
7118D16H02	Diode (REV)
71249	Nut, Engine Mount
71257	NUT, SS, ENGINE MOUNT
713227	HOSE
714016	HOSE, BLEED VALVE/ACCUMULATOR HYD
714026	Hose
714026P0001	Hose
714114	Insulation Blankets, SET
714114-1	Insulation Blanket
714114-19	Insulation Blanket
714114-5	Insulation Blanket
714114-6	Insulation Blanket
714213	HOSE, TLO, SUPPLY
714214	HOSE, TLO, RTN
714249	HOSE, HYDRAULIC START
714250	HOSE, STARTER
714324	Hose, DLE GAS FUEL FWD MANIFOLD (A RING)
714325	Hose, DLE GAS FUEL MID MANIFOLD (C RING)
714326	Hose, DLE GAS FUEL AFT MANIFOLD (B RING)
714437	Hose Assembly
714491	HOSE, TLO SUPPLY INTERCONNECT
714492	Hose, TLO Return Interconnect
714493	Hose, Hyd Start Supply Interconnect
714494	Hose, Hydraulic Start Return Interconnect
714495	Hose, HYDRAULIC START CASE DRAIN INTERCONNECT
714509	Hose, SUCTION, MAIN GLO PUMP
714510	Hose, DISCHARGE, MAIN GLO PUMP
714558P0003	Wedge Kit, Light

## Starfish PPS - Complete Catalog

Part Number	Description
714606	FABRIC EXPANSION JOINT
714610	FABRIC EXPANSION JOINT
714620	FABRIC EXPANSION JOINT
714655	HOSE, TLO
714659	HOSE, TLO
714664	HOSE, TLO SUPPLY FILTER INLET L2
714785	LIFT FIXTURE FOR LM2500+G4 DLE
718115-24	Gasket
719110	HOSE, HYDRAULIC START
719375	Hose, Instrument
72041400	Servo Valve
72043000	VALVE
721006	Piping, Intercooler
721007	Washer
721008	Plate, Slide, Intercooler
721016	Plate, Slide, Intercooler
721018	Plate, Intercooler
721048	HOSE ASSEMBLY, 8TH STAGE BLEED AIR, ANTI-ICE HO
721048P0001	HOSE ASSEMBLY, 8TH STAGE BLEED AIR, ANTI-ICE HO
721049	HOSE ASSEMBLY,8TH STAGE BLEED AIR,ANTI-ICE HO
721049P0001	HOSE ASSEMBLY,8TH STAGE BLEED AIR,ANTI-ICE HO
721172	Expansion Joint
721173	Manifold Assembly
721215	HOSE ASSEMBLY
721217	HOSE ASSEMBLY
721235	Mounting Link, Front
721236	Tool, Alignment
721237	Mounting Link, Front
721247	HOSE, VBV
721268	HOSE, VBV
721269	HOSE, VBV, SERVO
721270	HOSE, VBV, HYD SUPPLY
721270P0001	
721293	HOSE, LIQ FUEL
721294	HOSE
721533	ASSEMBLY, HOSE
7216 BECBP	Bearing
721835G0001	Anti-Icing T Pipe
721873	HOSE
721885	HOSE, VBV SUPPLY
721885P0002	HOSE, VBV SUPPLY
721886P0001	Hose Assembly
72190040P0001	CABLE, OFF-ENGINE, VIGV
72190140P0001	Cable, Electrical, VIVG
72190245P0001	Cable, Off-Engine
72190350P0001	Cable, Electrical, Vib
72190450P0001	CABLE, OFF-ENGINE
72190545P0001	CABLE, DRAIN VALVES
72190550P0001	CABLE, OFF-ENGINE
72190665P0001	Cable, Electrical, Vib
72190755P0001	Cable, Electrical, Act
72190860P0001	Cable, Electrical, VSV

Starfish PPS - Complete Catalog

Part Number	Description
72190955P0001	Cable, Electrical, Act
72191060P0001	Cable, Electrical, VSV
72191165P0001	Cable, Electrical, Temp
72191265P0001	Cable, Electrical, Temp
72191365P0001	Cable, Electrical, Speed
72191475P0001	Cable, Electrical, TEmp
72191565P0001	Cable, Electrical, Temp
72191665P0001	Cable, Electrical, Speed
72191765P0001	Cable, Electrical, Speed
72191865P0001	CABLE, OFF-ENGINE
72191965P0001	Cable, Electrical, Chip
72192075P0001	CABLE, ELECTRICAL, VIBRATION
72192175P0001	CABLE, XN44A LPC-IPT ROTOR SPEED
72192275P0001	Cable, Electrical, Speed
72192370P0001	Cable, Electrical, Temp
721924P0001	Cable, Off-Engine
72192570P0001	Cable, Electrical, Temp
72192670P0001	Cable, Electrical, T48
721927100P0001	CABLE, VIBRATION
721928100P0001	Cable, Electrical, speed
721929100P0001	CABLE, OFF-ENGINE
721930100P0001	Cable, Electrical, Key Phasor
72193165P0001	CABLE, OFF-ENGINE
721931A65P0001	CABLE, OFF-ENGINE
721931B40P0001	CABLE, DYNAMIC PRESSURE SENSOR
72193475P0001	Cable, Electrical, Flame
72193560P0001	Cable, Hydraulic Starter Clutch Oil
721936120P0001	Cable, Electrical, Vib
721937A40P0001	CABLE, TBV
721937B40P000-AR	CABLE, TBV, AS REMOVED
721937B40P0001	CABLE, TBV
72193840P0001	CABLE, 8TH STAGE BLEED VALVE
721938P0001	Cable, DLE CDP Bleed Valve
721950	HOSE ASSEMBLY,TURBINE HYDRAULIC,HOSE 6
72198145P0001	CABLE, LIQUID FUEL VALVES
72198245P0001	CABLE, LIQUID FUEL VALVES
72198340P0001	CABLE, MANIFOLD TEMPERATURE
72198345P0001	CABLE, LIQUID FUEL TEMPERATURE
72198350P0001	CABLE, MANIFOLD TEMPERATURE
72198445P0001	CABLE, DRAIN VALVES
72198540P0001	CABLE, DRAIN VALVES
72198570P0001	Cable, off engine
72198740P0001	Cabe, Liquid Fuel
722A688G02	BRUSH, CARBON
723043	Hose Assembly
723139	Hose discharge, GLO
723212	HOSE
723213	Hose
723214	Hose, Vent
723239	Hose, A9 Vent
723640	HOSE, SUCTION MAIN GLO PUMP BRUSH GENERATOR
723954	Hose

Starfish PPS - Complete Catalog

Part Number	Description
723954P0001	Hose
723955P0001	HOSE
723971	Hose Assembly
723972	HOSE, ENGINE CONNECTION A9
723995	Hose
724007	FABRIC EXPANSION BOOT ONLY
724008	FABRIC EXPANSION JOINT BOOT ONLY
724263	Hose Assembly
724263P0001	Hose Assembly
724379	HOSE ASSEMBLY, TLO Pump Return L6
724380	Hose, TLO Supply
724381	Hose, L2
724391	HOSE, TURBINE LUBE OIL, FILTER SUPPLY
724469	Sensor, Speed
724556	Hose, E-SPrint (TW1)
724607	Hose assembly, Hyd Starter Motor Supply
724608	Hose assembly, Hyd Starter Motor Return
724714	FABRIC EXPANSION JOINT
724746	Hose, Water Wash Supply
724748	Hose, Air Supply
724951	HOSE, AUX SKID, LP RETURN FILTER TO PUMP
726.2416	AMPLIFIER
72650340P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
72650430P0001	CABLE, XNSD SPEED
72650440P0001	CABLE, XNSD SPEED
72650450P0001	CABLE, XNSD SPEED
72650540P0001	CABLE, CRF ACCELEROMETER
72650640P0001	CABLE, TRF ACCELEROMETER
72650740P0001	CABLE, TEMP LUBE & SCAVENGE
72650840P0001	CABLE, TEMP LUBE RTD, D&E SUMPS
72650860P0001	CABLE, TEMP COMPRESSOR DISCHARGE, T3
72650940P0001	CABLE, VBV/VSV/IGV
72651040P0001	CABLE, VBV/VSV/LVDT
72651140P0001	CABLE, VBV/VSV-LVDT, RIGHT SIDE
72651230P0001	CABLE, OFF-ENGINE, T/C, T48 - LOWER
72651240P0001	CABLE, OFF-ENGINE, T/C, T48 - LOWER
72651340P0001	CABLE, IGV/LVDT, RIGHT
72651440P0001	CABLE, IGV/LVDT/XN2, LEFT
72651530P0001	CABLE, EGT THERMOCOUPLE, RIGHT
72651540P0001	CABLE, EGT THERMOCOUPLE, RIGHT
72651640P0001	CABLE, CHIP DETECTOR, A/B
72651650P0001	CABLE, CHIP DETECTOR, A/B
72651740P0001	CABLE, CHIP DETECTOR, C/D/E
72651840P0001	CABLE, T2/T25 RTD
72651850P0001	CABLE, T2/T25 RTD
72651940P0001	CABLE, XN25 SPEED
72652040P0001	CABLE, MANIFOLD TEMPERATURE
726521A40P0001	CABLE, CLUTCH OIL DRAIN RTD
726522A40P0001	CABLE, STAGING VALVES, LEFT
726522B40P0001	CABLE, STAGING VALVES, LEFT
726523A40P0001	CABLE, STAGING VALVES, RIGHT

Starfish PPS - Complete Catalog

Part Number	Description
726523B40P0001	CABLE, STAGING VALVES, RIGHT
72652445P0001	Cable, Motor Resolver
72652540P0001	CABLE, STAGING VALVES
72652601P0001	CABLE, PATCH
72652745P0001	CABLE, MOTOR POWER
726528A40P0001	CABLE, UV FLAME DETECTOR
726529A040P0001	CABLE, IGNITION TRANSFORMER
72653040P0001	Cable, Staging Valves
72653340P0001	CABLE, STAGING VALVES
72653545P0001	CABLE, RESOLVER FEEDBACK
72689040P0001	CABLE, VSV
72689045P0001	CABLE, SERVO VALVE
726891100P0001	CABLE, DUAL RTD/VSV/LVDT
72689150P0001	CABLE, DUAL RTD/VSV/LVDT
72690045P0001	CABLE, ACCELEROMETER
72690145P0001	CABLE, ELECTRICAL
72690235P0001	CABLE, STAGING VALVE, LEFT
72690470P0001	CABLE, STAGING VALVE
72690745P0001	CABLE, T2 DUAL
72693030P0001	CABLE, CDP
726932060P0001	CABLE
72693245P0001	CABLE, FLAME DETECTOR
726933100P0001	CABLE, RTD
726934070P0001	CABLE, T/C, DUAL, T3
72693560P0001	CABLE, ELEC, NGG1 GG SPEED
72694105P0001	CABLE, OFF-ENGINE, TM2500
728025	MOUNT, TURBINE
728026G0001	MOUNT, TURBINE REAR FRAME
728029	MOUNT, TURBINE
728034	BOLT
728035	BOLT, Engine Mount
728036	BOLT, Engine Mount
728036P0001	BOLT, Engine Mount
728039	FABRIC EXP. JOINT
728046	Bolt, Jacking, Clevis, Compressor Front Frame
728046P0001	Bolt, Jacking, Clevis, Compressor Front Frame
728066	Hose, MLO ,HOSE 1
728067	Hose, MLO ,HOSE 2
728068	Hose, MLO ,HOSE 3
728069P0001	HOSE FABRICATION DETAIL, MINERAL, LUBE OIL HOS
728102	Hose
728103	Hose
728104	HOSE
728126	HOSE, BOOSTER SCROLL DRAIN
728139	FABRICATION DETAIL,MINERAL LUBE OIL,HOSE 8
728169	Hose, Water Wash
728173	Hose, Water Wash
728174	Hose, Water Wash
728181	HOSE ASSEMBLY SYNTHETIC PUMP SUPPLY LUBE OIL
728183	HOSE, Scavenge Discharge Hose 2
728185	Hose Assembly

## Starfish PPS - Complete Catalog

Part Number	Description
728187	Hose, SLO Hose 4
728192	HOSE, TURBINE HYDRAULIC HOSE
728194	Hose, Exhaust Coll Drain
728195A	HOSE, TURBINE HYDRAULIC HOSE 5
728210	FABRIC HPC SCROLL DIAPHRAM
728215	FABRIC BOOSTER SCROLL DIAPHRAM
728245	HOSE, FABRICATION, DETAIL
728246	HOSE ASSY, TURBINE HYDRAULIC HOSE 4
728252	Hose Assembly, Liquid Fuel
728267	Hose
728290	HOSE ASSY, SYNTHETIC LUBE OIL DEMISTER VENT
728294	HOSE, SUMP SUPPLY PURGE
728304	HOSE, PS3
728305	HOSE, INSTRUMENT
728309	HOSE ASSEMBLY,INSTRUMENT HOSE
728317	Hose SLO – to / from Cooler
728321	HOSE, INSTRUMENT, PS3A AND PS3B
728322	HOSE ASSEMBLY,INSTRUMENT HOSE,P48 AND PTBH1
728511	HOSE ASSY, VBV TURBINE HYDRAULIC RETURN
728729	HOSE 1 ASSEMBLY, INTERCONNECTING PIPING
728730	HOSE ASSY, INTERCONNECT PIPING HOSE 2
728731	HOSE ASSEMBLY,INTERCONNECTING PIPING,HOSE 3
728732	HOSE ASSEMBLY,INTERCONNECTING PIPING,HOSE 4
728740	HOSE ASSY,MINERAL LUBE OIL SYSTEM COMPENSAT
728771	HOSE, HYDRAULIC STARTER OIL
728776	HOSE ASSEMBLY
728870	HOSE, ASSEMBLY, SLO SYSTEM
728888	HOSE ASSEMBLY
728889	HOSE ASSEMBLY,TURBINE HYDRAULIC,FROM FILTER
728898	HOSE
728909	HOSE ASSY, WATER INJECTION HOSE #1
729032	HOSE ASSY, SLO PRE-SEPERATOR CONNECTION, A1, VENT
729033	HOSE, SLO PRE-SEPARATOR CONNECTION, B-C SUMP
729034	HOSE ASSY, SLO PRE-SEPERATOR CONNECTION, D S
729039	HOSE ASSEMBLY,ROOF,SLO A1,A2 SUMP VENT
729041	HOSE ASSEMBLY,ROOF,SLO D SUMP VENT
729042	Hose Assembly, A10 D Sump Vent
729051	HOSE ASSEMBLY,SLO A1,A2 SUMP VENT
729135	HOSE ASSY, GAS FUEL MANIFOLD-F1
729171	HOSE, BOOSTER SCROLL DRAIN RH INTERCOOLER C
729203A	HOSE ASSEMBLY, HYDRAULIC STARTER, OIL SUPPLY
729203B	HOSE ASSEMBLY, HYDRAULIC STARTER, OIL SUPPLY
729204	HOSE ASSEMBLY
729205	HOSE ASSEMBLY,HYDRAULIC STARTER OIL TO START
729317	HOSE ASSY, WATER INJ DUPLEX FROM STRAINER
729975	LIFT FIXTURE
729XU220159	HEATER FLANGE, 153KW, 480V, 3ph
73-13524-A1	Switch, Prox
73-13561-H41549	Switch, Prox
731092	SEAL
731093	SEAL

## Starfish PPS - Complete Catalog

Part Number	Description
731095	SEAL
731184	HOSE, LOAD CAGE COOLING HOSE 7
731204P0001	ASSY DRAIN HOSE, GV-ACTUATOR
731214P0001	HOSE ASSY, MINERAL LUBE OIL GENERATOR INTERC
731439P0001	HOSE ASSY, MINERAL LUBE OIL HOSE 6
731582	HOSE,PRESSURIZING AIR
731630	HOSE
731631	HOSE
731737P0002	HOSE ASSY ROOF, SLO SYSTEM B-C SUMP VENT
731738	HOSE ASSEMBLY,SYNTHETIC LUBE OIL SYSTEM ENGR CONNECTION (A10),D SUMP VENT
731742P0002	HOSE ASSY, SYNTHETIC LUBE OIL SYSTEM, ENGINE C
731871P0001	FOD Screen
731872G0001	LMS100 FOD Sock Kit
731872G0001-SOCK	LMS 100 FOD Sock
731872P0001	FOD Sock
733108	HOSE, ASSEMBLY, JACKING OIL PUMP SUPPLY
733230	152.3/4" X 119" X 12.1/2" F/F PLENUM (PipingTech does I ONLY)
733574	HOSE, GAS FUEL DLE CONNECTION F1D
733575	HOSE, GAS FUEL DLE CONNECTION, F1E
736L680G01	Bergen Cables
737-3/4NPT X M25F	ADAPTOR, CONDUIT
737652	HOSE, LIQUID BOOST AUX SKID, PUMP DISCHARGE
737L694G02	KIT: VSV BUSHING
738L193G01	KIT: TUBE, AIR, HPT COOLING
739325	HOSE, DLE GAS FUEL MID MANIFOLD (G RING)
739326	HOSE, DLE GAS FUEL AFT MANIFOLD (B RING)
741041	Hose, Gas
741041P0002	Hose, Gas
741107	HOSE
741165	Hose
741166	Hose
741189	HOSE, CHARGER OUTLET TO TANK
741190	HOSE, COOLER
741200	8'-6" X 9'-4.11/16" X 12" F/F PLENUM FABRIC EXP. JOINT BACKUP BARS
741220	HOSE, PUMP OUTLET TO DRAIN FILTER
741228	HOSE, ASSEMBLY, LP RETURN MANIFOLD
741228P0004	HOSE, ASSEMBLY, LP RETURN MANIFOLD
741232	HOSE, TLO RETURN, L3
741233	HOSE
741234	HOSE, ASSEMBLY, MANIFOLD TO THERMAL
741235	Hose, Filter to Pump Return
741236	Hose
74240	TUBING, INSULATION, 6' LENGTH
744C0258P002	Bearing
744C258-001	Bearing
744F003	VALVE, SERVO
74712-06-02-04-00	Cable
74712-06-05-03-00	SEISMOPROBE
747714	FABRIC EXPANSION JOINT
747C0078G002	Bearing

## Starfish PPS - Complete Catalog

Part Number	Description
747C0778G002	Bearing
748948	HOSE, HYDRAULIC START, AUX SKID PUMP TO TANK
748953	HOSE, HYDRAULIC START CASE DRAIN
748954	HOSE, HYDRAULIC START, AUX SKID, PUMP TO CASE RETURN FILTER
750068-1408	FLF 768 7/8 X 1/2 CONNECTOR BRASS
752070P0001	HOSE ASSEMBLY
752124	Hose, Lube, GLO
752135	Alignment Pin, Exhaust to Enclosure
752163	HOSE, LIQUID FUEL, SECONDARY FUEL SUPPLY, HD-5
752164	HOSE, LIQUID FUEL, PRIMARY FUEL SUPPLY, HD-5, PR
752289	HOSE ASSEMBLY, HYDRAULIC
752289P0001	HOSE ASSEMBLY, HYDRAULIC
752310	HOSE ASSEMBLY, HYDRAULIC
752310P0001	HOSE ASSEMBLY, HYDRAULIC
752332	HOSE, TLO INLET PUMP, L1
752397	Hose, Case Drain Q/D
752397P0001	Hose, Case Drain Q/D
752398	Hose, Hydraulic Start Return
752454	HOSE ASSY LIQUID BOOST AUX SKID
752456P0001	Hose, VBV
752483	Hose, TLO System Return
752483P0002	Hose, TLO System Return
752486	HOSE
752486-QC	QUICK CONNECT, HOSE
752503	HOSE, TLO SYSTEM - B
752505	Hose - Gas Fuel System
752505P0001	Hose - Gas Fuel System
752515	Hose, Hyd Start Return
752547	HOSE, GAUGE PANEL
752548	HOSE, INSTRUMENT
752552	HOSE, ASSEMBLY
752553	HOSE
752554	HOSE
752560	Hose
752561	HOSE, WATER INJECTION MANIFOLD
752581	Alignment Pin, Air Filter to Enclosure
752586	HOSE ASSY EXHAUST DRAIN
752587	HOSE ASSY EXHAUST COLLECTOR DRAIN EXTERIOR
752637	HOSE, HYDRAULIC
752700	HOSE, GAS PURGE SYSTEM, HD-5 PROPANE
752702	HOSE, INSTRUMENT AIR SUPPLY
75271560001	ASSEMBLY: GAS DETECTOR, 505, METRIC
752755	HOSE, INLET LUBE SUPPLY L4
752828	Hose, Gas Fuel Supply
752828P0001	Hose, Gas Fuel Supply
752917P0001	GAS FUEL PILOT SUPPLY
752943	HOSE, TLO DISCHARGE, SCAVENGE, L3
752974	HOSE
752983	HOSE, ASSY, FIRE
7539500T03S03P0001	CABLE, TM2500
7539500T04S03P0001	CABLE, TM2500

Starfish PPS - Complete Catalog

Part Number	Description
7539500T05S03P0001	CABLE, TM2500
75406262-G09X	STUD
754554-2-85F	CLAMP
755047P0001	HOSE ASSY, MINERAL LUBE OIL #3J BEARING
755069P0002	
75507500	KIT: FILTER, SERVO, LPC-IGV
75511066	Filter Replacement Kit
755163P0001	HOSE ASSY, MLO, HOSE 7
755196P0001	HOSE ASSY, MINERAL LUBE OIL #3j BEARING
755197P0001	HOSE ASSY, MINERAL LUBE OIL #3 BEARING
755202	Hose, Metal, Water Injection Manifold
755202P003	Hose, Metal, Water Injection Manifold
755362	HOSE, LOAD CAGE COOLING HOSE 3
755421	HTOIC Vent hose
755421P0001	HTOIC Vent hose
755456	Hose, Turbine Hydraulic
755459P0001	Hose, Turbine Hydraulic
758248	HOSE, HYDRAULIC START A
758249	HOSE, HYD Start B
758928P0001	HOSE
758980P0001	HOSE ASSEMBLY, HYDROLIC START SUP
758981	HOSE ASSEMBLY, HYDRAULIC START RET
759249	HOSE ASSEMBLY
761-SS 2"	Y STRAINER
761-SS 2"-BSKT	Strainer Insert
761-SS 2"-GSKT	Gasket
761-SS 3"	Y STRAINER
761-SS-3"-GSKT	GASKET
764-CS	4" Y-Strainer Assembly
764-SS 1 1/2	Strainer, Y
764-SS 1"	Y Strainer
764-SS 3"	Y-STRAINER
764-SS 4"	Y STRAINER, INLET SCREEN
764-SS 4" GSKT	Y STRAINER GASKET
765A651G04	Control Relay
767X030002 VT-JVS-200	Outdoor Voltage Transformer
770081027315	ESys Module (Simplex)
771A0563P001	SWITCH, MICRO
772-298B	VALVE, SERVO
780-SD-32654	TRANSFORMER, CURRENT
780524	Exciter
780I-402-1	TRANSFORMER, CURRENT
780I-SD-15247MA	Current Transformer
781-SS	Y Strainer
781-SS-STRN	Y Strainer, replacement strainer, 100 mesh
781122X0055	HEATER, ENCLOSURE
782XDXH10-120A	RELAY, 24V
782XDXH10-24VDC	RELAY, 24V
783100X0730	BRACKET, HOLDER, MAG P/U
78432-04	PC Board for Distribution Module
7899	Gas Sniffer
78D25N00A025T38E1	RTD

Starfish PPS - Complete Catalog

Part Number	Description
78D25N00A120T22E1	TRANSMITTER
78N15N00N025E1	SENSOR, TEMPERATURE
78N15N00N025E5	SENSOR, TEMPERATURE
78N15N00N025KF	ELEMENT TEMP, FTD PLATINUM
78R25N00A020T38E5	TRANSMITTER
78R25N00A025T34E5	Sensor, Temp
78R25N00A025T38E1	RTD
78R25N00A025T38KF	RTD
78R25N00A045T22E5XA	RTD
78R25N00A100T22E1	TRANSMITTER
78R25N00A120T22E6	Model 79 Connection Head
78R25N00N120E1	DETECTOR
7940D52001	Piston, Igniter
79622-01	Main PC Board
79841	SUPPORT, EXHAUST
7A00401G01	PCA detector preamp (non-metrology units)
7A00402G01	PCA Solenoid/Heater
7A00403G01	PCA Base, I/O
7A00420G02	Backplane PCBA
7A00555G02	CPU Board
7ML1201-1AC00	Probe, 2 wire
7ML1201-1EF00	Probe, 2 wire
7ML51171BD074BK3	Probe, Level
8 AWG THHN	8 AWG THHN SINGLE STRAND
8-8 VBTX-SS	TRIPLE-LOK 37° 45° ELBOW VTX
800-1440	Module, input, fire system
800-1441	Manual Pull Module
800-1442	Module, Alarm
800-1443	MODULE, RELEASE
800-1444	Fault Module
800-1457	NT 420 Digital Gas Module, LFL
800-1760	MODULE, RELAY
800-1785	Module, Blank
800826-6752	Non-Setting Gasket and Jointing Compound
8013-1067	PUMP, LUBE
8013-1071	PUMP, LUBE
8014-1039	PUMP, FUEL
8014-1045	PUMP, FUEL
8014-1045-AR	Pump, Fuel-As Removed
8014-1051	Liquid Fuel Pump
803015	Hose Assembly, HYDRAULIC START PUMP DISCHARGE
803015P0002	Hose Assembly, HYDRAULIC START PUMP DISCHARGE
803016	HOSE ASSEMBLY, HYDRAULIC START LP RETURN
803027	HOSE ASSEMBLY, HYDRAULIC START
803028	Hose Assembly, HYDRAULIC START PUMP TO CASE DR
803070	HOSE ASSEMBLY, 1", LIQUID, WATER
803073	Hose Assembly, HYDRAULIC START MANIFOLD BLOCK
803106	Hose Assembly, WATER INJECTION SUCTION
803106P0001	Hose Assembly, WATER INJECTION SUCTION
803107	Hose, Water Injection Discharge
803107P0001	Hose, Water Injection Discharge
803163	Hose Assembly, HYDRAULIC START TANK TO PUMP

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
803242	DIAPHRAGM, DISK, RUPTURE
803511	Hose Assembly, TLO AIR OIL SEPARATOR RETURN
803535	HOSE, EQUIP-SPRINT INTERCONNECT
803536	Hose Assembly, Air Supply, Interconnect
803536P0001	Hose Assembly, Air Supply, Interconnect
803537	Hose Assembly, TLO SUPPLY
803539	Hose Assembly, Water Wash
803559	Hose Assembly, HYDRAULIC START SUPPLY INTERCON
803560	Hose Assembly, HYDRAULIC START RETURN INTERCO
803561	HOSE ASSEMBLY, HYDRAULIC START CASE DRAIN
803718	HOSE, GLO PIPING DRAIN
803724	HOSE ASSEMBLY, OUTLET JACKING OIL
803726	HOSE, COOLER INLET
803727	HOSE, COOLER OUTLET
803734	HOSE, SUPPLY GLO PIPING
806213	HOSE, TLO SUPPLY L1
806214	HOSE
806218	HOSE, TLO SUPPLY, L1
806219	HOSE, ASSEMBLY, TURBINE LUBE
806248	HOSE, TURBINE SKID, HYDRAULIC
806249	HOSE, ASSEMBLY, TURBINE SKID TO HYDRO
806372P0001	HOSE ASSEMBLY, TURBIN SKID HYDROLIC
806376	HOSE, TURBINE SKID, HYDRAULIC
806486	HOSE, TLO SUPPLY INTERCONNECT SPOOL 1
806491	HOSE, TURBINE LUBE OIL SUPPLY INTERCONNECT
806495	HOSE ASSEMBLY, HYDRAULIC
806526	HOSE, MEDIUM BTU GAS FUEL MANIFOLD
806586	HOSE, HYDRAULIC START, SAC PLUS SUPPLY/RETURN
806655	HOSE, TLO SUPPLY, FILTER INLET, L2
806659	Hose, TLO Supply Filter (L4)
806895	Inlet Seal
806895P0001	Inlet Seal
806895P0002	Inlet Seal
8085182	O-RING
80EJ/31/4/9	FAN, VENTILATION
8100-0005	ACTUATOR, VARIABLE
81045108	Seal Ring
81045224	Cover O-Ring
810864G0001	FABRIC EXPANSION JOINT ASSY
81160	RTV SILICONE
813013	Hose Assembly
813016	Hose Assembly, TURBINE AIR/OIL SEPARATOR
813018	Hose Assembly, A10
813019	Hose Assembly, A9
813126	Hose Assembly,
8131A6M-338-A	V GROOVE COUPLING
813555P0003	Hose Assembly GAS FUEL + WATER
813555P0007	HOSE, LIQUID FUEL
813555P0008	HOSE
813555P0015	GAS FUEL, NOX WATER, W3
813555P0027	Hose Assembly, Liquid, Water
813555P0028	Hose Assembly, LIQUID, WATER

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
813555P0029	Hose Assembly, LIQUID, WATER
813555P0035	HOSE, ASSEMBLY, TLO
813555P0040	Hose Assembly, Liquid
813555P0061	Hose Assembly, MINERAL LUBE OIL
813555P0062	Hose Assembly, LIQUID, MINERAL LUBE OIL
813706	Hose Assembly, HYDRAULIC START
8140-0601	Conditioner, Signal, Remote
81546-01	XDCR I/O & Record Terminals & Alarm Relay Outputs
81PS1F68-8	VALVE, RELIEF
81PS1M68-4	VALVE, RELIEF
81PS1M68-4 (150)	VALVE, RELIEF
81PS1M68-4(150)	VALVE, RELIEF
81PS1S12C16A-8	VALVE, RELIEF
81PSS12A16A-8	VALVE, PRESSURE RELIEF, TURBINE LUBE OIL
8200-1100	LINKNET-HT
8200-1102	LINKNET-HT
8200-1103	LINKNET-HT, MODULE
8200-1104	LINKNET-HT
8200-1105	LINKNET-HT
8200-1105-OH	Module, RTCNET DOUT (16 Channel)
8200-1151	LINKNET-HT
8200-1200	LINKNET-HT
8200-1202	LINKNET-HT
8200-1203	LINKNET-HT
8200-1204	LINKNET-HT
8200-1205	LINKNET-HT
8200-1252	COMMUNICATION DEVICE; RTN GATEWAY, 10 CAN PO ENHANCED
8200-1353	FLEX500,LVDC,BACK PANEL
8200-169	Driver
8200-176	Driver, EM, Fuel Valve, DLE, Woodward
8200-176-OH	DRIVER, EM, FUEL VALVE, DLE, WOODWARD
8200-177	Woodward Driver
8200-177-AR	WOODWARD DRIVER
8200-182	Woodward DRIVER
8200-182-AR	WOODWARD DRIVER, AS REMOVED
8200-182-OH	Woodward DRIVER, OVERHAULED
8200-185	DRIVER, DVP
8200-188	Positioner, Valve
8200-226	Controller, Servo Position
8200-314	Woodward Driver
8200-505	Driver, Digital Valve Positioner
8200-505-AR	Driver, Digital Valve Positioner, As Removed
8200-505-OH	DRIVER, DVP, OVERHAULED
8200-507	Driver, Woodward
8200-508	DIGITAL VALVE POSITIONER
8200-510	DVP, 24VDC, IP30, TB Input
821250	Pump, Fuel
8220G21	VALVE, SOLENOID, RED-HAT
8273-1011	Control, Speed / Load Sharing
830A-36889	Cable, Interface
8322-SAP	Conductor, Stranded Copper, 2, 16 AWG

## Starfish PPS - Complete Catalog

Part Number	Description
836-P17-ANCH	Switch, Pressure
840100974968	MERV 8 Pleated HVAC Air Filters 24x24x2
8408-017	Driver, Ignition System
84084240P0001	CABLE, OFF-ENGINE
84084360P0001	CABLE, CHIP DETECTOR
841338	HOSE, HYDRAULIC STARTER, LOW PRESSURE LINE, E
841345	HOSE, TLO INTERCONNECT SUPPLY
841430	HOSE, HYDRAULIC START TANK TO PUMP INLET
841431	HOSE, MANIFOLD TO THERMAL BYPASS
841435	HOSE, COOLERS TO TANK
841453	HOSE, TLO, L3, SCAVENGE, DISCHARGE
841594	HOSE, TURBINE LUBE OIL DRAINS
841704	HOSE, INSTRUMENT
8440-2167	MODULE, SYSTEM, SYNCHRONIZING
8440-2174	Control SPM-10
844555P0005	Hose, Hyd Start, Skid
844555P0060	Hose Assembly, Air
845-5747.2	ADAPTER, TERMINAL BLOCK
85.BAA.003035	Pump, GLO
850-E-P5-NN-G5-H-N-N-A-A-N-G-M-S-B-B-SE-N-N-B-N	Relay, Protection
850-E-P5-NN-G5-H-N-N-A-N-N-M-S-S-F-B-SE-N-N-B-N-4	RELAY, PROTECTIVE
850EP5NNG5HNNAANGMSBBSENNBN	Relay, Protection
8510023-1	Valve, stater pump
851360G0007	FABRICATION DETAIL, COVER
8519500G26S03P0003	CABLE
8519500G27S03P0002	CABLE
8519500G28P03P0001	CABLE
8519500G29P03P0002	CABLE
8519500G30P03P0002	CABLE
851950GS20S03P0001	CABLE, TM2500
851950OG25C21P0001	CABLE, TM2500
851950OG33P03P0001	CABLE
851950OT08P03P0001	CABLE
851950TC15B35P0001	CABLE, TM2500
851950TC16B35P0001	CABLE, TM2500
851950TC17B35P0001	CABLE, TM2500
852009	Hose Assy, Gas Fuel Interconn
852122	HOSE, TANK TO CHARGE PUMP FILTER
852125	HOSE, GAS FUEL SKID PIPING
852127	Hose Assy, Gas Fuel Interconn
852128	Hose, Gas
852128P0002	Hose, Gas
852128P0003	Hose, Gas
852128P0004	Hose
852130	HOSE
852131	HOSE, EXHAUST DRAIN
852132	HOSE, EXHAUST COLLECTOR DRAIN EXTERIOR
852132P0001	HOSE, EXHAUST COLLECTOR DRAIN EXTERIOR
852132P0002	HOSE, EXHAUST COLLECTOR DRAIN EXTERIOR
852133	HOSE
852140	Hose Assy,

## Starfish PPS - Complete Catalog

Part Number	Description
852141	Hose Assy, 2nd Liq Fuel Manifold
852142	HOSE ASSEMBLY, FUEL SYSTEM FILTERSUPPLY
852143	Hose Assembly, Fuel Return, Liquid
852143P0001	Hose Assembly, Fuel Return, Liquid
852148	HOSE
852154	HOSE ASSEMBLY, WATER INJECTIONRETURN
852155	HOSE, WATER INJECTOR SUPPLY, ASSEMBLY
852155P0002	HOSE, WATER INJECTOR SUPPLY, ASSEMBLY
852156	Hose Assy, Water Inj Manifold
852181	HOSE, TURBINE DRIP PAN DRAIN
852205	Hose Assy
852206	Hose Assy
852209	Hose Assy
852210	Hose Assy
852212	Hose, GLO Pump Discharge
852213	Hose Assy
852214	Hose, GLO Pump Suction
852499	Hose Assembly; TLO
852499P0001	Hose Assembly; TLO
852511	Hose Assy, Water Wash Tank to Pump
852512	Hose Assy, Water Wash Tank to Pump
852513P0001	HOSE ASSEMBLY, MANIFOLD TO CASE DRAIN
852513P0002	HOSE ASSEMBLY, MANIFOLD TO CASE DRAIN
852514	Hose Assy
852515	Hose Assy, Ret Filter to Charge Pump
852516	Hose Assy, Tank to Charge Pump
852517	Hose Assy, Fin Fan Outlet
852517P0001	Hose Assy, Fin Fan Outlet
852517P0002	Hose Assy, Fin Fan Outlet
852518	Hose Assy, FIN FAN INLET
852521	Hose Assembly, Liquid
852521P0001	Hose Assembly, Liquid
852530	HYDRAULIC START TO RETURN FILTER
852530P0001	HYDRAULIC START TO RETURN FILTER
852530P0002	HYDRAULIC START TO RETURN FILTER
852531	Hose Assy, Manifold to Case Drain
852532	Hose Assy, CHARGE PUMP TO HYDRAULIC START SUP
852533	HOSE, TLO TANK TO L1
852534	Hose, TLO, L2 to SUPPLY
852534-M	Hose, TLO, L2 to SUPPLY
852535	HOSE, ASSEMBLY, TLO FILT TO L4
852535-M	HOSE, ASSEMBLY, TLO FILT TO L4
852536	HOSE, ASSEMBLY, LIQUID, TURBINE, TLO SCAVENGE D
852537	Hose Assy, Water Wash IntCon
852538	Hose, Liquid
852538P0001	Hose, Liquid
852545	Hose Assy, HYDRAULIC START RETURN
852545P0001	Hose Assy, HYDRAULIC START RETURN
852546	Hose Assy, Hyd Start Drain
852547	Hose, Hyd Start Supply
852547P0001	Hose, Hyd Start Supply
852548	HOSE, TLO SUPPLY L1

## Starfish PPS - Complete Catalog

Part Number	Description
852549	Hose Assy, TLO Scavenge
852550	Hose Assy, TLO L2
852551	HOSE, TLO HEADER SUPPLY L4
852552	HOSE, WATER WASH DETERGENT MANIFOLD
852710P0001	Seal Ring, Turbine Bellmouth
852710P0002	Seal Ring, Turbine Bellmouth
852810P0001	FABRICATION DETAIL, MATING FLANGE
852821	Manifold, Gas Fuel
852887	Hose
852887P0001	Hose
852888	Hose
852888P0001	Hose
8530631001	RELAY, 24VDC COIL DPDT
85435-01	Power Terminal
856-2-12C	Pressure Probe
8570/12-306	CONNECTOR, STAHL
8580-080	Pump
8580-085	PUMP
8580-086	Pump, hyd
86/060-039A-1	Pump Seal Kit
861-SS(1INCH)	Y-STRAINER 1"
861-SS-1-100BSKT	Y-Strainer Replacement Basket
861-SS-1GSKT	Y-Strainer Replacement Gasket
86160RIW039A-1	PUMP, LIQUID
862-7-19C	T/C; T48
86200RIW039A-1	PUMP, LIQUID FUEL
864M-SS 1"	Y-STRAINER
86517-01-01-01-01	MODULE, INTERFACE
86517-01-01-01-02	MODULE, INTERFACE
86691-1250-400-15-00	Probe
866B	Flame Arrestor
868138P0001	Hose, Water Inj, Pump Suction
868139P0001	Hose, Water Inj, Pump Suction
868140P0001	Hose, Water Inj, Pump Discharge
868141P0001	Hose, Water Inj, Pump Discharge
868142	HOSE, HYDRAULIC START TANK TO PUMP
868143	Hose, Hydraulic Start
868256	HOSE, GAS FUEL DLE CONNECTION F4
868257	HOSE, GAS FUEL DLE CONNECTION F2
868258	HOSE, GAS FUEL DLE CONNECTION F3
868259	HOSE, GAS FUEL DLE CONNECTION F5
868260	HOSE, GAS FUEL DLE CONNECTION F1
868515	HOSE, HYDRAULIC START SUPPLY
868557	Hose Assembly, Sprint Air (TA4)
868669	HOSE, HYDRAULIC START COOLER TO TANK
868693	Hose Assembly, Secondary Fuel Supply F3
868735	HOSE
868797G0001	Duct, VBV
868797G0003	Duct, VBV
868797G0003-Boot	BOOT
868797G0003-IRON	TOOL, IRON, SEALING
868797G0003-strips	STRIPS

## Starfish PPS - Complete Catalog

Part Number	Description
868843	HOSE, HYDRAULIC START RETURN, FILTER TO PUMP,
868884	Hose Assembly, TLO
868885	HOSE, TLO FILET/COOLER
868886	HOSE ASSEMBLY, AIR SUPPLY
868887	HOSE ASSEMBLY HYDRAULIC START RETURN
868888	HOSE ASSEMBLY, HYDRAULIC START
868889	HOSE, ASSEMBLY, HYDRAULIC STARTER
868890	HOSE WATER INJECTION SUPPLY
868891	HOSE, ASSEMBLY, WATER WASH SUPPLY
871-B32686S7474K561	CAPACITOR .47UF 1200V for VSR100 / VSR175
87461146	ORING, FILTER HOUSING
8800-1001	CONTROLLER - DSS-2: DIGITAL SPEED SWITCH, 2 CHANNEL
883-3-14C	Thermocouple T5:4
88593	AFT Mount Bearing
88697	MT BOLT, HOT END
88698	BOLT,ENGINE MOUNT HOT END - LM2500
88702	PIN, MOUNTING
88MHNSS	PARKER MALE HEX NIPPLE 1/2" MNPT X 1/2" MNPT
8904-931	GAS VALVE ACTUATOR, 3103 VLV WITH TM-55P
89134217	Backup Ring
8915-094	VALVE, GAS
8915-094-AR	VALVE, GAS, AS REMOVED
8915-094-OH	VALVE, GAS, OVERHAULED
8915-1010	VALVE, FUEL
8915-1010-AR	VALVE, FUEL, AS REMOVED
8915-1023	VALVE, WATER
8915-1023-AR	VALVE, WATER, AS REMOVED
8915-1023-OH	Valve, Water, OVERHAULED
8915-1024	VALVE, FLOW CONTROL, WATER INJ.
8915-1024-AR	AS REMOVED VALVE, WATER
8915-1024-OH	VALVE, WATER
8915-1029	Gas Valve, Woodward
8915-103	Water Valve
8915-1310	VALVE, FUEL
8915-1310-AR	VALVE, FUEL, AS REMOVED
8915-1310-OH	VALVE, FUEL
8915-1311	Valve
8915-1315	Valve, fuel
8915-1317	Valve
8915-1320	Gas Valve, Woodward
8915-1320-AR	VALVE, GAS, AS REMOVED
8915-1320-OH	Gas Valve, Woodward
8915-1322	GAS VALVE, WOODWARD
8915-1323	Gas Valve, Woodward
8915-1323-AR	GAS VALVE, WOODWARD AR
8915-1323-OH	GAS VALVE, WOODWARD, OVERHAULED
8915-1325	Valve, Woodward
8915-1328	Valve, Woodward
8915-1329	Gas Valve, Woodward
8915-1329-OH	GAS VALVE, WOODWARD, OVERHAULED
8915-153	Gas Valve, Woodward

Starfish PPS - Complete Catalog

Part Number	Description
8915-153-AR	Gas Valve, Woodward
8915-371	STIG valve, Woodward
8915-429	Water Valve, Woodward
8915-429-AR	VALVE, WATER, AS REMOVED
8915-429-OH	Water Valve
8915-526	VALVE-3103/TM55P
8915-526-AR	VALVE, FUEL, AS REMOVED
8915-652	VALVE, GAS
8915-652-AR	VALVE, GAS, AS REMOVED
8915-877	LIQUID VALVE, WOODWARD
8915-877-AR	Liquid Valve, Woodward
8915-886	Gas Valve, Woodward
8915-886-AR	VALVE, GAS, AR
8915-887	Fuel Valve
8915-947	VALVE, WATER
8915-947-AR	VALVE, WATER
8915-948	VALVE, FLOW CONTROL, WATER INJ.
8915-948-AR	VALVE, AS REMOVED
8915-948-OH	VALVE, FLOW CONTROL, WATER INJ
8915-953	Valve, Fuel
8915-955	Gas Valve, Woodward
8915-955AR	VALVE, GAS, AS REMOVED
8915-972	Valve, Woodward
89150106	Backup Ring
8918-082	ASSEMBLY: GSOV
8918-176	Flow Meter
8918082*WIC	ASSEMBLY: GSOV
8923-1186	Kit, Lubrication, Actuation, Woodward, Linear, LMS100
8923-2146	KIT - PCBA REPLACEMENT, QUICKTRIP
8928-5007	SOFTWARE LICENSE - GAP MONITOR
8928-5359	SOFTWARE LICENSE - GAP EDITOR 4.X SW LICENSE
8928-5361	SOFTWARE LICENSE - GAP MONITOR 4.X SW LICENSE
8928-5363	SOFTWARE, NETSIM nVe
8928-5364	SOFTWARE, NETSIM nVe
8928-7189	Seal Kit
8935-1311	LMS100 VBV Actuator Parts Kit
894A500P19	BRUSH, MOTOR
895C715G01	Cable, Igniter
89680425	Filter Kit for Liquid Fuel Filter Assembly
898891	HOSE, ASSEMBLY, WATER WASH SUPPLY
8AWG THHN	8 AWG THHN SINGLE STRAND
8EA2AEN1	Cable, PT Speed NPT
8EH15AAA1	CABLE, PATCH
8EH28AAC1	CABLE, IGV/LVDT/XN2, LEFT
8EH28AAD1	CABLE, IGV/LVDT, RIGHT
8EH28AAE1	CABLE, XN25 SPEED
8EH28AAF1	CABLE, VBV/VSV/LVDT
8EH28AAG1	CABLE, CHIP DETECTOR, A/B
8EH28AAH1	CABLE, TEMP LUBE & SCAVENGE
8EH28AAJ	CABLE, TEMP LUBE RTD, D&E SUMPS
8EH28AAK1	CABLE, VBV/VSV-LVDT, RIGHT SIDE

Starfish PPS - Complete Catalog

Part Number	Description
8EH28AAL1	CABLE, CRF ACCELEROMETER
8EH28AAM1	CABLE, TEMP COMPRESSOR DISCHARGE, T3
8EH28AAN1	CABLE, MANIFOLD TEMPERATURE
8EH28AAP1	CABLE, XNSD SPEED
8EH28AAR1	CABLE, TRF ACCELEROMETER
8EH28AAT1	CABLE, OFF-ENGINE, T/C, T48 - LOWER
8EH28AAU1	CABLE, EGT THERMOCOUPLE, RIGHT
8EH2AAE1	CABLE, T5.4, LEFT SIDE
8EH2AAF1	CABLE, T5.4, RIGHT
8EH2AAT1	CABLE, LPT, SPEED
8EH2AAT2	CABLE, LPT, SPEED
8EH2AAU1	CABLE, LPT, SPEED
8EH2AAU2	CABLE, LPT, SPEED
8EH2ABR1	CABLE, T5:4, FOR 2 PROBES
8EH2ABT1	CABLE, T5.4, FOR 3 PROBES
8EH2ABW1	CABLE, TBV
8EH2ABW1-AR	CABLE, TBV, AS REMOVED
8EH2AEB1	Cable, Staging Valve
8EH2AED1	Cable, Staging Valve
8EH2AEE1	Cable, Staging Valve
8EH2AEF1	CABLE, BLEED VALVE
8EH2AEG1	CABLE, CLUTCH OIL DRAIN RTD
8EH2AEH1	CABLE, CHIP DETECTOR
8EH2AEJ1	Cable, CRF Accel
8EH2AEK1	CABLE, TRF ACCELEROMETER
8EH2AEL1	CABLE, T/C
8EH2AEM1	CABLE, NGG2 SPEED
8EH2AEN1	CABLE, PT SPEED NPT
8EH2AEP1	CABLE, T3
8EH2AER1	Cable, Dynamic Pressure Sensor
8EH2AET1	CABLE, DUAL RTD/VSV/LVDT
8EH2AEU1	CABLE, VSV
8EH2AEV1	CABLE, TEMP, FUEL MANIFOLD
8EH2AEW1	Cable, Staging Valve
8EH2AHM1	Cable, NGG1 GG Speed
8EH2AKC1	CABLE, STAGING VALVE
8EH2AKD1	CABLE, STAGING VALVE
8EH2AKG1	CABLE, CHIP DETECTOR
8EH2AKR2	Cable, T48 Upper Thermocouple Harness
8EH2AKT1	Cable, T48 Lower Thermocouple Harness
8EH2ALA1	Cable, TRF Accel
8EH2ARS1	CABLE, TBV
8EH2DEM1	CABLE, ELEC, NGG1 GG SPEED
8EH2DHA1	CABLE, STAGING VALVES, RIGHT
8EH2DHB1	CABLE, STAGING VALVES, LEFT
8EH2DHC1	CABLE, TBV
8EH2DHD1	CABLE, 8TH STAGE BLEED VALVE
8EH2DHF1	CABLE, TEMP COMPRESSOR DISCHARGE, T3
8EH2DHM1	CABLE, NGG1 GG SPEED
8EH2DHR1	CABLE, DYNAMIC PRESSURE SENSOR
8EH2DHS1	CABLE, NPT SPEED
8EH2DHT1	CABLE, T5:4

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
8EH2DHU1	CABLE, T5:4
8EH2DHW1	CABLE, ACCEL, CRF/TRF
8EH2DHY1	CABLE, DUAL ELEMENT, T2
8EH2DJB1	Cable, VSV 1 Controls
8EH2DJC1	Cable, VSV 2 Controls
8EH2DJD1	Cable, PT Control Harness
8EH2DJE1	Cable, Fuel Solenoids, GG Speed 1
8EH2DJF1	Cable, RTDs, Lube Oils
8EH2DJG1	Cable, Ignition System
8EH2DJH1	Cable, CRF, TRF Accelerometers
8EH2HAA1	Cable, CRF Accel
8EH2HAB1	Cable, TRF Accel
8EH2HAC1	Cable, RTD Transfer
8EH2HAD1	Cable, NGG1 GG Speed
8EH2HAE1	Cable, Liquid Fuel
8EH2HAF1	Cable, PT Speed NPT
8EH2HAG1	Cable, HP Exhaust Temp
8EH2HAH1	CABLE, T3 COMP DISCHARGE
8EH2HAJ1	Cable, Sensor Dual RTD/VSV LVDT
8EH2HAK1	Cable, Chip Detector
8EH2HAL1	Cable, VSV Servo Valve
8EH37AAA1	CABLE, ELECTRICAL, IGV, LEFT
8EH37AAB1	CABLE, ELECTRICAL, IGV, RIGHT
8EH6ABL1	CABLE, THERMOCOUPLE
8EH6ABU1	CABLE, THERMOCOUPLE
8EH8CAA1	CABLE, FLAME SENSOR
8EH8CAD1	CABLE, UV FLAME DETECTOR
8EH8CAE1	CABLE, UV FLAME DETECTOR
8EH8CAT1	CABLE, UV FLAME DETECTOR
8EH8CHM1	CABLE, SERVO
8EH8CJA1	CABLE, LVDT
8EH8DBK1	CABLE, UV FLAME DETECTOR
8EH8DHK1	CABLE, UV FLAME DETECTOR
8EH8EAB1	CABLE, UV FLAME DETECTOR
8LMS8-316	Adapter
8PC2ABV1	Cable RTD Transfer 65'
8PC33BAC1	CABLE, T/C
8PC33BBJ1	CABLE, THERMOCOUPLE
8PC34ABW1	PROBE
8PT61AAC1	Thermocouple, Immersion, EGT, FT8
8TC19AAE1	SENSOR, TEMPERATURE
8TC34ABW1	
8TC34ABY1	T48 Thermocouple
8TC34BAG1	T5.4/T4.4 T/C PROBE
8TC37AAC1	T3 sensor
8TC37AAR1	T3 Sensor
8TC37AAY1	SENSOR, T3
8TC37ABA1	SENSOR, T3
8TC37ABC1	Thermocouple T5:4
8TC37ABJ1	Thermocouple T5:4
8TE34ACE2	3 T/C Harness Top Rt
8TE34ACF2	3 T/C Harness Top Left

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
8TE34ACH2	3 T/C Harness Bottom Right
8TE34ACJ2	2 T/C Harness Bottom Left
8TR1AAB1	THERMOCOUPLE, WHEELSPACE
8TR4AAJ1	Thermocouple
8TR4AAS1	THERMOCOUPLE, WHEELSPACE
8TR4AAT1	THERMOCOUPLE, WHEELSPACE
8TR4ACF1	Thermocouple, WheelSpace
8TR4ACM1	THERMOCOUPLE, WHEELSPACE
8TR4ACP1	Thermocouple, WheelSpace
8TR4ACT1	THERMOCOUPLE, WHEELSPACE
8TR4ACV1	Thermocouple, WheelSpace
8TR4ACW1	Thermocouple, WheelSpace
8TR4AFR1	Thermocouple, WheelSpace
8TR4BAU1	Thermocouple, WheelSpace
8TR4CAL1	Thermocouple, Exhaust
8TR4CAL1-AR	THERMOCOUPLE, AS REMOVED
8TR4DAA1	Thermocouple, Exhaust
8TR4DAF1	Spring Loaded Thermocouple
9-90035	Gasket, Clutch to AGB
9-PS-3380	RING, PACKING, PRESSURE BREAKER
900-3011-0000	TELKOOR POWER SUPPLY
900-3011-10-AR	POWER SUPPLY
9001/51-280-091-141	SAFETY BARRIER, ZENER
90016G01	RACKING MECHANISM RETAINER ASSY
9001KR9P35RH1	Pushbutton
900344	Filter Element
90040G01	TOC SWITCH ASSEMBLY
9007M01	VALVE, CHECK
9009M14P05	Bushing
9009M32P01	WASHER, KEY
9009M39P01	Seal
9009M74P01	GASKET
9009M74P03	Gasket
9010M11P06	Bolt, shear
901190500	KIT, MINOR SERVICE, ACE038
9011M60P01	Gasket
9013M28P01	Gasket, Lube In Seal
9013M28P02	Gasket, Lube In Seal
9013M29P01	Gasket, Lube In Seal
9013M29P02	Gasket, Lube In Seal
9013M30P01	Gasket, Lube In Seal
9013M30P02	Gasket, Lube In Seal
9014M45P49	CLAMP
9014M45P65	COUPLING
9014M79P256	COUPLING
9015M15P21	STRAP
9015M63P05	Rod, Actuation Push
9016M30P02	ASSEMBLY: SEAL, RING
9019-51	Valve, Check
9019F-51	VALVE, CHECK
9022M50P01	BOLT
9022M73P06	Washer

## Starfish PPS - Complete Catalog

Part Number	Description
9025M29G01	Nut
9032M78P05	SEAL
9032M81P03	Seal
9039M45P09	Pump
9040M58P02	Conditioner, Signal, Remote
9044624-1	Igniter Plug
9048M33P06	Bearing
9048M34P03	BEARING, PLAIN ROD END
9049M91P07	CLEVIS
9051M51G04	Connector, VSV Bridge S1
9051M52G04	Connector, VSV Bridge
9051M53G04	Connector, VSV Bridge
9052565	Capacitor Module
9055M89P03	3 T/C Harness Top Rt
9055M90P05	3 T/C Harness Top Left
9055M90P06	3 T/C Harness Bottom Right
9055M91P03	2 T/C Harness Bottom Left
9057M32P01	GASKET
9057M92P01	GASKET
9057M92P04	Gasket
9057M92P05	Gasket
9057M92P08	Gasket
9057M92P10	Gasket
9057M92P11	Gasket
90585A718-M	Screw, FHCS, 1/2"-13 x 13/4", SS, Modified
90585A724-2.75M	Screw, FHCS, 1/2"-13 x 23/4", SS, Modified
90585A724-M	Screw, FHCS, 1/2"-13 x 3", SS, Modified
9058730-1	Igniter
9059129-145	Lead, Ignition
9059129-205	Lead, Ignition
9059129-313	Lead, Ignition
9059129-385	Lead, Ignition
9059129-73	Lead, Ignition
9059360-145	Lead, Ignition
9059360-205	Lead, Ignition
9059360-313	Lead, Ignition
9059360-385	Lead, Ignition
9059360-73	Lead, Ignition
9059430-145	Lead, Ignition
9059430-205	Lead, Ignition
9059430-206	Lead, Ignition
9059430-313	Lead, Ignition
9059430-314	Lead, Ignition
9059430-385	Lead, Ignition, Flexible, 32 foot
9059430-386	Lead, Ignition
9059435-145	Lead, Ignition
9059435-205	Lead, Ignition
9059435-206	Lead, Ignition
9059435-313	Lead, Ignition
9059435-314	Lead, Ignition
9059435-385	Lead, Ignition

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
9059435-386	Lead, Ignition
905G1C4D3	Valve, Check
9060008	Output Module
9066M46P01	GASKET
9079M28G12	SLEEVE
9080M96G10	Bracket
9084M71P02	SEAL
909-300-01	Seal-In Relay
90R075KC5NN80P4S1C29GBA361024	PUMP, START
90R075KC5NN80P4S1C29GBA361024-AR	PUMP, START
90R075KC5NN80P4S1C29GBA361024-OH	PUMP, START
90R130K71NN80L4F1F29GBA361024	PUMP, STARTER
90R130KC1AB80L4F1F29GBA361024	Starter Pump
90R130KC1NN80L4F1F29GBA361024	Pump, Starter
90R130KC1NN80L4F1F29GBA361024-AR	Pump, Starter
90R130KC1NN80L4F1F29GBA361024-OH	Pump, Starter, Overhauled
910001	TBV Gasket
9101M37P72	Igniter Plug
9102M17P02	Bushing
9102M17P05	
	Bushing, Connecting Link, Stage 5, LM6000
9102M17P09	Bushing
9103M46P01	PLUG
9103M85G02	PLUG, BORESCOPE
9106M39P04	Bushing
9107M21P06	Bolt
9107M23P01	Gasket, Clutch to AGB
9107M23P02	Gasket, Clutch to AGB
9107M25P04	Washer, Thrust
9107M35G08	STUD, BELLCRANK, WELDED FRAME
9107M99P01	Washer
9108M27P03	Bolt
9109M72P09	NUT, SELF-LOCKING, DBL HEX, 0.250-28
9109M91P01	BOLT
9115M99P05	Flange
9116M48P03	STRAP, RETAINING
9116M48P05	Strap
9117M17P07	BOLT
9117M47P02	MT BOLT, HOT END
9128M71P02	GASKET
9130M96P02	Screw
9130M96P03	Screw
9130M96P06	Screw
9131M44P02	Bushing, VBV
9131M45P02	Washer, VBV
9134M25P117	STRAP
9134M25P125	Strap, Retaining
9134M25P33	STRAP
9134M25P41	Strap
9134M25P49	STRAP, RETAINING

Starfish PPS - Complete Catalog

Part Number	Description
9135M62P01	PLUG, HPC
9135M76P03	Bolt
9135M80P02	NUT
9137M30P01	ROD
9137M95G02	CONNECTING LINK, ACTUATION RING
9137M95G02-AR	Link
9137M95G05	LINK
9138M30P01	BOLT
913BDCM01-JE-0900	VALVE, RELIEF
913BDCM01-JE1050SET	VALVE, RELIEF
9146M63P03	BOLT
9146M80P02	Bushing
9146M80P03	SLEEVE, ACTUATION ARM
9146M80P05	SLEEVE, ACTUATION ARM
91520520	ELEMENT, THERMOSTATIC
9153M75P02	Transducer, Displacement
9154M98P03	Fuel Filter Assembly
9155M25P02	BOLT
91700	ADAPTER
9174M19P01	Washer
9174M20P01	STRIP
917B0496P015	Valve
9181M41P02	Connecting Link
9181M41P04	Arm, Level, Stage 3
9181M42P04	LINK
9186M93G04	SCREW, MACHINE
9187M73P128	COUPLING
9187M73P140	Coupling
9187M73P36	Coupling Clamp
9187M73P40	Coupling Clamp
9193M69P19	SPACER
9198M35P02	SHIM
9198M61P02	SEAL
9198M62P01	SEAL
9198M65P01	NUT, SELF LOCKING
9198M65P02	NUT
9198M65P03	NUT
9200A006-P019	TRANSDUCER, LVDT
9206M59P18	Spacer
9206M61P05	SPACER
9206M79P01	Washer
9206M79P02	Washer, Flanged
9206M79P03	washer
9206M79P10	Washer, Flanged
9206M79P11	washer
9206M79P16	Washer, Flanged
9206M79P17	washer
9207M53P06	Spacer
9207M53P09	SPACER
9207M68P01	Bushing
9207M68P02	Bushing,
9207M68P03	BUSHING

Starfish PPS - Complete Catalog

Part Number	Description
9207M68P08	Bushing,
9207M68P13	BUSHING, FLANGED
9207M68P14	Bushing,
9207M68P15	BUSHING
9208M42P01	WASHER
9208M51P01	SEAL
9208M52P01	SEAL
9208M64G02	NUT
9208M77P01	Weight
9208M90P01	BOLT
9208M91P01	BOLT
9208M92P02	Bolt
9211M13P05	BOLT
9211M30P01	BOLT
9211M36P01	NUT
9211M36P02	NUT, SELF LOCKING
9211M38P01	NUT
9211M39G02	BUSHING, SHROUD
9212M79P06	PLUG
9215M47P08	SPACER, RING
9219M19P05	SHIM
922971	Filter, Cartridge, Replacement
92304	STUD
9232M90P18	NUT, ASSY, SELF LOCKING
9234M17P05	BOLT
9234M87P01	SEAL, METAL
925385	TRANSMITTER, PRESSURE
9257M84P04	Gasket
926010-1680	Pin
9263M70P02	CLEVIS
92655A412-M	Bolt, HH, 1/2"-13 x 2", Grade 8, Modified
92655A416-M	Bolt, HH, 1/2"-13 x 2-1/2", Grade 8, Modified
9272M68G01	BOLT
9283M23P01	Bushing
9293M73P172	Clamp
9294M61P03	GASKET
9294M61P04	Gasket
9294M61P05	GASKET
9294M61P07	GASKET
9294M61P18	Gasket
9299M11P02	GASKET
9299M96G06	Plug, Boroscope
9299M96G07	PLUG, BORESCOPE, HPT, STG1
9303M59G01	BRACKET
9303M65P01	Sensor, fan speed
9311M44P01	NUT
9311M45P01	NUT
9315M28P02	SCREW
9319100100	RELAY
9319500106	UNDERVOLTAGE RELAY
9324233	Hose

Starfish PPS - Complete Catalog

Part Number	Description
9329M26P01	Bolt, Borescope Plug; stg 10, 12, 13
9331M55P02	Ring, seal, blade retaining
933576Q	FILTER, HYDRAULIC
9349M73P02	Clevis, Actuation Compressor Stator
9352M41P10	Bushing
9354M40P01	Gasket
9354M40P02	Gasket
93552	ELECTRONIC SWITCH
9356M78P02	SEAL
9358M66P117	Strap, Ring
9358M66P29	STRAP, RETAINING
9358M66P33	Strap
9358M66P37	STRAP
936001-1003	GASKET, SPIRAL WOUND
936001-1005	GASKET, SPIRAL WOUND
9365M41P117	Gasket
9365M41P122	Gasket
9365M41P229	Gasket
9365M41P236	Seal
936600-1250	E-SEAL, RING
936600-1300	E-SEAL, RING
9371M19P04	Seal
9371M19P05	SEAL
9371M19P06	Seal
9371M19P08	Seal
9371M19P10	Seal
9371M19P12	Seal
9374M29G02-OH	Seal, Air, OVERHAULED
9378M31P01	Fitting
9378M31P01 - AR	FITTING
9379M41G05	SHROUD ASSY
9379M42G04	SHROUD ASSY- STAGE 2 VANE
9379M93P01	Gasket, Thermocouple
9384885	RING, PACKING
9385661	GAUGE, 4-1/2", 100 PSI
939-B1549-04	Valve, Check
9392M95P04	PLUG, IGNITER
9392M95P04SHIM	SHIM, IGNITER
9392M95P07	PLUG, IGNITER
9395M19P01	BOLT
9397M20P02	Adaptor
9397M22P02	Washer, Locking
940281	Starter
94121-001	THERMOSTAT
941NC-4350	CLAMP
942-2-12C	SENSOR, SPEED
9432E-825-T	V-Coupling, Voss
9441M54P02	Offset Wrench
9441M54P03	T Handle
9443141P0165	PIN, , ANCHOR, 3/8" DIA, 1" LTH, FERROUS METAL
9453M62P01	Tester, Air Flow, Lube System
9488M18G01	Toolkit, Engine Maintenance

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
95-115	ELEMENT GLO
95-117	Filter, Element
95-133	FILTER, OIL
95-310	Filter Element
9504M33P01	SENSOR, TEMPERATURE
952438D	BREAKER, CIRCUIT
9559M19P01	Seal, Fuel Nozzle Ring
9559M20G01	ASSEMBLY: SEAL, RING
9559M20G02	ASSEMBLY: SEAL, RING
955G1A4A3011C020	VALVE, CHECK
955G1B4A3	VALVE, CHECK
9566	Expansion Joint
957.09.05.1510	GENERATOR, SIGNAL, PRECISION
9571-17	VELOM/SEIS EXTENSION CABLE
9580706	KIT, GASKET, OVERSPEED TRIP
958405-12	Gasket
958405-28	Gasket, Seal-Flange
958406	Gasket, Seal-Flange
95L-124S	Air Pressure Regulator
9600M37P12	Cable, Power, Electric
9600M37P13	CABLE, IGNITER
9600M37P14	Ignition Lead
9600M37P15	Ignition Lead
9601M54G02	SHIM
9601M73P07	Seal
9602941-57	MAVR ASSEMBLY
9602M39P02	NUT, CHANNEL
9606M45P01	Sleeve Bushing
9607M05P08	PACKING
9607M05P21	O-RING
9607M05P26	Packing
9607M05P33	Packing
9607M05P34	Packing
9607M80P03	Ring, Keyed, Retaining
9608M08G16	Gasket
9608M08G43	Gasket
9608M08G44	Gasket
9608M08G45	Gasket
9608M08G46	Gasket
9608M08G47	Gasket
9608M08G48	GASKET
9608M08G51	GASKET, SQUARE
9608M08G52	GASKET, SQUARE
9608M08G53	Gasket
9608M08G54	Gasket
9608M08G55	Gasket
9608M12P02	Gasket
9608M12P04	Gasket
9608M80P03	RING, KEYED, RETAINING
9609M13P02	GUIDE, VSV
9609M43P01	Washer
9609M43P02	Washer

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
9609M43P03	Washer
9609M43P05	Washer
9609M88P04	Bushing
9610M50P01	NUT
9610M50P02	NUT, 12 PT
9610M50P03	Nut
9610M50P04	NUT
9610M50P05	Nut
9610M50P20	Nut
9610M50P21	Nut
9610M50P23	Nut
9610M50P27	Nut
9610M81P03	SCREW
961101MFA	VALVE, PRESSURE RELIEF
962609900	C10 Low Speed Detector
9627M01P01	Gasket
9627M01P02	Gasket
9627M62P02	Pin
9628M16P02	Bolt
9629M48P02	Nut, 6 PT
9629M48P03	Nut, 6 PT
9629M48P04	NUT, 6 PT
9629M48P06	Nut, 6 PT
9629M48P10	Nut, 6 PT
9629M62P02	GASKET
9629M79P116	Gasket
9629M79P16	GASKET
9629M79P20	Gasket
9629M79P28	GASKET
9629M83G02	Seal
9631M84P02	RING
9632M56P01	CLIP
9633M14G22	ARM
9634M42P03	SLEEVE
9634M85P01	RING, MATING
9634M85P06	Ring, Seal Mating
9643M56P01	Gasket
9643M56P02	Gasket
9643M84P02	Gasket
9644M72P03	NUT
9646M51P07	SLEEVE, ALIGNING
9649M39P02	Clamp, Coupling
9649M39P04	Clamp, Coupling
9649M39P05	Clamp, Coupling
9649M41P08	Bearing
965014322	A30 COMPLETE
9654M24P01	Washer
9655M01P04	Seal Ring
9655M01P07	Seal Ring
9655M01P10	Seal Ring
9655M01P12	Seal Ring
9655M01P13	Seal

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
9658M51P03	BEARING
9658M93P02	Seal
9661M72P02	PACKING
9661M98P01	Pin / Bolt
9662M67P01	Bolt
9662M72P06	BOLT
9662M72P10	BOLT
9663M71P07	Nut
9663M71P13	NUT
9664M68P01	Nut
9665M50P01	Bolt
9665M50P04	BOLT
9665M50P06	BOLT
9665M50P13	Bolt
9665M55P01	Bolt
967082	IND, DISCH, 3/4 POP-UP
9670M46P05	Gasket
9673M11P02	BUSHING
9673M11P04	BUSHING, FLANGED
9673M66G15	LEVER
9680M73G03	PLUG, BORESCOPE
9681M48P06	BUSHING
9682M50P06	GUIDE
9682M74P01	REDUCER
9686M65P01	NUT
9686M80P02	Plug, Borescope 9, 10, 11
9687M21P01	NUT, CHANNEL
9687M94P03	STRIP
9688M09P01	STRIP, OUTER
9688M11P01	Washer
9691M29P25	Actuator, VSV
9693M35P04	Seal
9693M35P08	Seal
9693M65P01	Screw
9693M68G04	SPACER, ACTUATION RING
9697M19P01	PLUG
9699M11P02	Bearing
9699M66P01	Bolt
9713M89P03	Cover
9713M89P12	Cover Plate
974A0953P007	Nut
974A827P006	Nut, Hex Head
9753CG	Contact Kit
9760X120	ASSEMBLY - ELEMENT - 120F
97619A440	Nut
982505	Scale, CO2
9877K818-100	Strainer
98HH	REGULATOR, FISHER
98HH-KIT	KIT, OVERHAUL
990-04-70-02-00	Vibration Transmitter
990-04-70-02-05	Vibration Transmitter
9902-072	Pump

Starfish PPS - Complete Catalog

Part Number	Description
9902-222	VALVE, SERVO
9902-332	CONTROLLER, VSV
9902-363	Actuator
9902-364	HYDRAULIC CONTROL UNIT
9902-364-AR	HYDRAULIC CONTROL UNIT
9902-364-OH	HYDRAULIC CONTROL UNIT
9902-369	Valve, servo
9902-398	PUMP
9902-398-AR	PUMP; AS REMOVED
9902-402	VALVE, SERVO
9902-404	VALVE, SERVO
9902-406	Control
9902-406-OH	CONTROLLER, VSV, OVERHAULED
9902-412	VALVE, SERVO
9902-414	VALVE, SERVO
9902-420	GAS STAGING VALVE
9902-420-AR	GAS STAGING VALVE, AS REMOVED
9902-420-OH	GAS STAGING VALVE - overhauled
9902-428	PUMP
9902-428-AR	PUMP, AS REMOVED
9902-441	ASSEMBLY: SERVO VALVE & PUMP
9902-458	PUMP, VSV
9902-458-OH	PUMP, OVERHAULED
9902-459	Servo and Pump, VSV
9902-461	ASSEMBLY: SERVO VALVE & PUMP
9902-469	ASSEMBLY: SERVO VALVE & PUMP
9902-471	ASSEMBLY: SERVO VALVE & PUMP
9902-480	Liquid Fuel Staging Valve
9902-700	ASSEMBLY: PUMP, VSV
9902-701	HYDRAULIC CONTROL UNIT
9904-1351	Actuator
9904-1759	Valve, Gas Fuel Control
9904-1875	Valve, Control
9904-1884	Gas Fuel Control Valve
9904-1892	Gas Fuel Control Valve
9904-1895	Gas Fuel Control Valve
9904-260-AR	PUMP
9904-263-OH	PUMP
9904-264	VALVE, SERVO, HYDRAULIC
9904-264-AR	VALVE, SERVO, HYDRAULIC - AS REMOVED
9904-264-OH	VALVE, SERVO, OVERHAULED
9904-3106	IGV Actuator
9904-506	Valve, 2 in
9904-507	Valve, 3 in
9904-516	VALVE, LSOV
9904-532	GSOV, Woodward
9904-534	GSOV
9904-540	Valve, 2 in
9904-541	Valve, 3 in
9904-549	VALVE, GSOV
9904-549-AR	VALVE, GSOV, AS REMOVED
9904-549-OH	VALVE, OVERHAULED

## Starfish PPS - Complete Catalog

Part Number	Description
9904-581	GSOV, Woodward
9904-769	Valve
9904-773	SRV,W/ 6 INCH FSHR VALVE, DUAL LVDT
9904-938	Valve
9905-1548	VALVE, GS6
9905-204	DSM Synchronizer Module
9905-285	Proportional Actuator
9905-285-AR	Proportional Actuator
9905-449	GSOV
9905-708	Digital Synchronizer and Load Control
9905-708-OH	DIGITAL SYNCHRONIZER, OVERHAULED
9905-760	RESISTOR, TERMINATING
9905-760-AR	RESISTOR, AS REMOVED
9905-964	Valve, Gas Shut Off
9905-968	Linknet, 6-Ch Analog Input 4-20 mA w/o 24 V Loop Power
9905-968-AR	MODULE, LINKNET, AS REMOVED
9905-968-OH	Overhauled Linknet, 6-Ch Analog Input 4-20 mA w/o 24 V Loop Power
9905-969	Linknet 6-Ch Analog Input 4-20 mA w/ 24 V Loop Power
9905-969-AR	MODULE, LINKNET, AS REMOVED
9905-970	Linknet Module, 6 CHannel, 100 ohm RTD
9905-970-AR	MODULE, LINKNET, AS REMOVED
9905-970-OH	Overhauled Linknet Module, 6 CHannel, 100 ohm RTD
9905-971	Linknet 16-Ch Discrete Input 24 Vdc
9905-971-AR	MODULE, LINKNET, AS REMOVED
9905-971-OH	Overhauled Linknet 16-Ch Discrete Input 24 Vdc
9905-972	Linknet, 6-Ch Analog Output 4-20 mA
9905-972-AR	MODULE, LINKNET, AS REMOVED
9905-973	LINKNET, MODULE, DISCRETE OUT
9905-973-AR	MODULE, LINKNET, AS REMOVED
9907-1142	VALVE, EGMV, 3"
9907-1143	Valve, Fuel, Metering
9907-1144	Valve, Metering
9907-1145	Water Injection Metering Valve
9907-1187	Woodward valve
9907-1187-AR	Woodward valve
9907-1196	MANIFOLD - 1000 PS
9907-1207	VALVE, GSOV, HIGH TEMP
9907-1231	VALVE, EWMV UNPLATED, 2"
9907-1233	Valve, USOV
9907-1233 AR	VALVE, USOV
9907-1233-OH	VALVE, USOV
9907-1264	VALVE, USOV, 3"
9907-135	DRIVER
9907-1456	Gas Fuel Metering (Primary) - VALVE - EGMV,3IN,RF600# CF8M,2.5ACD,NA-EU,-40TO380F,125VDC,SPRING,0,REM
9907-1457	Valve, Fuel, Metering
9907-1460	Water Injection Metering Valve
9907-1782	Valve
9907-186	Driver - GS10 Gas Valve UL/CSA
9907-207	Actuator, IGV
9907-2203	Pressure Transducer Assembly
9907-2328	Valve

## Starfish PPS - Complete Catalog

Part Number	Description
9907-2328-OH	Valve - Overhauled
9907-331	Transducer, DLE
9907-487	GSOV, Woodward
9907-487-OH	GSOV, WOODWARD, OVERHAULED
9907-487AR	GSOV, WOODWARD
9907-502	Gas Fuel Metering (Primary) - EGMV,3IN,RF600#,SS-CF8 EU,-40TO380F,125VDC,SPRING,0,REM
9907-503	Valve, Fuel, Metering
9907-504	Valve, Fuel, Liquid
9907-506	Water Injection Metering Valve
9907-526	Valve, Fuel, 2"
9907-526-AR	VALVE, FUEL, AS REMOVED
9907-526-OH	Fuel Valve 2" - Overhauled
9907-528	Woodward valve
9907-553	Gas Valve, GS16, Single Resolver
9907-559	Woodward GS6 valve
9907-561	VALVE, GS16
9907-572	Valve
9907-573	Valve, Woodward
9907-652	Valve, Control
9907-696	Valve, Control, LQ25
9907-861	GSOV HT
9907-862	EM/TM Resolver
9907-869	Valve, USOV
9907-869-AR	VALVE, USOV
9907-869-OH	VALVE, USOV
9907-870	Valve
9907-896	Valve
9907-954	Woodward GS6 valve
9907-960	Actuator
9907-962	TRANSMITTER, PRESSURE, 12-800 PSIA
9907-962-OH	TRANSMITTER, PRESSURE, 12-800 PSIA (3 port) - overh
9907-963	Transmitter
9907-963-OH	TRANSMITTER, OVERHAULED
9907-994	Valve, Control, LQ25
9907-995	VALVE, CONTROL, LQ25
9907-995-AR	VALVE, AS REMOVED
9907-995-OH	VALVE, OVERHAULED
9907-996	VALVE, LQ25
9907-996-AR	Valve, LQ25, AS REMOVED
9907-996-OH	Valve, LQ25 OVERHAULED
9908-024	Valve, Fuel, Liquid
9908-1501	Fuel Valve
9908-1502	VALVE, FUEL
9908-1532	Valve, Fuel
9908-1534	Valve
9908-1548	Woodward GS6 valve
9908-1548-AR	VALVE, GS6
9908-1548-OH	VALVE, GS6, OVERHAULED
9908-1549	Woodward GS6 valve
9908-1549-OH	Woodward GS6 valve
9908-1554	Fuel Metering Valve

Starfish PPS - Complete Catalog

Part Number	Description
9908-1555	Valve, Fuel
9908-1556	Woodward GS6 valve
9908-1556-OH	Overhauled Woodward GS6 valve
9908-1581	VALVE, FUEL
9908-1601	Valve
9908-1603	Gas Metering Valve
9908-1607	VALVE,GS50,2"/RF600#/SST/2.0ACD,125V,N0S
9908-1642	Gas Metering Valve
9908-1657	GS50 Fuel Metering Valve
9908-200	LQ25T
9908-201	Valve, Bypass, Liquid Fuel
9908-211	Valve
9908-216	Valve, Control, LQ25
9908-222	VALVE, Fuel
9908-224	VALVE, FUEL
9908-233	LQ25T
9908-234	VALVE-LQ25, 0.3 SQ INCH, PIV/SOV/24 VDC
9908-236	Valve, Fuel
9908-243	Fuel Valve
9908-265	Valve, Fuel Metering
9908-354	Valve, Shutoff
9908-376	ACTUATOR, EML100
9908-416	Valve, Fuel - LQ25 Liquid
9973	NOZZLE, FOG, AMMONIA
99807-0438	CLAMP
998367-17	Metal Gasket Ring, E Seal
998367-24	Gasket, Liquid Fuel Mix Block
9995	Assy, Pmt/Cooler?Reaction Chmb
99M-23-AVL	Level Gauge
99M75-23-AVL	Level Gauge
9A00402G01	PCA Solenoid/Heater
9F60BHH001	FUSE 15.5 KV
9F60CMJ905	Fuse
9F60FMH050	FUSE, 15.5KV
9RD0216	Flow Divider
9T11A1600	Transformer, Ignition
9T51B0171	TRANSFORMER
9T58B0055	TRANSFORMER, 60HZ
9T58K2803	Control Transformer
9T62Y4021	Transformer, Ignition
A	Transmitter
A-0745	O-Ring
A-1127	VALVE, PRESSURE MODULATION
A-18682	INDICATOR, CYCLE
A-3507	O-Ring
A-5374	Sight Glass
A0124	DISC, RUPTURE
A10 Flange	Flange
A1013353	Diaphragm Assembly
A1013357	Diaphragm Assembly

## Starfish PPS - Complete Catalog

Part Number	Description
A1013359	Kit, Guide Cage Assembly
A1013368	Kit, Guide & Springs for Diaphragm Assemblies
A1013370	Kit, Guide Cage Assembly
A1013372	Kit, Diaphragm Cove w/ Cover & Fitting
A1013376	Kit, Diaphragm Cove Includes Cover
A1013386	Kit, O-Ring Replacement
A146826	
A1B-0-AL-1-1	SWITCH, PRESSURE
A3X400-177L	Fuse
A4J35	FUSE, 35A
A4J6	FUSE, 6A
A4J70	FUSE, 70A
A50TF201	Anti-Seize, Graphite Paste
A5Y10-2	FUSE, 10A
A5Y15-2	FUSE, 15A
A5Y2-2	FUSE, 2A
A5Y20-2	FUSE, 20A
A5Y5-2	FUSE, 5A
A7601350 - A79A5679	Blower Wheel + Retainer
A7601350-A79A5679	Blower Wheel + Retainer
A804	FITTING, FIXTURE, END CAP, STEEL
A9 Flange	Flange
AA4VG125EP2D1/32R-NSF52F001PX-ES	PUMP, VG
AA4VG125ES7DM1/32R-NSF52F001PM-S	PUMP, VG
AA6VM107HA1	Hyd Start Motor
AA6VM107HA1/63W-VSD527A	MOTOR, STARTER
AA9227-1640D2A-BOWL	Filter Bowl
AA9500D102	Screw, Socket head, special fuel system
ABF-3/10-M-P12	Cap, Air Breather
ABSBDCM01-JEO800	VALVE, RELIEF
AC-B244F-2440	Filter Element
AC-B244F-2440Y1	VGW Filter Element
AC9227F1640	FILTER, ELEMENT
ACB24424D2Y	Filter Bowl
ACB244F2440	Filter Element
ACB244F2440Y1	VGW Filter Element
ACE038N3NVBP-A101	Oil Pump
ACE038N3NVBP-A413	Gen Lube Pump
ACE038N3NVBP-A413-OH	Oil Pump
ACE382NC101	Pump
ACETONE	
ACG045N7NVBP	Lube Pump
ACG045N7NVBP A101	Lube Pump, Counterclockwise
ACG045N7NVBP-OH	Lube Pump
ACS-3BF-13.63" X 4"	Element, Filter
ACS-3BF-13.63X4	Element, Filter
ACS580-01-124A-4	ABB Drive
ACS580-01-124A-4+B056	ABB Drive
AD-B244-24	FILTER ASSEMBLY
AD-B244-24-AR	FILTER ASSEMBLY - AS REMOVED
AE-229-110	ELEMENT, FILTER, Exhaust
AE3315788002	Solenoid Valve

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
AE5312957	PreFilter Panel
AF1530PW4V-140	Valve
AF24-SR	Belimo
AHPB22443H	Bearing
AI-PM3-3KT-L-SS	MONITOR, PRESSURE, 3000PSI
AIP015-0015-10	CONTROLLER
AIP100-0039-10	RESISTOR, .057 OHMS
AIP302-0004-10	DIODE, REDUNDANCY MDL
AIP490-0010-10	RELAY, 24VDC
AIP490-0037-10	RELAY, OVERLOAD
AL1269	Fuse 4 A
AL1308	Micro Fuse 31 mA
AL1310	Micro Fuse 100 mA
AL1328	Micro Fuse 2 A
AL1335	Micro Fuse 50 mA
AL8001440	Module, input, fire system
AL8001440D	Module, input, fire system
AL8001440DEV38	AL8001440DEV:38 DEVIATED MODULE
AL8001441	Manual Pull Module
AL8001442	Module, Alarm
AL8001442D36	Alarm Module (Horn & Strobe Driver) PSW
AL8001443-D	Digital Release Module
AL8001444	Fault Module
AL8001444D46	Fault Module (RU)
AL8001457	4-20 mA Gas Module
AL8001530-M	Master input mod. 2 Channel
AL8001530-S	Slave input mod. 2 Channel
AL8001537	Remote Relay Module
AL800169016	16-Slot Rack
AL8001760	MODULE, RELAY
AL8001800	Status Module
AL8001820	Release Module
AL8002800	Cycle release module
ALH_5747.2	ADAPTER, TERMINAL BLOCK
ALPA1-D-3-TR	Pump, Jacking
AMS330250	AMS 3302 Silicone Rubber Strip, 50 Duro, 0.015" thick x 7/8" long, Adhesive on one side
AN122705	PIN
AN122766	Pin
AN123469	RIVET
AN123470	RIVET, FLAT HEAD
AN123480	RIVET, FLAT HEAD
AN123620	RIVET, SOLID
AN123622	RIVET
AN123631	RIVET
AN316C4R	NUT
AN6230-3	Ring
AN763-24	Gasket
AN919-13	Fitting
AN960	TC harness, Top right LM5000
AN960C10	Washer
AN960C10L	Washer

Starfish PPS - Complete Catalog

Part Number	Description
AN960C1216	Washer
AN960C416	WASHER, FLAT
AN960C416L	Washer; 1/4
AN960C516	Washer; 5/16
AN960C516L	Washer; 5/16
AN960C616	Washer
AN960C616L	Washer; 3/8
AN960C816	Washer; 1/2
AN960C816L	Washer; 1/2
APD170148	GAUGE, PRESSURE, MAGNAHELIC
APEX8000X81247A0T	ACTUATOR, WITH NT3000 TRANSDUCER
AR 000N6	TUBE
ARC-178681	O-Ring
ARC-180246	O-Ring
ARC-180654	Sight Glass
ARC-185746	Seal
ARC-204278	Gasket, Cylinder Cover
ARD4L	Control Relay
ARD880SR	Control Relay
ARMTO-303E2T1XX	Reservoir Heater and Thermostat
ARW0001201021	Wedge 120 AISI 316
AS1001632	Fan Motor Mount & Adjustment Bolt Assembly, SERVICEA SURPLUS
AS151702	RTD, Casing
AS1895/1-150	Clamp, Coupling
AS1895/1-200	Clamp, Coupling
AS1895/1-225	Clamp, Coupling
AS1895/1-250	Clamp, Coupling
AS1895/1-250 - AR	FLANGE
AS1895/1-300	Clamp
AS1895/1-350	Clamp, Coupling
AS1895/1-400	Clamp
AS1895/1-400 - AR	CLAMP, COUPLING
AS1895/1-600	Clamp, Coupling
AS1895/23-125	Seal
AS1895/4-125	Clamp
AS1895/4-350	CLAMP
AS1895/7-150	E-SEAL, RING
AS1895/7-200	Coupling
AS1895/7-225	E-SEAL, RING
AS1895/7-250	E-SEAL, RING
AS1895/7-300	E-SEAL, RING
AS1895/7-350	E-SEAL, RING
AS1895/7-400	E-SEAL, RING
AS1895/7-600	E-SEAL, RING
AS3209-026	O-RING
AS3209-210	O-RING
AS3209-219	O-RING
AS3209-228	O-RING
AS3209-269	O-RING
AS3209-278	O-RING

Starfish PPS - Complete Catalog

Part Number	Description
AS3237-08	BOLT
AS3237-10	Bolt
AS3237-22	BOLT
AS3238-15	Bolt, machine, DBL hex .3125-24 by 1.375
AS3251-16	BOLT
AS3481-04	NUT
AS3485-09	Nut
AS3485-10	Nut
AS3485-11	Nut, 12 PT
AS3486-10	NUT
AS3510-0218K	Bergen Cables
AS3510-0224K	Bergen Cable; 24"
AS3510-2F	Lock wire termination Ferrule; -50 / magazine
AS3580-4-16	BOLT
AS3580-4-34	BOLT
AS4370J04	Nut, Swivel
AS5355/3-13B	V GROOVE COUPLING
AS5355/3-15B	CLAMP, V-BAND, RETAINER
AS5355/3-22B	Clamp
AS568-178	O-RING
AS568-267	O-RING
ASC-3BX4	FILTER
ASTUD3	RELAY, Time Delay & Timing
ATL-IRR-460-N3-BRKR-STD	Breaker - Starter
ATMR1-1/2	FUSE, 1 1/2A
ATMR2	FUSE, 2A
ATMR3	FUSE, 3A
AWK-4121-EU-T	ROUTER
Aeroshell 500	Turbine Lube Oil, Synthetic
Andritz Generator Filter Kit	Andritz Generator Filter Kit
B-01-H4663	Expansion Joint
B-01-H4663 - AR	GIMBAL EXPANSION JOINT
B057215	FITTING
B1548-03-16	VALVE
B1548-04-10	VALVE, CHECK
B1548-04-12	VALVE, CHECK
B200S10L	Pneumatic Actuator
B32686S7474K651	CAPACITOR .47UF 1200V for VSR100 / VSR175
B43584S9338M2	CAPACITOR 3300UF 400V VSR100 / VSR175
B461BXNH30#	SWITCH, PRESSURE
B52555RK099K001	Filter Replacement Kit
B700A09H20C	VALVE, , BOILER, TURBINE, 3-1/2"DIA, W/7-15/16"LG ST NON-ASBESTOS
B73-4B20-HM3	LIQUID LEVEL SWITCH
B750CJ850F1B20	Thermocouple,
B7953A	Cable, Cat 6
B984C302AP012	FILTER, HYDRAULIC
BA01B3T28E312	Accumulator
BA01B3T28E470	ACCUMULATOR, HYDRAULIC
BA01B3T28E470-AR	Accumulator, Hydraulic
BA01B3T28E470-OH	Accumulator, Hydraulic
BA01B3T28P1464	Hydraulic Accumulator

Starfish PPS - Complete Catalog

Part Number	Description
BA01B3T28P2	Hydraulic Accumulator
BA01B3T28X312	Accumulator
BA0403SKFO1A0284	ACCUMULATOR, HYDRAULIC
BB10	Brush, Carbon
BE12WH02	CABLE, MARK VI
BF020LWSD1BL	Valve, butterfly
BFA1281-13	SENSOR, FLAME, UV
BFL58GC-3	REPAIRED PCB FOR 75 MVA TRANSFORMER
BGSI-346	Igniter
BLP-100-3	SET: SLING, LIFT FIXTURE
BLP080719GLC	GLO Lube Pump Coupling w/ Flex Element
BLP082219PJH	HOSE, JACKING PUMP DISCHARGE
BLP7290ERJT	Generator Inspection Kit
BM323	Safety Cable Terminator
BM327	Safety Cable Terminator
BRAYCO 599	BRAYCO PRESERVATIVE - 8 oz Can
BRAYCO 599 - DRUM	55 Gallon Drum of Brayco 599 Preservative Oil
BRGIP215L	Bearing
BRGIP215LE	Bearing
BSP601	GENERATOR ENCLOSE FAN GUARD
BSP605	Turbine Enclosure Fan Guard
BTL7-E500-M0100-K-K05	Magnetostrictive linear position sensor
BTW71P 71-Segment TRI-COLOR Circular Array	GAUGE, RPM
BUVTRXXXY4M	GAUGE, RPM
BX-56-17	Belt, Cooler Motor
BX-70	Belt
BZ2R244P1	Honeywell Switch
C-29592	Fan, Turbine Enclosure
C-31109	Fan, Generator Enclosure
C-31471	Enclosure Fan
C-4779	BRUSH, CARBON
C-604165	Gasket, Fuel Nozzle, SEAL RING
C159462	Position Indicator Switch
C173255-5	Pressure Transducer
C236435-1	Staging Valve
C236435-AR	Liquid Fuel Staging Valve - AS REMOVED
C30513-1124-0300	MANIFOLD
C324890	GASKET
C324892	FLANGE, SPECIAL, CDP
C325021	FLANGE, SPECIAL, CDP
C325022	FLANGE, SPECIAL, CDP
C325032-1	SWITCH, CDP VALVE
C325032-2	SWITCH, CDP VALVE
C326381	Bellows Assembly
C327335	Valve, CDP
C327335-AR	VALVE, CDP
C327335-OH	VALVE, CDP
C327345	VALVE, CDP
C327345-OH	VALVE, CDP
C327405	Valve, CDP
C327405-OH	VALVE, CDP
C327875	GAS STAGING VALVE

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
C327875-1	GAS STAGING VALVE
C327875-4	Staging Valve
C327875-AR	VALVE, AS REMOVED
C327875-OH	VALVE, STAGING, OVERHAULED
C329635-C102	Valve, Fuel Metering
C3X01S	VALVE, 3-WAY
C422845-E2	2" Pilot Fuel Metering Valve
C423095-1	Valve
C423102-OH	VALVE, RELIEF, OVERHAULED
C423105-1	VALVE, RELIEF
C423105-1-AR	VALVE, RELIEF, AS REMOVED
C423115-2-AR	VALVE, AS REMOVED
C423115-4	VALVE, VENT
C423115-4-AR	VALVE, AS REMOVED
C423115-4-OH	VALVE, OVERHAULED
C423155-1	Valve, Drain, Manifold
C423675-1	VALVE
C424035-7	Valve, Bleed Air
C424035-8	Valve, Bleed Air
C424045-4	VALVE, BLEED AIR
C424045-4-AR	VALVE, BLEED AIR, AS REMOVED
C424045-4-OH	VALVE, BLEED AIR, OVERHAULED
C424065-7	Valve, Bleed Air
C520325-1	Valve, solenoid
C520325-1-AR	Valve, solenoid
C520325-1-OH	Valve, solenoid
C604165	Gasket, Fuel Nozzle, SEAL RING
C66070-001-OH	PUMP, SMEC, OVERHAULED
C74653-001	TRANSFORMER
CA21000-11-05-00-085-03-02	Vibration Element
CAP-3471	Seal Ring, Turbine Bellmouth
CAP3471	Seal Ring, Turbine Bellmouth
CBA28-800	Pads, Vibration Isolation
CC-DCN-DCDC-005	DECON with Solvancer, 5 gallon pail
CCLC00040000	PreFilter, 24"x24"x4", G4
CD5.241-L1	DC/DC CONVERTER, 92 W
CDP PURGE VALVE FLANGE KIT	CDP PURGE VALVE FLANGE KIT
CDP Pipe	3"dia, 5 1/2' length, SS, 321 SS Flanges (2)
CEP20820	Expansion Joint
CEP9566G001	Expansion Joint
CF-22592-023	Fan Wheel
CFSKIT-10002	Repair Kit
CFSKIT-11002	Thermo Valve, OVERHAUL KIT
CGB193 1/2" NPT	CABLE, FLAME SCANNER
CGI-1C	GASKET, SPIRAL WOUND
CGI-1D	GASKET, SPIRAL WOUND
CGI-1E	GASKET, SPIRAL WOUND
CGI-1F	GASKET, SPIRAL WOUND
CGI-1G	GASKET, SPIRAL WOUND
CGI-1H	GASKET, SPIRAL WOUND
CGI-1J	GASKET, SPIRAL WOUND
CGI-1L	GASKET, SPIRAL WOUND

## Starfish PPS - Complete Catalog

Part Number	Description
CGI-1N	GASKET, SPIRAL WOUND
CGI-1P	GASKET, SPIRAL WOUND
CGI-1Q	GASKET, SPIRAL WOUND
CGI-3D	GASKET, SPIRAL WOUND
CGI-3E	GASKET, SPIRAL WOUND
CGI-3F	GASKET, SPIRAL WOUND
CGI-3G	GASKET, SPIRAL WOUND
CGI-3H	GASKET, SPIRAL WOUND
CGI-3J	GASKET, SPIRAL WOUND
CGI-3L	GASKET, SPIRAL WOUND
CGI-3P	GASKET, SPIRAL WOUND
CGI-6F	Gasket, Spiral Wound
CGI-6G	GASKET, SPIRAL WOUND
CGI-6J	GASKET, SPIRAL WOUND
CGI-6L	GASKET, SPIRAL WOUND
CGI-6P	GASKET, SPIRAL WOUND
CGI-9D	GASKET, SPIRAL WOUND
CGI-9F	GASKET, SPIRAL WOUND
CGI-9G	GASKET, SPIRAL WOUND
CGI-9L	GASKET, SPIRAL WOUND
CGS4332316NE3B171L14D024	Valve
CGSS1A6C2R1X	SENSOR, GAS
CGSS1A6V2R1X	SENSOR, GAS
CGSS1C6C2R1X	SENSOR, GAS
CGSS1C6V2R1X	SENSOR, GAS
CH31963	Igniter, plug
CH31966-1	Igniter, HT
CH37140	Igniter
CH38039	Ignitor
CL-75M	MALL, IRON, CL, 3/4"
CLA3240A-X01	Coolant Heating System
CM-MPN-525	ABB Protection Relay
CM5006-01	CM Drain Kit with Hose
CMF025M313N2B2EZZZ	CORIOLIS METER, 1/4 INCH
CONTAINER	CAN, TRANSPORT, LM2500, UNIVERSAL
CPD PURGE VALVE FLANGE KIT	CDP PURGE VALVE FLANGE KIT
CPIN2.375"-EQ	Connecting Pin, 3/8" D, 23/8"L, 321SS
CPIN2.75"-EQ	Connecting Pin, 3/8" D, 23/4"L, 321SS
CPIN3.375"-EQ	Connecting Pin, 3/8" D, 33/8"L, 321SS
CPIN3.625"-EQ	Connecting Pin, 3/8" D, 35/8"L, 321SS
CPT5-95-5-SDO7032	TRANSFORMER, CONTROL POWER
CR05-2104	Filter Element
CR104PSG34B91A	Switch, 3 position, maintain
CR104PSK21A91L	Keyed Switch
CR104PXC1	Contact Block
CR104PXG49	INDICATING LAMP
CR104PXL07R	Lens, Indicator Light
CR120E01102	GENERAL PURPOSE INDUSTRIAL RELAY
CR123C184A	HEATER, PANEL MOUNTED OVERLOAD RELAY, NEMA 3
CR123F118C	HEATER, MOTOR STARTER, GE, NEMA SIZE 4
CR2940U203	Contact Block
CR2L-200	FUSE, SUPER RAPID, 200A

## Starfish PPS - Complete Catalog

Part Number	Description
CR2L-325	FUSE, SUPER RAPID, 325A
CR305E002AALH	CONTACTOR, CHILLER FAN MOTOR
CR305X100D	Aux Contact Kit
CR324CXCS	Overload Relay
CR324F310F	SIZE 4 3PH OVERLOAD RELAY NC
CR360L40302AAAA	CONTACTOR
CR463L20ANA	Contactora
CR487E6F2MJ4AAAAA	Breaker - Starter
CRN1S	PUMPSET, AMMONIA
CRN3-7	Pump/Motor Assembly
CS/006165F	Filter, Panel
CS51-100	CELL, CONDUCTIVITY
CS604LGH13	Filter Element
CSFR37K812R75B009	RESISTOR
CSG-3321-316-B660-S-XDBT4-D024	VERSA SOLENOID VALVE
CSG-3321-316-L14-XX-D024	Pneumatic Directional Valve
CSG-3321-316-L14-XXE-DO24	Valve, Solenoid
CSG-3321-316-ME-S-XDBT4-D024	VALVE, SOLENOID
CSG-3321-316-ME-U-XDBT4-D024	VALVE, SOLENOID
CSG-3321-316-XDBT9-44-D024	VALVE, 3-WAY, SST, 24VDC
CSK206(X)	Bearing
CT0093CE3D40000	Final Filter, Composite Cartridge
CT109804	Filter, Generator
CT112361-1	Hose Flex Duct 5.0-50
CT112508	Transducer, Pressure
CT112509	TRANSDUCER, PRESSURE
CT112510	Transducer, Pressure,12-18 PSIA
CT112558	Sensor
CT112599	DETECTOR, CHIP
CT112599-SP1	O-RING
CT112599-SP2	Valve
CT112751-1000	NUT, HEAVY HEX
CT112763-0800	GASKET, SPIRAL WOUND
CT112841-4610	Stud
CT112841-4650	Stud
CT112841-4650-3	Stud
CT113003	VALVE, CHECK
CT113009	Transducer, Pressure, 0-1500 PS1G
CT113015	Valve, Check, Steam, & Gas Fuel
CT113069	Valve, relief
CT113805	FILTER, HYDRAULIC PUMP
CT113863	VALVE, SOLENOID
CT114357	Transducer, Pressure, 0-100 PSIG
CT114358	TRANSDUCER, PRESSURE
CT114359	TRANSDUCER, PRESSURE
CT114361	TRANSDUCER, PRESSURE
CT115328-1	VALVE, PRESSURE SAFETY
CT115567-2	Transducer, Pressure, 0-50 PSIA
CT115594-SP1	FILTER, OIL MIST
CT115594-SP2	O RING, FILTER
CT116171	RTD, Dual
CT116295	Transducer, Pressure 0-10 PSID

## Starfish PPS - Complete Catalog

Part Number	Description
CT116346-1	Starter
CT116346-SP23	Seal, Starter Shaft
CT116346-SP24	Gasket, Plate Seal
CT116346-SP3	HOSE, CASE DRAIN
CT116529	RTD
CT116529-1	RTD
CT116560-1	Sensor
CT116567	Transducer, Pressure
CT116610-1	Pump, Vacuum, Assembly
CT116624-02	LS TC Harness
CT116624-03	RS TC Harness
CT116819-14	Transducer, Proximity
CT1169-46-1	O-RING
CT116911	Pump, Lube
CT116914	Pump, Lube
CT116937-5437-523	Module - Analog Field Term
CT116937-5437-672	Module, Netcon Field Term.
CT116937-5437-687	Module, Netcon 24 Channel Field
CT116937-5464-643	Woodward I/O
CT116937-5464-654	Module, D.O.64 Channel w/Watch
CT116937-5464-658	DIGITAL SPEED SENSOR
CT116937-5466-031	MODULE
CT116937-5466-258	MODULE, I/O
CT116937-5466-315	Module, High Density Analog I/O
CT116937-5466-316	Module, Analog Combination
CT116937-5466-353	Module, Main Transceiver
CT116937-5466-355	Transceiver
CT116937-5466-409	Micronet CPU
CT116937-5466-654	Discrete Out
CT116937-5466-658	Digital Speed
CT116937-5501-367	Module, Micronet Discrete FTM
CT116937-5501-371	Module, Micronet Simplex MPU & AIO FTM
CT116937-5501-376	Module, Analog, High Density, Simplex
CT116937-5501-432	Module, Actuator Netcon CONT.2C
CT116937-5501-465	Power Supply
CT116937-5503-267	Module, Netcon SIO
CT116937-5503-279	Board, Micronet HDVIM
CT116937-5503-282	Module, FTM HDVIM
CT116937-5566-258	High Density D. I/O
CT116937-5566-315	High Density A I/O
CT116937-9905-760	RESISTOR, TERMINATING
CT116937-9905-969	Linknet 6-Ch Analog Input 4-20 mA w/ 24 V Loop Power
CT116937-9905-970	Linknet Module, 6 Channel, 100 ohm RTD
CT116937-9905-971	Linknet 16-Ch Discrete Input 24 Vdc
CT116938-1	Filter, Fuel
CT116939-5437-845	Notch Filter
CT116946-1	O-RING
CT116946-2	O-RING
CT116946-3	Filter, Relieving
CT116946-4	Packing, Preformed
CT116999-1	Fuse
CT117004-28	Filter

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
CT117004-29	Filter
CT117004-35	Coupling, Hub
CT117004-36	Coupling, Element
CT117004-37	Coupling, Element
CT117004-44	FILTER
CT117004-45	FILTER
CT117007-02	RS EGT Harness
CT117007-03	LS EGT Harness
CT117015-215	Gasket (set of 2)
CT117015-286	Temperature Detector
CT117062-3	Filter Element
CT117088-1	WASHER
CT117101-16	Power Supply
CT117101-4	Transducer
CT117101-5	Transducer
CT117104	Clutch
CT117111	Harness, FT8, Engine, Left
CT117156	Valve, Gas Shut Off
CT117190-1	DETECTOR, CHIP
CT117190-4	DETECTOR, CHIP
CT117293	VALVE, SERVO, HYDRAULIC
CT117358	Valve, fuel
CT117358-1	Valve, fuel
CT117358-2	Valve, fuel
CT117369	Switch, Overspeed
CT117393	Actuator, TBalance
CT117419-2	Filter Element
CT117444-1	GSOV, Woodward
CT117444-2	Ring, Spacer, valve
CT117444-3	GASKET, SPIRAL WOUND
CT117444-4	Kit, Conversion
CT117445	Valve, Control
CT117452	Woodward Driver
CT117452-AR	WOODWARD DRIVER
CT117453	Woodward Driver
CT117462	Exchanger, heat
CT117542	Valve, Fuel
CT117688-1	Valve, Dump, Fuel
CT117718-1	POWER SUPPLY, IGNITER
CT117728-35	Panel, Fire
CT117728-50-1	Panel, Fire
CT117915-1	TRANSDUCER, DIFF, PRESSURE, LUBE SYS
CT117915-2	Transducer, DIFF, Pressure, FLT HSE
CT118017-1-23	Sensor
CT118017-2-10	Sensor
CT118017-2-20	Sensor
CT118025-11	Sensor
CT118025-12	Sensor
CT118025-17	Sensor
CT118032-1	Transmitter, Press
CT118032-12	Switch, Pressure
CT118032-19	Valve, Lube

Starfish PPS - Complete Catalog

Part Number	Description
CT118032-2	Gauge, Differential Pressure
CT118032-20	Valve, check
CT118032-26	Pump, L.O., DC Motor Driven
CT118032-28	Filter, L.O. Duplex
CT118032-29	Valve, Temp
CT118032-41	Element, L.O. Duplex Filter
CT118032-42	Element, Oil Mist
CT118032-43	Element, Oil Mist
CT118032-44	Valve
CT118032-45	Heater
CT118032-47	Oil Mist Eliminator
CT118032-5	Transmitter, Press
CT118032-50	Element
CT118032-6	Indicator, Temperature
CT118032-8	Switch, Level Alarm
CT118032-9	Switch, Level trip
CT118044-1	Transmitter, Pressure
CT118090-5466-1000	Power Supply, Micronet
CT118090-5466-1035	CPU, MICRONET
CT118090-5466-1036	WOODWARD, MICRONET+
CT118090-5503-335	CPU, Motorola 5200, Micronet Plus
CT118117-8	Filter
CT118161	Valve, Control, LQ25
CT118162	Valve, Shutoff
CT118164-1	Motor
CT118700-1-1	Thermocouple, Immersion, EGT, FT8
CT119176-01	Harness, FT8, EGT, Left
CT119176-02	Harness, FT8, EGT, Right
CT119176-03	Harness, FT8, EGT, Left
CT119176-04	EGT Kit, Bracket, Adapter
CT119176-05	EGT KIT, CABLE
CTL500L-58	LUG, COMPRESSION, COPPER
CTX10A3N2T	Combustible Gas Transmitter
CVHG12Y11S	Valve, Check
CVHG12Y31S	VALVE, CHECK
CVHG16Y41S	Valve, Check
CVHG6Y41S	VALVE, CHECK, GAS PURGE
CVHG6Y71S	valve, check
CXF230P231	Screwplug Heater 240V 3000W
CXH-A-03S-436-32-40-20-CE	Heater
CXH-A-05-43-32-00-20-EP	Chromalox 5 KW Heater
CXH-A-05-43-32-40-20-EP	Heater
CXH-A-10S-436-32-40-20-CE	HEATER
CXH-A-20M-335-32-40-20-CE	HEATER
Conntect 6000	Turbine Cleaner, 55 Gallon Drum
D1VW020BVYCF	Valve, Control
D3W030BVYC51XB826	VALVE, SOLENOID
D40240802R322TC	Sol Valve, GSR
D40250802R322TC	Sol Valve, GSR
D5217771G005	Fuel Nozzle Tip
DBV10-E10-F0320	PRV, MLO

Part Number	Description
DC-3T-60K3-0000	WATLOW POWER CONTROLLER
DCM373T075CD2B	Capacitor
DCP-AO-01-2"	Hose Assembly
DCT24-25-A643	BATTERY CHARGER
DECS-250	Digital Excitation Control System
DF 0320	HOUSING, FILTER
DF-0320-MK	Filter Assembly
DF200R12KE3	IGBT DF200R12KE3 VSR100 / VSR175
DISCARD	DISCARD
DM639-00-C	Element
DM812-00-C	Demister Lube Oil Filter
DM830-00-C	Filter
DM839-00-C	Filter, Element
DMSCK-85	GAS, CALIBRATION
DOLLY PARTS	MISC DOLLY PARTS
DPI 611	Pressure Calibrator
DPI610E-SPC	Druck Calibrator
DPST-NC	RELAY, FINDER, MODULAR CONTACTOR
DPST-NO	RELAY, FINDER, MODULAR CONTACTOR
DRV15-45-9	RVDT
DS200ACNAG1A	CARD, ARCNET
DS200BDAAG1A	BOARD, SNUBBER
DS200CDBAG1B	BOARD, CONTACTOR DRIVER
DS200CPCAG1A	CARD, PILOT CONTRACTOR, CPCA
DS200DTBAG1A	BOARD, DIGITAL, CONTACT INPUT, TEAM
DS200DTBBG1A	BOARD, TERMINAL, DTBB INPUT, DIGITAL INPUT
DS200DTBCG1A	BOARD, TERMINAL, DTBC, RELAY SOLENOID
DS200DTBDG1A	BOARD, TERMINAL, DTBD, RELAY SOLENOID
DS200EXPSG1A	CARD, POWER SUPPLY, EXPS
DS200GDPAG1A	BOARD
DS200LPPAG1A	CARD, LINE PROTECTION, LPPA
DS200PCCAG1A	CARD, DC2000 POWER CONNECTOR
DS200PCCAG6A	CARD, DC2000 POWER CONNECTOR, PCCA
DS200PTBAG1A	CARD, TERMINAL, PTBA MODULE
DS200PTBAG1B	BOARD, TERMINAL, PTBA MODULE
DS200PTCTG1A	BOARD, SIGNAL CONDITION, EX2000, PTCT
DS200PTCTG1B	EX2000, Signal Conditioner Card
DS200QTBAG1A	BOARD, TERMINAL, QTBA MODULE
DS200RTBAG1A	CARD, RELAY, RTBA
DS200SDCCG1A	CARD, DRIVE CONTROL, SDCC
DS200SHVMG1A	CARD, SCR HIGH VOLTAGE, SHVM
DS200SLCCG1A	CARD, LAN COMM., SLCC
DS200SNPAH1A	MODULE
DS200TBCAG1A	BOARD, TERMINAL, TBCA, ANALOG SIGNAL
DS200TBQAG1A	BOARD, TERMINAL, TBQA, RST, TC, S16
DS200TBQBG1A	BOARD, TERMINAL, TB0Q, RST ANALOG, SI
DS200TBQCG1A	BOARD, TERMINAL, TB0B, RST, ANALOG SI
DS200TBQCG2A	Analog I/O Terminal Board
DS200TCCAG1B	MKV, Common Analog Card
DS200TCCBG3B	CARD, EXPANSION ANALOG, I/O, TC2000, TCCB
DS200TCDAG1B	BOARD, DIGITAL I/O

Starfish PPS - Complete Catalog

Part Number	Description
DS200TCDAH1B	BOARD, DIGITAL I/O, COAT, TCDA
DS200TCEAG1B	BOARD, EMERGENCY OVERSPEED
DS200TCEAG2B	Emergency Overspeed Card
DS200TCEBG1B	BOARD, COMMON CIRCUITS EOS, TCEB
DS200TCPDG1B	MODULE, POWER DISTRIBUTION, TCPD
DS200TCPSG1A	MKV, DC Input Power Supply Card
DS200TCQBG1B	BOARD, RST, EXTENDED ANALOG, TCQB
DS200TCQCG1B	BOARD, RST, OVERFLOW, TCQC
DS200TCRAG1A	BOARD, RELAY OUTPUT, TCRA
DS200TCTSG1A	BOARD, ST/TRM/SIMPLEX TRIP MODULE
DS200XDSAG1A	GP SENSOR, I/O FUEL CONTROL
DS2020DACAG2	Power Module
DS215DMCBG1A	CARD, DMCBG1A AND FW
DS215DMCBG1AZZ03A	CARD, DMCBG1A AND FW
DS215KLDCG1A	CARD, KLDCG1 AND FW
DS215KLDCG1AZZ03A	CARD, KLDCG1 AND FW
DS303A2A01FX1010	CONTACTOR,DC, 50A, FOR LM6000
DS303A2A01FXA003XF	CONTACTOR, DC
DS303A2A01FXA010	CONTACTOR, DC, 50A, 600V
DS3800NDAC	Analog Output Card
DS3800NGDC	MODULE, GROUND DETECTOR, EX2000, OSCILSCOPE
DS3800NGDD	MODULE, FIELD GROUND DETECTOR, EX2000
DS3820ACSA	AC Source Selector
DS3820ACSA/RM	AC Source Selector
DS3820PS1B	POWER SUPPLY
DSIV1-250	Kit, Door Seal Replacement
DSOV1-250	Kit, Door Seal Replacement
DTE, Light, Mobil	Hydraulic Oil
DV1350L-32S-P	Transfer Valve
DY025-DBLBA1-2D/KF2/SCT	FLOW METER,VORTEX
DY025-DBMBA1-2D/FF1/SCT	Meter, Flow
DY025-DBMBA1-2D/KF2/SCT	DIGITAL VORTEX FLOW METER, 25MM/1"
DYC-1-4F	CABLE, YOKOGAWA
Delivery	Hot Shot
Dolly Stanchion	LMS 100, LM 6000 Dolly Stanchion
Dolly, LM2500	LM2500 Air Ride Dolly
Dolly, LM6000	Air Ride Dolly for LM600
E-800128-400	E-SEAL, RING
E-A-PS-USB/DB9	Cable, Adapter. Serial to USB
E-BM-AS-PS-01H	Hydraulic Starter Driver
E-BM-AS-PS-01H/A	Valve Controller
E-C-PS-DB9/RJ45	Cable
E024-150-4DG30	BATTERY CHARGER, 24VDC, 150 AMP, 230
E1A2549131	1.5" VALVE
E1A2564145/	ASHCROFT BIMETAL THERMOMETER MODEL A
E604Y200	Filter, Element
EA2-TX-AAA	Dew Point Transmitter
EA3-B0-26-620-1DA-EB	Breaker
EAU2-008	EASYchange Universal Adapter - Double, Threaded

Starfish PPS - Complete Catalog

Part Number	Description
EBZ-241601-400	Brush, Carbon
EC600-24-24FH-24FHB-0053.00-PT	Hose, Assembly, Kit, Interconnect 2
ECD15	DRAIN, CONDUIT BREATHER
ED101EK0000SF00	Filter, Inlet Air
EDSC2130	SWITCH, SNAP, 3 WAY, 3/4"
EDSC271	BODY, CONTROL ASSEMBLY
EDSF23WQ	SWITCH, SNAP
EFHC8321G001	Solenoid
EFHT8210G34	VALVE, SOLENOID, RED-HAT
EG1033AA01	AMPLIFIER, FLAME
EG1033AC01	Flame Detector
EG133AA010	AMPLIFIER, FLAME
EG9599	Brush, Carbon
EJA310-DAS4B-92NC/HAC	Pressure transmitter
EJA310A-DAS4B-92NN/FF1/HAC/D1	TRANSMITTER, INLET PRESSURE
EJX310A-JAS4G-912ND/FF1/D1	Pressure Transmitter
EKLN25	Pump, Fog
EL900-A-C-1-A	CONVERTER, MEDIA, ETHERNET COPPER TO FIBER
EMG1	GUARD, SMALL, EM SERIES
EMI15	FIXTURE, INCANDESCENT, EMI SERIES
EN 13190	ASHCROFT BIMETAL THERMOMETER MODEL A
EN0027	AT10 Auxilary Relay Alarm Board
EN13190	GAUGE, TEMP, STAMI
EN5012-00	Hindlepower
ENHCPASSY	Core Processor
EP-125F	Module, RSTi-EP Digital Input, 16 Points, Positive Logic, 24VDC, RSTi-EP 1
EP-225F	Module
EP-3264	Module
EP-3704	Module
EP-3804	Module
EP-4264	Module
EP-5261	Module
EP-711F	Module
EP-750F	Module
EPETD-8D	THERMOSTAT
EPXPNS001	NETWORK ADAPTER
EQ2253DCUEX	DETECTOR, GAS TRANSMITTER
EQ3016DNNW	Controller
EQ3730DW	MODULE, EDIO
ERC384S2DA-1	Filter Element
ESG3180A03	SPARK ARRESTOR
ET-9MS-2SC	Switch, Ethernet, 8 Port
ET-GT-9ES-1-AR	SWITCH, AS REMOVED
ET450	Circuit breaker finder
EX619M01/-002-03	ACCELEROMETER, CRF
EX619M01/004	ACCELEROMETER, CRF
EZ-6-76817	Exhaust Collector Drain Flow Control Valve
EZBA-001	Brush Box
EZBA-018	Brush Box
EZCA-003	Brush Removal Tool
EZMA-005	EASYchange Copper Lower Mount Assembly

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
EZMK-001	EASYchange System Maintenance Kit for 1.5" x 1" Holders
EZSA-004-150	Brush, Height Setting Rigging
EZX2	ASSEMBLY, CEILING MOUNT, 3/4"
F-S20B-150P-002	Valve, Transfer
F-S20B-150P-002-REPAIRKIT	Rebuild Kit for Transfer Valve
F-S20E-150T-001	Valve, Transfer
F1000	Fiberoptic Cleaning Wipes
F1001-224	O-RING
F13000006-0224	Hose Assembly
F13000008-0204	Hose Assembly
F13000016Z-0263	HOSE
F13000016Z-0320	HOSE
F13000104-0220	HOSE
F13000108-1230	HOSE, LUBE
F13000210-0485	HOSE
F130102E0726-180	HOSE
F130202E0230-180	Tube
F1319276	Seal Kit
F16-50-BN	Element Kit, Filter
F18000104-0220	HOSE
F18000204-0472	Hose Assembly
F1JSSFS.125SS	VALVE, CHECK
F1JSSMT.500SS	VALVE, CHECK
F1JSSTF1.50SS	Check Valve
F1JSSVT.500SS	VALVE, CHECK
F1JSSVT1.50SS	VALVE, CHECK
F1KSSMT.500SS	VALVE, CHECK
F1KSSVT.125SS	Valve, Check
F1KSSVT.500SS	Valve, Check
F1NSSVT.500SS	Valve, Check
F1PSSVT.500SS	Valve, Check
F30B50	Lock wire termination Ferrule; -50 / magazine
F3RG-03-B1-22	VALVE, SEQUENCE, CONTROL
F4B-E-207R TYPE E-XTRA	Bearing, TYPE"E" Size 2 7/16" Diameter
FA1763-1	Woodward
FA230IG	Filter, Ingersoll Rand
FB-811-15	Gasket
FB-A008X	FILLER, BREATHER ASSEMBLY
FD200R12KE3	IGBT FD200R12KE3 VSR100 / VSR175
FD45-1064-12-12	COUPLING, QUICK DISCO
FE150-CS-UIR	Check valve
FF14GG50V32P	FUSE-LINK, 32A 500V
FF6672	Arrester, Flame
FFB1224HH-F00	Fan, Chassis
FFF14010	NUT
FKHW04V6-ALABY-YL	Pressure Transmitter
FKKW12V1-AHABTT-AE	Pressure Transmitter
FKPW04V1AHABY0Y	Pressure Transmitter
FLEX-CGI-4-300-304	4 IN 300 PSI 304 SS CGI FG
FLEX-CGI-4-300-316	4 IN 300 PSI 316 SS CGI FG
FLT93F-1B1A203C4A03000	Flow Switch

## Starfish PPS - Complete Catalog

Part Number	Description
FLT93S	SWITCH, FLOW
FR22GG69V32P	FUSE, FAST ACTING, 22X58MM, 690V, 32A
FS-67CFR-239	REGULATOR
FS1301F-3/B2/T4/SC2	REGULATOR
FS1301F-3/B2/T4/SC2 Rebuild Kit	Rebuild Kit for Fisher 1301F Regulator
FS15B150P-001	Valve, Transfer
FS19573	FILTER, WATER SEPERATOR
FS19838	FILTER, WATER SEPERATOR
FS20B150P-002	Valve, Transfer
FS20E150T-001	Valve, Transfer
FS21770-320-99	EM Filter
FS67CFR-239	Air Pressure Regulator
FSA-127-1.1	Thermometer - panel mound, hydac
FT-060E-150P-03	Transfer Valve
FT-060E-150T-XX	Transfer Valve
FT-12NEXW-LEG-5	Flow Meter
FT-16NENW-LED-5	FLOW METER
FT-16NEXB-LEA5X	METER, FLOW
FT-16NEXWRLEG5X	METER, FLOW
FT20C3XBLEA-5005	Flow Meter - Fuel
FT24C3XWRLEG5	Flow Meter - Nox Water
FW05501D	Seal
G043.006331.010.009.010	Solenoid Valve
G24-R0001	GLOBE, LIGHT FIXTURE, 200 WATT
G251	GLOBE, GLASS
G3194-001	KIT: FILTER, SERVO, LPC-IGV
G3DHS-187	Pump
G408-0001	Slim Pak
G408-5004	SLIM PAK
G572026G153	Air Conditioner
G771K202	Servo Valve
G771K202A	Servo Valve
G771K203A	Valve, Servo
G771K227A	Valve, Servo
G771K615A	VALVE
G772K241A	Valve, Servo
G772K620A	Valve, Servo
GCA3830K03V	ELEMENT, FILTER, COALESCER
GD-B1516-51SL-08	RECEPTACLE, ATTACHMENT
GDC-3.15A	Fuse
GE-600-2	LUG
GE-CTF-349	Toolkit, Engine Maintenance
GE138T7714P0001	Valve
GEA120321SP-FF03	Filter, Inlet Air
GEH 35 ES-2RS	Spherical Bearing
GEJOTO13MM	Hose
GEJOTO16FM	Hose
GEJOTO26	Hose
GFS38152	SCREW
GFV15076	SCREW
GP460	Anti-Seize, Graphite Paste
GQF19044	Screw

## Starfish PPS - Complete Catalog

Part Number	Description
GS169539	CABLE, ACCELEROMETER
GSER501375P0027	Sensor, CASE EXPANSION TRANSDUCER - DC LVDT
GSOV-HT-Kit	Kit, Conversion
GT-32	Turbine Lube Oil
GT30-N	DETECTOR, FLAME
GTH12031	1/2-13 X 1 1/4 422 SS HEX
GTHW07077	SPARE PART FOR GTG CONTROL PANEL, IHI PACKAGE
GTJ19044	SCREW
Gasket, Enclosure	Kit, Door Seal Replacement
H1	Hose
H2	Hose
H201Ti-CE-X1-V1-VC0-H1-L1-F0	Gas Monitor
H8650SKZ	Seal Kit
H8940SKZ	Seal Kit
H8F8-SS	FEMALE PLUG
H9600SKZ	Seal Kit
HAND SANITIZER	
HAT 800-S	Transformer, Current - VSR100 / VSR175
HC2288FAS8Z	Filter, Element, Sprint
HC2288FCS8Z	Filter, Element, Sprint
HC2288FMS8Z	Filter, Element, Sprint
HC2288FRS8Z	Filter, Element, Sprint
HC2289FAS28Z	Filter, Element
HC2289FMS28Z	Filter, Element
HC645-01-C	Filter
HC8300FCS39Z	Filter
HC8300FKS39Z	Filter
HC8300FMT30ZYGE	Filter
HC8900FAN39Z	GLO Filter
HC8900FCN39Z	GLO Filter
HC8900FKN26Z	Filter Element
HC8900FKN39Z	GLO Filter
HC8900FRN26Z	Filter Element
HC8900FRN39Z	GLO FILTER
HC8904FAN13Z	Filter
HC8904FAS13Z	Filter, Element
HC8904FCS13Z	Filter, Element
HC8904FKN13Z	Filter
HC8904FKS13Z	Filter, Element
HC8904FRN13Z	Filter Element
HC8904FRS13Z	Filter, Element
HC9020FCT4Z	FILTER, HYDRAULIC PUMP
HC9021FDP4Z	FILTER, HYDRAULIC
HC9021FHT4Z	Filter Element
HC9021FHT8Z	Filter
HC9600FAN13Z	Filter, Element
HC9600FCN13Z	Filter, Element
HC9600FCS8Z	Filter
HC9600FKD13Z	FILTER
HC9600FKN13Z	Filter, Element
HC9600FRN13Z	Filter, Element
HC9600FRN8Z	Filter Element

Starfish PPS - Complete Catalog

Part Number	Description
HC9600FRS13Z	Element, Filter
HC9600FRS8Z	Filter
HC9600FTP8Z	Oil Filter
HC9600FTS8Z	Filter Element
HC9601FCP16Z	Filter
HC9601FHT13Z	Filter
HC9604FAN13H	Filter Element
HC9604FAN13Z	Filter Element
HC9604FKN13Z	Filter Element
HC9604FKS13Z	FILTER
HC9604FRN13H	Filter Element
HC9604FRN13Z	Filter Element
HC9604FRS13Z	Filter Element
HC9606FAN13H	Element, Filter
HC9606FHN13Z	Element, Filter
HC9606FHS8Z	ELEMENT, FILTER
HC9801FAT8Z	FILTER, PALL
HD-2338-13	O-RING
HDA-478G-F21-00200-DV-001	TRANSMITTER, PRESSURE
HE670RLY168C	Relay Output Module
HE693THM166	Horner Electric TC card
HE697RTM701	Comms Module
HEH06019	SCREW
HF1016414	Fan Assembly
HF9-24-8-G	FILTER, AIR
HFR1124/50M	CONVERTER
HFU660UY100J	Filter Element
HG1262921	Filter, Oil Cooler
HG1262993	Starter Skid Filter Element
HG6439HSBV	Filter, Fuel
HG6439HSCV	Fuel Filter
HG6439HSDV	Filter, Fuel Forwarding
HGA11J70	Aux Relay
HGA11S56	Hinged Armature Relay
HGA17C61	Auxiliary Relay
HHI150-18-445TD	Motor
HL4-1-8	LUG, GROUNDING
HL8-1A-P	LUG, GROUNDING
HM51650	LP Servo Filter
HMC735-1	O-RING
HMI	Innova HMI LM 6000 MARK VI
HMK25-04	Filter, Element
HO11/2X11/2-5-100-CB-1M(X-ATEX)E2-F9SS-PED-CE-EXP-DF2	TRANSMITTER, FLOW
HO99H018	PUMP, STARTER
HOKE 316	FITTINGS
HP102L18-12MB	Mineral Oil Filter
HP89L39-6MV	GLO Filter
HPK0300B0802NX	FILTER HOUSING
HPQ210076SL14-25MV	Filter
HRT1-3A-M-W-5-X-X-CE	FLOW CONVERTER
HS-AC010-U060	Accelerometer cable assembly

Starfish PPS - Complete Catalog

Part Number	Description
HS-AC335-U060	Accelerometer Cable
HS-ICE-012-SS	Enclosure
HS150-I-100-50-02	Accelerometer
HS173-I-100-54-02	Accelerometer
HTGD280160P0001	Diaphragm, Relief
HU02600148	FILTER
HU09157926	Filter Element
HU09157956	FILTER
HV272241001	Valve, Solenoid
HV2722411	Valve, Solenoid
HX-580158	Heater, Strip
HZ0937032KSTWBQ17	Duplex Filter Housing
HZ3142J04KNXWPTYN95	Filter Housing
HZ8640A20KNTS00001	Filter Housing, HZ8640A20KNTWPTY302
HZ8640A20KNTWPTY302	Filter Housing
HZ8640A20MNTWPT-Y302	Filter Assembly, Turbine Lube Oil
HZ8640A20RNTWPTY302	Filter Housing
HZ8640SK	Kit, Seal
HZ8670	Seal Kit
IC-101-M3-480-70-E-W	Three Phase Master (M3) 70A Control
IC-101-S3-480-70-W	Three Phase Slave (S3) 70A Control
IC200ACC200	VERSAMAX, EMPTY FILLER MODULE
IC200ALG240	Analog Input
IC200ALG264	
	ANALOG INPUT 15 CHANNELS
IC200ALG331	Versamax
IC200ALG430	ANALOG, MIXED, 12 BIT
IC200ALG620	Analog Input
IC200CBL002A	F/W Upgrade Cable
IC200CBL110C	CABLE, FANUC
IC200CHS002	CARRIER, I/O, BOX STYLE
IC200CHS003	I/O CARRIER
IC200CHS022	Compact I/O Carrier
IC200CHS022L	CARRIER, I/O
IC200CPUE05	CPU, Versa Max
IC200GBI001	Genius Network Interface
IC200MDL640	Module, Input
IC200MDL650	DISCRETE INPUT MODULE, VERSAMAX 32 POINT, 24V
IC200MDL741	DISCRETE OUTPUT MODULE 16 CHANNEL 24VDC
IC200MDL750	Versamax
IC200MDL940	VersaMax, Module
IC200PBI001	-
IC200PNS001	VERSAMAX PROFINET SCANNER
IC200PWB001	CARRIER, POWER SUPPLY BOOSTER
IC200PWR001A	Versamax Module
IC200PWR002	Power Supply
IC200PWR01	POWER SUPPLY, ISOLATED, 24 VDC, 11 W
IC200PWR012	POWER SUPPLY, ISOLATED, 24V, 11W
IC200TBM002	CARRIER, I/O
IC200UDR164	MICRO CONTROLLER
IC200UEX626	Power Supply
IC3600KVSA1E	CARD, ZERO SPEED

Starfish PPS - Complete Catalog

Part Number	Description
IC3600LINA1D1B	IC Card
IC3600LRDH1	Relay Driver Board
IC3600LRDJ1	Relay Driver Board
IC3600SFKA1B	Card, Fuel Splitter
IC3600SSLD1	Setpoint Control
IC3600SSZA1	Card, Droop
IC3600STDC1	Time Delay Card
IC3600STKH1A	Temperature Control Card
IC610CPU105C	CPU Module
IC660BBA020	GE FANUC; I/O ANALOG MODULE, AS REMOVED
IC660BBA020-AR	GE FANUC; RTD, 6 CHANNEL MODULE, AS REMOVED
IC660BBA021	GE FANUC; THERMOCOUPLE BLOCK
IC660BBA021-AR	GE FANUC; INPUT BLOCK, SRC
IC660BBA023	GE FANUC; 16 PT SOURCE BLOCK
IC660BBA026	GE FANUC; 32 PT SOURCE BLOCK
IC660BBD022	Analog Input, Current, 8 Channel, Grouped
IC660BBD024	Analog Input, Current, 16 Channel
IC670ALG230	Analog Output, Current, 8 Channel
IC670ALG240	RTD Module
IC670ALG330	RTD Module
IC670ALG620	I/O Term Block, 2 Tier
IC670ALG621	I/O Term Block, 2 Tier
IC670CHS002E	I/O Term Block, 2 Tier
IC670CHS102	Interface Module Bus Field Control
IC670CHS102A	Logic Fast Input, 16 Point, Grouped
IC670GBI002	Logic Output, 16 Point, Grouped
IC670MDL644	AUX. TERMINAL
IC670MDL740	BATTERY
IC670TBM002C	MODULE, AUXILIARY BATTERY, OUTPUT 3VDC 15AH
IC693ACC301	Communication Cable for RX3i CPE305
IC693ACC302	GE FANUC COMM CONTROL MODULE
IC693CBL316	GE Fanuc CPU
IC693CMM311	PLC Device Net Controller Card
IC693CPU374	GE FANUC INPUT
IC693DNM200	DISCRETE INPUT MODULE TO FREQUENCY CONVERT
IC693MDL241	Input Module
IC693MDL645	Output Module
IC693MDL646	POWER SUPPLY IC 693 PWR 322 TO FREQUENCY COM
IC693MDL740	POWER SUPPLY, 120/240VAC 30W
IC693PWR322	MODULE, RX3i, BLANK SLOT FILLER, BLUE
IC693PWR330	MODULE, RX3i PACSYSTEM
IC694ACC310	MODULE, ANALOG OUTPUT
IC694ALG223	MODULE, DISCRETE INPUT
IC694ALG392	MODULE, DISCRETE INPUT
IC694MDL240	
IC694MDL645	

Part Number	Description
IC694MDL655	RX3i PacSystem
IC694MDL660	MODULE, DIGITAL INPUT
IC694MDL930	MODULE, RELAY OUTPUT
IC694MDL940	MODULE, RELAY
IC694TBB132	Module
IC695ACC302	BATTERY, LITHIUM SMART
IC695ALG508	MODULE, ISOLATED RTD INPUT for RX3i PacSystem
IC695ALG600	MODULE, ANALOG INPUT, UNIVERSAL
IC695ALG708	MODULE, ANALOG OUTPUT, 8CH
IC695ALG808	MODULE, ANALOG OUT; 8 CH
IC695CHS012	PLC RACK, RX3i, 12 SLOT
IC695CHS016	BACKPLANE, UNIVERSAL, RX3i, 16-SLOT
IC695CMM002	SERIAL COMMUNICATION MODULE, RX3i, 2 PORTS
IC695CPE305	RX3i PacSystem - CPU
IC695CPE310	RX3i PacSystem
IC695CPE330	RX3i PacSystem
IC695CPU310	RX3i PacSystem
IC695CRU320	CPU, RX3i, 1000MHz CELERON-M REDUNDANCY CPU
IC695ETM001	ETHERNET MODULE, 10/100MBITS
IC695MDL664	RX3i PacSystem
IC695NIU001	GE RX3i NIU with two serial ports
IC695PNC001	PROFINET CONTROLLER
IC695PSA140	POWER SUPPLY, RX3i 40W, 120 to 240VAC/125VDC, 47
IC695PSD040	RX3i PacSystem
IC695RMX128	REDUNDANCY MEMORY XHCNAGE, 128MB, RX3i
IC697ACC701A	GE FANUC;BATTERY, Li
IC697ALG230	GE FANUC; INPUT, ANALOG, 8PT
IC697ALG320	GE FANUC; OUTPUT, ANALOG, 4 PT
IC697ALG320-AR	MODULE, AS REMOVED
IC697BEM731	GE FANUC; Genius Bus Controller
IC697CGR935	Processor
IC697CMM742	GE FANUC; Ethernet Interface Module
IC697CMM742-AR	MODULE, AS REMOVED
IC697CPX935	GE FANUC; CPU, CPX935 W/ 1 MEG MEMORY
IC697CPX935-AR	MODULE, AS REMOVED
IC697HSC700	GE FANUC; COUNTER, HIGH SPEED
IC697HSC700-AR	MODULE, AS REMOVED
IC697MDL653	MODULE, FANUC, 24VDC INPUT 32 PT
IC697PCM711	GE FANUC; PCM711 CO PROCESSOR
IC697PCM711-AR	MODULE, AS REMOVED
IC697PWR711	POWER SUPPLY, SERIES 90-70
IC697PWR724	GE FANUC; POWER SUPPLY, 24VDC
IC698CPE040	CPU W/ ETHERNET, RX7i 1.8GHz, 10/100
IC698PSA350	Power Supply
IC752SPL013-BA	Ex2100 Excitation Control Interface Panel, BA Series
ICC020801001	GASKET, SPIRAL WOUND
IE-2000-4TS-B V01	Switch, Industrial Ethernet

Starfish PPS - Complete Catalog

Part Number	Description
INFB490S1	Fan Funnel
INR-S-00035-XHT-API-S3S-V	JACKING OIL FILTER
INR-S-00320-API-GF10-V	Filter, H2O Injection Skid
INR-S-00320-API-GF25-V	Filter Element
INR-S-00620-API-PF5-V	Filter Element
INR-S-00663-API-PF-10-V	Water Injection Pump Discharge Filter
INR-S-00663-API-PF10-V	Indufil INR-S-00663-API-PF10-V filter cartridge
INR-S-00700-XHT-API-SS10-V	Filter Element
INR-S-00860-D-XPG-F	Filter Cartridge
INR-S-0710-XHT-GF003-V	FILTER, ELEMENT
INR-S-0860-D-UPG-F-REP	Filter Element
INR-S-620-CC10V	Filter, Element
INR-Z-00320-API-GF5-V	FILTER
INR-Z-00320-API-PF-10-V	Filter HP
IPC24371-1	Fuel Hose
IPD20188-1	Hose 1 1/4 Teflon Tube
IPD21306-24-2	Hose 3/8 Teflon Tube 24
IPD21306-28-2	Hose 3/8 Teflon Tube 28
IPD21306-29	Hose 3/8 Teflon Tube 29
IPD21306-39-3	Hose 3/8 Teflon Tube 39
IPD21306-41	Hose 3/8 Teflon Tube 41
IPD21306-45-2	Hose 3/8 Teflon Tube 45
IPD21306-49	Hose 3/8 Teflon Tube 49
IPD21306-50-2	Hose 3/8 Teflon Tube 50
IPD21308-12	Hose 1/2 Teflon Tube12
IPD21308-28	Hose 1/2 Teflon Tube 28
IPD21310-20	Hose 5/8 Teflon Tube 20
IPD21324-24-1	Hose 1 1/2 Teflon Tube
IPD21324-27	Hose 1 1/2 Teflon Tube
IPD21324-30	Hose 1 1/2 Teflon Tube
IPD21324-48-1	Hose 1 1/2 Teflon Tube
IPD21324-55-1	Hose 1 1/2 Teflon Tube
IPD21324-55-2	Hose 1 1/2 Teflon Tube
IPD21406-116-1	Hose 3/8 Elastomer Tube
IPD21406-47	Hose 3/8 Elastomer Tube
IPD21406-55-1	Hose 3/8 Elastomer Tube
IPD21410-26	Hose 5/8 Elastomer Tube
IPD21412-20	Hose 3/4 Elastomer Tube
IPD21412-26	Hose 3/4 Elastomer Tube
IPD21412-58-1	Hose 3/4 Elastomer Tube
IPD21416-53-1	Hose 1 Elastomer Tube 5
IPD21506-20-1	Hose 3/8 Teflon Tube 20
IPD21506-32-2	Hose 3/8 Teflon Tube 32
IPD21506-32-4	Hose 3/8 Teflon Tube 32
IPD21506-50-1	Hose 3/8 Teflon Tube 50
IPD22323-3	Hose Flex 2.0 9.50L
IPD22323-4	Hose Flex 2.0 44.00L
IPD22334-19-1	Hose 3/8 Stainless Steel
IPD22334-24-1	Hose 3/8 Stainless Steel
IPD22334-41-1	Hose 3/8 Stainless Steel
IPD22334-50-1	Hose 3/8 Stainless Steel
IPD22334-78-1	Hose 3/8 Stainless Steel

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
IPD22335-20-1	Hose 3/8 Stainless Steel
IPD22335-24-1	Hose 3/8 Stainless Steel
IPD22617	HOSE
IPD22872-1	Hose 2 Metal Tube
IPD23356-1	Hose 1 GGLO PMP DISCH
IPD23357-1	Hose 1 GGLO Filter OutL
IPD23361-1	Hose HYDR. Start Return
IPD23363-1	Hose HYDR. Start Drain 7
IPD23365-1	HOSE
IPD23365-2	HOSE
IPD23367-1	Hose 1 1/2 SSBuffer Air
IPD23369-2	Hose 2 SS Buffer Air 13
IPD23371-1	Hose, P&W, 1 1/2"
IPD23372-1	Hose, P & W, 2"
IPD23373	Hose, Buffer Air
IPD23373-1	Hose, P&W, 1 1/2"
IPD23379-1	Hose 2 Vent
IPD23441-26-1	Hose 3/8 Teflon 26
IPD23441-58-1	Hose 3/8 Teflon 58
IPD23498-75-1	Hose 1 Teflon 75
IPD23499-2	Hose 1,5 Elastomer GGLO S
IPD23781-1	Hose 1-1/2 Teflon
IPD23782-1	Hose 1-1/4 Teflon
IPD23783-1	Hose 1-1/2 SS WI Supply
IPD23784-1	Hose 2-1/2 GG Breather
IPD23930-1	Hose 1-1/2 SS Vent
IPD24347-1	Hose SS BUFER Air 61.0
IPD24414-1	Hose GT Lube Oil Tank V
IPE24605-1	Hose 1 1/4 Teflon Tube FL P
IQQ060170127	ETHERNET / IP
IRC000010298	Adhesive and Sealant
IRM047279061	Gen Lube Pump
IRP103200640	FILTER
IRQ110580262	Transmitter
IS200BCAAH1A	Mark VI, Board
IS200BCABH1A	Mark VI, Board
IS200DPWAG1A	BOARD, EXCITATION POWER
IS200DSPXH1D	CARD, CONTROL, DRIVE DSP, EX2100
IS200EAUDH1A	EX2100e High Speed Contactor Board
IS200EAUXH1A	BOARD
IS200EAUXH2A	Board
IS200EBACG2A	EX2100E BRDG AC FDBK, 650V
IS200EBRGH1A	BOARD, INTERFACE, EXCITER BRIDGE, EX2100e
IS200EBRGH2A	EX2100E GATE PLS 42-77MM
IS200ECTBG2A	BOARD
IS200EDEXG1B	EXCITER DE-EXCITATION
IS200EDFFH1A	BOARD, FAB, MARK VIe
IS200EDFFH3A	EX2100e, Fanned DC Feedback Card
IS200EDISG1A	EX2100e, Power Distribution Card
IS200EDSLH1A	PCB,Selector Board,EX2100e DualRegulator
IS200EMIOH1A	EX2100, MAIN I/O Card
IS200EPCTG1A	BOARD

Part Number	Description
IS200EPDMG1B	Mark VIe, EXCITER PWR DIST MODULE
IS200EPSMG2A	REGULATOR POWER SUPPLY MODULE
IS200ERAXH1A	BOARD,, AUXILIARY, REGULATOR, CONTROL, EXCITAT I/O
IS200ERDDH1A	EX2100, Dynamics Discharge Card
IS200ERDDH1A_RM	EX2100, Dynamics Discharge Card - Reman
IS200ERGTH1A	Card, Detector, REG, GND, EX2100
IS200ERIOH1A	EXCITER MAIN I_O
IS200EROCH1A	EXCITER REGULA. OPTION CARD
IS200ERRRH1A	Board
IS200ERSCG1A	BOARD
IS200ERSDG1A	EX REG CONVERTER
IS200ESYSH1A	CARD, EXCITER
IS200ESYSH2A	EX2100e, System I/O Dual Card
IS200ESYSH3A	ESys Module (Simplex)
IS200EXCSG1A/RM	EX2100, Conduction Sensor Card (/RM)
IS200EXHSG2A	EX2100, H.S. Relay Driver Card
IS200GDDDSG1A	CARD, GATE, EX2000 PWM, GATE DRIVER & DYNAMIC DISCHARGE BOARD Module
IS200HSLAH1A	BOARD, INTERFACE, LINK, SERIAL
IS200HSLAH2A	BOARD, INTERFACE, OVERHAULED
IS200HSLAH2A-OH	MARK VIe, TERMINAL
IS200JGNDG1A	CARD, AC POWER DISTRIBUTION, MARK VIe
IS200JPDBG1A	CARD, POWER DISTRIBUTION
IS200JPDCG1A	MKVIe, DC Power Distrubution Module
IS200JPDDG3A	CARD, DC POWER DISTRIBUTION, MARK VIe
IS200JPDFG1A	BOARD, TERM, DC POWER DIST
IS200JPDGH1A	PACK, POWER, DIN RAIL MODULE
IS200JPDHG1A	CARD, 28V, DC POWER DISTRIBUTION, MARK VIe
IS200JPDMG1A	BOARD, TERM
IS200JPDSG1A	BOARD, AS REMOVED
IS200JPDSG1A-AR	Board, Power, Distribution
IS200JPDVG1A	LS2100e, Terminal Board
IS200LSTBH1A	module
IS200MVRCH1A	Card, Power Supply, Core Power Distribution, Mark VI
IS200MVRPH1A	BOARD, POWER SUPPLY, PSCD
IS200PSCDG1A	CORE ANALOG TB
IS200SCLSH1A	MKVleS, I/O Expansion Terminal Board, DIN
IS200SHRAH2A	Mark* VIe, 10/2 HART ANALOG INPUT TB
IS200SHRAS2A	Term BD, Hart Analog, SIL
IS200SPIDG1A	Mark* VIe, MKVIe Profibus-DP Master Comm Board
IS200SRLYH2A	MKVI, DO Plug Box Type TB
IS200SRTDH1A	Board, Term, RTD
IS200SRTDH2A	RTD, INPUT, PCB
IS200SSCAH2A	BOARD, TERM, COMM
IS200SSVPH1A	Term BD, Servo Control, Barrier typ, SPX
IS200STAIH2A	BOARD, TERM, ANALOG I/O
IS200STAIH2A-C	CHASSIS, MKVIe
IS200STAOH2A	MARK VI, ANALOG OUT
IS200STCIH2A	MARK VIe, I/O
IS200STTCH2A	BOARD, TERM, THERMOCOUPLE
IS200TBAIH1C	BOARD, TERM, ANALOG I/O

Starfish PPS - Complete Catalog

Part Number	Description
IS200TBAIH2C	MODULE, INPUT
IS200TBAIS1C	MKVIES ANALOG I/O - SIL
IS200TBAOH1C	BOARD, TERMINAL, ANALOG
IS200TBCIH1B	MKVI, Contact IN Terminal Board
IS200TBCIH2B	MKVI Contact IN Terminal Board
IS200TBCIH2C	BOARD, TERM
IS200TBCIH2C-AR	BOARD, AS REMOVED
IS200TBCIH3C	MARK VIe, INPUT
IS200TBCIS2C	BOARD, TERM, DISCRETE INPUT
IS200TBQDH2A	Terminal Board,MMV, AIO, Fixed, Opt
IS200TBTCH1B	MKVle, Thermocouple Input
IS200TBTCH1C	BOARD, THERMOCOUPLE TERMINALNEW
IS200TBTCS1B	Term BD, Thermocouple Input, SIL
IS200TDBTH2A	BOARD, TERM, OBS, DISCRETE
IS200TEFVH1A	MARK VI BOARD
IS200TPROH1C	BOARD, TERMINAL
IS200TPROS1C	Term BD, Backup Protection, Barrier
IS200TREA1A	MKVle, TRIP/Protection
IS200TREAS1A	CARD, TRIP RELAY, EMERGENCY
IS200TREGH1B	BOARD, TRIP TERMINAL, 125V
IS200TREGH2B	MKVle, Emergency Trip TB, 24 VDC
IS200TRESH1A	BOARD, TERMINAL, RTD
IS200TRLYH1B	BOARD, TERM
IS200TRLYH1D	MKVI, Relay Terminal Board
IS200TRLYH2E	BOARD, TERM
IS200TRLYH3E	MKVle, Relay Output PCB
IS200TRLYS1B	Term BD, 125V Relay, SIL
IS200TRPAH1A	BOARD, TERM
IS200TRPGH2B	BOARD, TERMINAL, TRIP PRIMARY
IS200TRPSH1A	BOARD, TERMINAL, TRIP PRIMARY
IS200TRTDH1D	MKVle, RTD Terminal Board, Simplex
IS200TSVCH1A	BOARD, TERMINAL, SERVO, MARK VIe
IS200TSVCH2A	Mark VIe; Module, Servo
IS200TSVCH2A-AR	BOARD, AS REMOVED
IS200TTPWH1A	BOARD, MKVI, 28V POWER DISTRIBUTION
IS200TTURH1C	BOARD, TERMINATION
IS200TTURS1C	MKVIES, TURBINE CONTROL TB, SIL
IS200TVBAH2A	CARD, MAIN, VIBRATION
IS200TVBAH2B	CARD, MAIN, VIBRATION
IS200TVIBH2B	BOARD, TERM, VIBRATION
IS200VAICH1C	Card
IS200VAOCH1C	CARD, ANALOG, VME OUTPUT
IS200VCCCH1B	MKVI, Contact IN/ Relay OUT Card
IS200VCRCH1B	CONTACT RELAYS
IS200VRTDH1D	CARD, VME RTD, MARK VIe
IS200VSVOH1B	CARD, SERVO, VME
IS200VTCCH1C	MARK VI THERMOCOUPLE Card
IS200VTURH1B	Card
IS200VVIBH1C	CARD, INPUT, VIBRATION
IS200WDIIH1A	DAUGHTER BOARD, WETTING, SDII
IS200WDIIH1A-AR	PCB, Board
IS200WNPSH1A	CARD, POWER

Part Number	Description
IS200WREAS1A	
IS200WROBH1A	Mark VI, Power card
IS2020DRLYH1A	CARD, ASSY, DRLY, PLA
IS2020RKPSG2A	POWER SUPPLY, MARK VI, 335V
IS2020RKPSG3A	Power Supply Module
IS210DTAIH1A	TERMINAL BOARD, DTAI, MARK VI
IS210DTTCH1A	TERMINAL BOARD, DTTTC, MARK VI
IS210JPDHG1A	PACK, POWER, DIN RAIL MODULE
IS210MVRAH1A	Module, MVRA, Mark VI, Control
IS210MVRBH1A	Interface Board, MMV, ADIO (Opt)
IS210MVRCH1A	Module, MVRC, Mark VI, Control
IS210MVRFH1A	Module, MURF, Mark VI
IS210SAMBH1A	Terminal Board Assy, Analog Processor
IS210SCLSH1A	CORE ANALOG TB
IS210SCLTH1A	SIMPLEX TERMBD CORE ANALOG with ASSEMBLY
IS210SCSAS1A	MKVleS, I/O Expansion Terminal Board, DIN
IS210SCSAS1A-AR	MKVleS, I/O Expansion Terminal Board, DIN
IS210TCSAS1A	Term BD Assy, (TCSA/WCSA)
IS210TREAH1A	RELAY,TRIP,EMERGENCY
IS210TREAS1A	AERO TRIP TB/W DBRD, SIL
IS210WSVOH1A	MODULE, SERVO
IS210WSVOH1A-AR	MODULE, AS REMOVED
IS215ACLEH1A	EX2100, 266 MHz Processor Card
IS215ACLEH1B	Card, EX2100
IS215ACLEH1C	CARD, EX2100
IS215PMVDH1A	MODULE, DIGITAL I/O (TCDA), MARK VIe
IS215PMVPH1A	Module, Processor, Bop W/MVR Protection, Input/Output
IS215UCCAM03A	MKVle, CPCI 650MHz Controller Card
IS215UCCCM04A	MKVle, CPCI Controller Card
IS215UCCCM04A-AR	MKVle, CPCI Controller Card
IS215UCVEH2A	MKVI, VME CPU Card
IS215UCVEM01A-OH	VME CONTROLLER CARD
IS215UCVEM03A	CARD, VME CPU
IS215UCVEM04A	CARD, VME
IS215UCVEM08A	MKVI, VME (1 E-Net, 2 ISBUS, 1 DLAN+)
IS215UCVEM08B	MKVI, VME (1E-Net, 2ISBUS, 1DLAN+)
IS215UCVGH1A	CONTROLLER CARD
IS215VCMIH1B	BOARD,PRINTED CIRCUIT, CARD, MARK VI INTERFACE COMMUNICATIONS ASM.
IS215VCMIH2C	CARD, I/O-NET VME COMM
IS215VPROH1B	MKVI, VME PROTECTION MODULE (HIGH CAPACITY)
IS215VPROH2B	MODULE, PROTECTION, LOW POWER
IS220PAICH1A	PACK, I/O, ANALOG, BASIC
IS220PAICH1A-AR	PACK, I/O, AS REMOVED
IS220PAICH1A-OH	PACK, I/O, OVERHAULED
IS220PAICH1B	PACK, I/O, ANALOG, BASIC
IS220PAICH2A	PACK, I/O, ANALOG, 200mA
IS220PAICH2B	PACK, I/O, ANALOG, 200mA
IS220PAOCH1A	PACK, I/O, ANALOG OUTPUT
IS220PAOCH1B	PACK, I/O, ANALOG OUTPUT
IS220PCNOH1B	PACK, I/O, CANOPEN GATEWAY
IS220PDIAH1A	PACK, I/O, DISCRETE INPUT

<b>Part Number</b>	<b>Description</b>
IS220PDIAH1A-AR	PACK, I/O, AS REMOVED
IS220PDIAH1A-OH	PACK, I/O, OVERHAULED
IS220PDIAH1B	PACK, I/O, DISCRETE, CONTACT IN
IS220PDIOH1A	PACK, I/O, DISCRETE
IS220PDIOH1B	PACK, I/O, DISCRETE
IS220PDOAH1A	PACK, I/O, DISCRETE OUTPUT
IS220PDOAH1A-AR	PACK, I/O, AS REMOVED
IS220PDOAH1A-OH	PACK, I/O, OVERHAULED
IS220PDOAH1B	PACK, I/O, CONTACT OUT
IS220PDOAH1B-OH	PACK, I/O, OVERHAULED
IS220PEFVH1A	PACK, I/O, ELECTRIC FUEL VALVE GATEWAY
IS220PHRAH1B	PACK, I/O, ANALOG, HART ENABLED
IS220PPDAH1A	PACK, I/O, PDM DIAGNOSTICS
IS220PPDAH1A-AR	PACK, I/O, AS REMOVED
IS220PPDAH1A-OH	PACK, I/O, OVERHAULED
IS220PPDAH1B	PACK, I/O, PDM DIAGNOSTICS
IS220PPRAS1B	PACK, I/O, EMERGENCY TURBINE PROTECTION
IS220PPRFH1B	PACK, I/O, PROFIBUS MASTER GATEWAY
IS220PPROH1A	PACK, I/O, BACKUP TURBINE PROTECTION
IS220PPROS1B	PACK, I/O, BACKUP TURBINE PROTECTION
IS220PRTDH1A	PACK, RTD I/O
IS220PRTDH1A-AR	PACK, I/O, AS REMOVED
IS220PRTDH1B	PACK, RTD I/O
IS220PSCAH1A	PACK, I/O, SERIAL COMMUNICATION
IS220PSCAH1B	PACK, I/O, SERIAL COMMUNICATION
IS220PSVOH1A	PACK, I/O, SERVO CONTROL
IS220PSVOH1A-AR	PACK, I/O, AS REMOVED
IS220PSVOH1A-OH	PACK, I/O, OVERHAULED
IS220PSVOH1B	PACK, I/O, SERVO CONTROL
IS220PTCCH1A	PACK, I/O, THERMOCOUPLE INPUT
IS220PTCCH1A-AR	PACK, I/O, AS REMOVED
IS220PTCCH1A-OH	PACK, I/O, OVERHAULED
IS220PTCCH1B	PACK, I/O, THERMOCOUPLE INPUT
IS220PTCCH2B	PACK, I/O, THERMOCOUPLE INPUT
IS220PTURH1A	PACK, I/O, PRIMARY TURBINE PROTECTION
IS220PTURH1A-AR	PACK, I/O, AS REMOVED
IS220PTURH1A-OH	PACK, I/O, OVERHAULED
IS220PTURH1B	PACK, I/O, PRIMARY TURBINE PROTECTION
IS220PVIBH1A	PACK, I/O, VIBRATION MONITOR
IS220PVIBH1B	PACK, I/O, VIBRATION MONITOR
IS220TPROH1C	BOARD, TERMINAL, PROTECTION
IS220UCSAH1A	PACK, I/O, PMVE CONTROL
IS220YDIAS1A	PACK, I/O, DISCRETE INPUT
IS220YDOAS1A	PACK, I/O, DISCRETE OUTPUT
IS220YHRAS1A	IO Pack, HART Analog IO, BPPB
IS220YPROS1A	MKVIES, IO Pack, Protection, SIL
IS220YSILS1B	IO Pack, Core Safety Protection
IS220YTCCS1A	IO Pack, Thermocouple Input, SIL
IS230JPDGH1B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS, MKVIe
IS230JPDGH2B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS, MKVIe
IS230JPDGM1B	ASSEMBLY: I/O PACK, PDM DIAGNOSTICS
IS230JPDS1AG01	ASSEMBLY: POWER DISTRIBUTION, 28VDC, MKVIe

Part Number	Description
IS230JPDSG1B	ASSEMBLY: POWER DISTRIBUTION, DIN MOUNT, MKVI
IS230PCAAH1A	ASSEMBLY: CORE I/O, ANALOG
IS230PCAAH1B	Assy, Core Analog (HD Gas)
IS230SNAIH4A	ASSEMBLY: BASIC ANALOG I/O, SIMPLEX, MKVIe
IS230SNAOH2A	ASSEMBLY: ANALOG OUT, BASIC, SIMPLEX,(BPPC), MKVIe
IS230SNCIH2A	ASSEMBLY: INPUT, MKVIe
IS230SNPRH1A	ASSEMBLY: PROTECTION, SIMPLEX,(BPPC), MKVIe
IS230SNPRH2A	ASSEMBLY: PROTECTION, SIMPLEX,(BPPC), MKVIe
IS230SNRLH2A	ASSEMBLY: OUTPUT, MKVIe
IS230SNRTH2A	ASSEMBLY: RTD INPUT, SIMPLEX, MKVIe
IS230SNSCH2A	ASSEMBLY: SERIAL COMMUNICATIONS, MKVIe
IS230SNSCH2A-C	CHASSIS, MARK VIe
IS230SNTCH2A	Module, Mark VI
IS230SNTCH4A	ASSEMBLY: THERMOCOUPLE INPUT, SIMPLEX,(BPPC)
IS230SNTRH2A	TURB PRI PRO DIN RAIL MODULE W/PTURH1B
IS230SRLYH2A	ASSEMBLY: OUTPUT, MKVIe
IS230SRTD2ASRTD2AG01	ASSEMBLY: I/O MODULE, S, RTD, TWIN, MKVIe
IS230SRTD2ASRTD2AG01-AR	ASSEMBLY: I/O MODULE
IS230SRTD2ASRTD2AG11	ASSEMBLY: I/O MODULE, S-TYPE, RTD, TWIN, MKVIe
IS230SRTD2ASRTD2AG21	ASSEMBLY: I/O MODULE, S-TYPE, RTD, TWIN, MKVIe
IS230SRTDH2A	ASSEMBLY: RTD INPUT, SIMPLEX, MKVIe
IS230SSCA2AG01	ASSEMBLY: I/O MODULE, S RTD, SINGLE, MKVIe
IS230SSCA2ASSCA2AG01	ASSEMBLY: I/O MODULE, S, RTD, TWIN, MKVIe
IS230STAI2ASTAI2AG01	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVIe
IS230STAI2ASTAI2AG11	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVIe
IS230STAI2ASTAI2AG21	ASSEMBLY: I/O MODULE, S, 0-20MA, TWIN, MKVIe
IS230STAIH4A	ASSEMBLY: BASIC ANALOG I/O, SIMPLEX
IS230STAO2ASTAO2AG21	ASSEMBLY: ANALOG OUT, MKVIe
IS230STCI2ASTCI2AG01	ASSEMBLY: I/O MODULE, MKVIe
IS230STTC2ASTTC2AG01	ASSEMBLY: MODULE, I/O, S-TYPE, MKVIe
IS230TBAI1CG01	ASSEMBLY: I/O, T-TYPE, TMR, MKVIe
IS230TBAI2CG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVIe
IS230TBCI2CG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVIe
IS230TBCIH5C	ASSEMBLY: CONTACT INPUT, TMR,(BPPB), MKVIe
IS230TCSAH1A	Assy, Analog (TCSAS1A/YSILS1B)
IS230TEFV1AG01	ASSEMBLY: I/O, FUEL CONTROL, T-TYPE, MKVIe
IS230TNAIH2C	ASSEMBLY: INPUT, MKVIe
IS230TNAIH4C	ASSEMBLY: ANALOG I/O
IS230TNAOH1C	ASSEMBLY: ANALOG OUTPUT, MKVIe
IS230TNAOH2C	ASSEMBLY: ANALOG OUTPUT
IS230TNCIH3C	ASSEMBLY: CONTACT INPUT DIN RAIL
IS230TNCIH4C	ASSEMBLY: CONTACT INPUT, DISCRETE, TMR,(BPPC),
IS230TNCIH5C	ASSEMBLY: INPUT, MKVIe
IS230TNCIH5C-C	CHASSIS, MARK VIe
IS230TNCIH6C	ASSEMBLY: INPUT, MKVIe
IS230TNCIH6C-C	CHASSIS, MARK VIe
IS230TNDTH2A	ASSEMBLY: DISCRETE TMR DIN RAIL, MKVIe
IS230TNEAH1A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVIe
IS230TNEAH2A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVIe
IS230TNEAH3A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVIe
IS230TNEAH4A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVIe
IS230TNEAH5A	ASSEMBLY: SPEED PROTECTION, TMR,(BPPC), MKVIe

Part Number	Description
IS230TNPAH1A	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPC), MKVIe
IS230TNRLH1B	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRLH1B-C	IS230 board without IS220s
IS230TNRLH1E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRLH1F	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRLH2E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRLH2F	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRLH3E	ASSEMBLY: RELAY OUTPUT, TMR,(BPPC), MKVIe
IS230TNRTH3D	ASSEMBLY: RTD INPUT, DUAL,(BPPC), MKVIe
IS230TNRTH4D	ASSEMBLY: RTD INPUT, DUAL,(BPPC), MKVIe
IS230TNSVH3A	ASSEMBLY: SERVO CONTROL, MKVIe
IS230TNSVH4A	ASSEMBLY: SERVO CONTROL, MKVIe
IS230TNTCH1B	ASSEMBLY: THERMOCOUPLE INPUT, MKVIe
IS230TNTCH2C	ASSEMBLY: THERMOCOUPLE INPUT, MKVIe
IS230TNTRH1C	Assembly, Primary Turbine Protection
IS230TNVBH4A	Assy, Vibration In (TVBAH2B/PVIBH1B)
IS230TPROH3C	ASSEMBLY: BACKUP TURBINE PROTECTION, MKVIe
IS230TRLSH2B	ASSEMBLY: DISCRETE OUTPUT
IS230TRLY1BG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVIe
IS230TRLY2EG01	ASSEMBLY: I/O MODULE, T-TYPE, TMR, MKVIe
IS230TRLY3EG01	ASSEMBLY: I/O, T-TYPE, TMR, MKVIe
IS230TRLYH2E	ASSEMBLY: RELAY OUTPUT, TMR, MKVIe
IS230TRPA1AG01	ASSEMBLY: TRIP/PROTECTION, TMR,(BPPB), MKVIe
IS230TSPRH1C	Assy, Protection (TPROS1C/PPOS1B)
IS230TSVC2AG01	ASSEMBLY: SERVO CONTROL, MKVIe
IS230TSVC2AG01-OH	ASSEMBLY: MODULE, OVERHAULED
IS400JPDDG1A	MKVIe, 125VDC/28VDC PDM, ROHS
IS400JPDGH1A	BOARD, TERM, DC POWER DIST
IS400JPDHG1A	HIGH DENSITY PWR DISTR
IS400JPDMG1A	CARD, 28V, DC POWER DISTRIBUTION, MARK VIe
IS400JPDSG1A	Board
IS400TDBTH2A	BOARD, TERM, OBS, DISCRETE
IS400TDBTH6A	MKVIe, Discrete Terminal Board
IS400TRLYS1B	BOARD, TERM, 125V RELAY
IS400TVBAH2B	Vibration Term (MKVIe Turbine Control - Operational)
IS400WNPSH1A	CARD, POWER
IS400WNPSS1A	POWER SUPPLY, +28 TO -28
IS400WROBH1A	Daughter BD, Power Dist, Fused
IS410JPDDG4A	DC PDM DIN RAIL ASSY
IS410JPDEG1A	Term BD Assy, 24/48VDC Pwr Dist
IS410JPDGH1A	MKVIe, DC PWR DIST. CARD, DIN MT
IS410JPDHG1A	28VDC Power Distribution board w/DIN-Mtg
IS410SCSAS1A	MKVIe, YSIL I/O Expansion Card
IS410TBCIS2C	MKVIe, Contact TB, Safety Rated
IS410TVBAH2B	VIBRATION TERMINAL BOARD
IS415UCVHH1A	MKVI, VME Processor Control Card
IS420ESWAH1A	SWITCH, ETHERNET, 8 PORT, 1 FIBER
IS420ESWAH2A	Switch
IS420ESWAH2A-AR	SWITCH, AS REMOVED
IS420ESWAH3A	SWITCH ETHERNET, 8 PORT, ESWX INDUSTRIAL
IS420ESWBH1A	SWITCH, ETHERNET

## Starfish PPS - Complete Catalog

Part Number	Description
IS420ESWBH2A	Switch, Ethernet, ESWB, W/Fiber
IS420ESWBH3A	SWITCH, ETHERNET
IS420ESWBH5A	IONet Switch, 16-Port, 2-SM Fiber SFP
IS420ESWCH2A	Switch
IS420PFFAH1B	FOUNDATION FIELDBUS LINKING DEVICE
IS420PPDAH1B	MKVIe, PDM SYSTEM FEEDBACK PACK, BPPC
IS420PPNGH1A	MODULE, PROFINET GATEWAY
IS420PSCAH1B	IO PACK, SERIAL COMM, BPPC
IS420PUAAH1A	Module, Serial Communication Input/Output
IS420PVIBH1B	PACK, I/O, VIBRATION MONITOR
IS420UCECH1B	Controller
IS420UCSBH1A	GE MARK VIe CONTROLLER
IS420UCSBH3A	UCSB CONTROLLER
IS420UCSBH4A	MODULE, UCSB H1A CONTROLLER
IS420UCSBS1A	UCSB Controller
IS420UCSCH1B	Mark VIe Controller 1.6GHz
IS420UCSCH2A	Controller
IS420UCSCS2A	Mark VIe, UCSC-SIL CONTROLLER,DUALCORE,1.6GHZ
IS420UCSEH2B	Controller
IS420YAICS1B	PACK, I/O, ANALOG
IS420YDIAS1B	PACK, I/O, DISCRETE INPUT
IS420YDOAS1B	PACK, I/O, DISCRETE OUTPUT
IS420YUAAS1A	IO Module, Universal IO
IS430SNUAH1A	ASSEMBLY: UNIVERSAL I/O, MKVIe
IS430SSUAH1A	Assy, Special Function
ISM101332545	T3 sensor
ISM101334994	Transducer, Displacement
ISM990970856	RING
J-4620	KIT, Calibration
J-4621	
	GAS
J-4666-5	CYLINDER, 50%LEL METHANE
J-4691	COMPOUND, SEALING, CHICO
J00008	Compound, Sealing
J00021	VALVE, CHECK
J00022	Valve, relief
J00044	Valve, relief
J00068	VALVE, CHECK
J00089	Ametek Pressure Transmitter
J00091	PRESSURE GAUGE
J00092	VALVE, SOLENOID
J00093	VALVE, SOLENOID
J00094	VALVE, SOLENOID
J00095	METER, FLOW
J00097	VALVE, SOLENOID
J00098	VALVE, SOLENOID
J00100	VALVE, SOLENOID
J00101	VALVE, SOLENOID
J00105	RTD
J00106	Valve, Check
J00107	VALVE, CHECK
J00120	VALVE, SOLENOID
	VALVE, CHECK 4 INCH

## Starfish PPS - Complete Catalog

Part Number	Description
J00121	VALVE, CHECK, MANUAL
J00125	Yokagawa flow meter 3
J00142	SWITCH, FLOW
J00146	VALVE, SOLENOID
J00147	VALVE, SOLENOID
J00162	RTD, Dual
J00176	Valve, Them Control
J00180	Valve, Check
J00286	BOLT, HEX
J00290	BOLT, HEX
J00300	BOLT, HEX
J00356	Screw Seal S/T, 1/4-20 C x 1 PL
J00361	Screw
J00417	Coupling
J00457	Temp Sensor Assy
J00458	Valve, check
J00463	Filter, Element
J00464	Thermo Valve
J00464KIT	Thermo Valve, OVERHAUL KIT
J00465	Valve, Drain
J00495	Coupling
J00535	Glass, Wired
J00537	LOCK WASHER
J00547	NUT, HEAVY HEX
J00550	NUT, 6 PT
J00590	STUD
J00622	WASHER, FLAT
J00662	BOLT, HEX
J00702	Manifold
J00744	Gasket
J00748	WASHER, FLAT, SAE
J00749	BOLT, HEX
J00755	NUT, HEX
J00792	BOLT, HEX
J00793	BOLT, HEX
J00825	VALVE, CHECK
J00829	Reservoir Heater and Thermostat
J00833	Coupling, Water Injection
J00838	VALVE, CHECK
J00841	Nat Gas vent valve
J00972	GAUGE, PRESSURE
J00973	MAIN SYSTEM PRESSUREGAUGE
J01068	Temp sensor, GLO
J01240	WASHER, LOCK, M161W HELICAL ZINC
J01310	Sensor, temp
J01649	BOLT, HEX
J01653	BOLT, HEX
J01654	WASHER, LOCK, 3/8, HELICAL, 316SS
J01657	BOLT, HEX
J01658	WASHER, LOCK
J01659	WASHER, FLAT, NARROW, TYPE B

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J01660	NUT, HEAVY HEX
J01683	BOLT, HEX
J01689	NUT, LOCK
J01718	WASHER, LOCK
J01720	WASHER, FLAT, NARROW SERIES, TYPE B
J01752	NUT, HEAVY HEX
J01796	BOLT, HEX
J01798	BOLT, HEX
J01804	BOLT, HEX
J01881	NUT, HEAVY HEX
J01912	BOLT, HEX
J01991	Filter Element
J02088	BOLT, HEX
J02486	FOD Sock
J02538	ADAPTER, ADJUSTABLE
J02705	KIT, INSULATION BLANKET, DIFFUSER
J02979	Valve, Check
J03490	Pressure transmitter
J03562	VALVE, FLOW REGULATING, 1 INCH FNPT PORTS
J03600	TBV Gasket
J03601	TBV Gasket
J03697	Air Pressure Regulator
J03744	Meter, Flow
J03886	COUPLING, FULL, 1 FNPT, 3000LB, 316SS
J04050	Tube
J04052	Tube
J04054	Tube
J04081	NUT, HEAVY HEX
J04082	WASHER, FLAT, WIDE, STANDARD
J04083	WASHER, LOCK
J04182	RTD, Dual Platinum
J04363	KIT, BLANKET, CDP PIPING
J04412	Temp Sensor
J04448	Joint, Expansion
J04460	GLO Pressure Transmitter
J04462	Sensor, Temp
J04467	Transmitter, pressure
J04498	Differential Pressure Gauge
J04504	VALVE, BALL, MANUAL, 1 1/2 IN, FNPT, SS
J04545	Meter, Flow
J04683	Pump, Starter, SOV actuated
J04698	Coupling, water inj
J04699	Pump, Low Pressure
J04725	GEARBOX, ROTOJET
J04726	Pump, High Press
J04800	TRANSMITTER, PRESSURE 0-1000 PSIG
J04839	VALVE, RELIEF
J04844	Valve, Check
J04919	Switch, Level
J04920	TLO Tank Level Switch
J04938	CABLE, UV FLAME DETECTOR
J04968	Duplex Filter Housing

## Starfish PPS - Complete Catalog

Part Number	Description
J04983	WASHER, FLAT, NARROW, TYPE B
J04989	Cable, TRF Accel
J05000	PUMP, START
J05000-AR	PUMP, START
J05000-OH	PUMP, START
J05003	VALVE, CHECK
J05015	valve, check
J05021	Drain Strainer
J05022	VALVE,CHECK
J05061	Pump, Start
J05080	Coupling, start pump
J05120	SWITCH, PRESSURE
J05122	Switch, pressure
J05124	SWITCH, TEMPERATURE, ADJUSTABLE
J05144	Switch, Pressure, Adj (Neo-Dyn)
J05146	Switch, Press., Adj., Diff.
J05147	Switch, Pressure, Adj.
J05150	SWITCH, PRESSURE
J05272	STUD
J05287	Pump, GLO / Gearbox Lube Oil
J05301	SWITCH, TEMPERATURE
J05305	VALVE, SOL
J05344	LAMP
J05482	ADAPTER, 1 5/16 - 12 MJ
J05525	COUPLING
J05585	NOZZLE, AMMONIA
J1092P03	Nut
J1092P04	NUT, SELF LOCKING
J1092P05	NUT, SELF LOCKING
J1092P06	Nut
J1128P03	Seal Ring
J1128P05	E-SEAL, RING
J1128P08	E-SEAL, RING
J1128P10	E-SEAL, RING
J1128P12	Metal Gasket Ring, E Seal
J1128P13	GASKET, METAL
J1128P18	E-SEAL, RING
J1128P19	E-SEAL, RING
J1128P19 - AR	SEAL RING, METAL
J1128P24	E-SEAL, RING
J1128P28	E-SEAL, RING
J1153G08	CLAMP
J120-S164B	Discharge Pressure Switch
J1212P06	NUT
J1215P13	Gasket, Seal
J1215P16	GASKET
J1215P17	Metal Gasket Ring, E Seal
J1215P24	Gasket, Liquid Fuel Mix Block
J1220G03	Clamp, Loop
J1220G04	Clamp, Loop
J1220G05	Clamp, Loop
J1220G06	Clamp, Loop

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J1220G07	Clamp, Loop
J1220G08	Clamp, Loop
J1220G09	Clamp, Loop
J1220G10	Clamp, Loop
J1220G11	Clamp
J1220G12	Clamp, Loop
J1220G13	CLAMP
J1220G14	CLAMP
J1220G15	CLAMP
J1220G16	CLAMP
J1220G20	CLAMP
J1220G24	CLAMP
J1220G28	Clamp, Loop
J1220P09	Clamp, Loop
J1221G03	CLAMP
J1221G04	Clamp
J1221G05	Clamp
J1221G06	Clamp
J1221G07	Clamp
J1221G08	Clamp
J1221G10	Clamp
J1221G12	Clamp
J1221G14	Clamp
J1221G15	CLAMP
J1221G16	Clamp
J1221G24	Clamp
J1227P06	STRAP
J1274G0184DAB	Hose, Teflon
J1274G0211DAB	HOSE
J1274H0260DAB	HOSE ASSEMBLY
J1276F0185DAB	HOSE
J1276F0750DAB	HOSE
J1276G0250DAB	Hose, Oil
J1276G0990CAB	HOSE
J1276G0990DAB	HOSE, TEFLON
J1276G1250DAB	HOSE, TEFLON
J1276H0110DAB	Tube
J1276H0256DAB	HOSE
J1279E0482DAB	Hose, TLO
J1280E1245DA064	HOSE
J1311P03	E-SEAL, RING
J1311P05	E seal
J1311P05A	SEAL, RING, METAL
J1311P06	E-SEAL, RING
J1311P11	E-SEAL, RING
J1311P13	E-SEAL, RING
J1315G106	CAP
J1317P10B	Nut, Swivel
J1411P04	NUT
J1431P03	CLAMP
J1431P04	Clamp
J1431P05	Clamp

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J1431P06	Clamp
J1431P07	Clamp
J1431P08	Clamp
J1431P10	CLAMP
J1431P12	Clamp
J1431P15	Clamp
J1435P79	SPACER
J158P006	Stud
J158P013A	Stud
J180F0480G090	TUBE, OIL - VSV
J180G0440G090	TUBE, OIL - VSV
J180H0420G090	HOSE
J193H0360A090	TUBE, OIL - VBV
J193H0360C090	HOSE
J198P01	Nut
J198P02	Nut
J198P02A	Nut
J198P02B	Nut
J198P02C	Nut
J198P02D	Nut
J198P04	Nut
J200P02	Nut
J200P03	Nut
J201P01	NUT
J201P02	Nut
J201P03	NUT, 12 PT
J201P04	NUT
J201P04A	NUT
J219P02	Gasket, Seal-Flange
J219P03	Gasket
J219P04	Gasket
J219P05	Gasket, Seal-Flange
J219P05A	GASKET
J219P06	Gasket
J219P07	Gasket
J219P08	Gasket
J219P09	Gasket, Seal-Flange
J221P006	O-RING
J221P008	O-RING
J221P009	O-RING
J221P010	O-RING
J221P012	O-RING
J221P013	O-RING
J221P014	O-RING
J221P015	O-RING
J221P016	O-RING
J221P017	O-RING
J221P018	O-RING
J221P019	O-RING
J221P020	O-RING
J221P021	O-RING
J221P022	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J221P023	O-RING
J221P026	O-RING
J221P028	O-RING
J221P034	O-RING
J221P035	O-RING
J221P036	O-RING
J221P037	O-RING
J221P042	O-RING
J221P043	O-RING
J221P044	O-RING
J221P110	O-RING
J221P112	O-RING
J221P113	O-RING
J221P114	O-RING
J221P115	O-RING
J221P116	O-RING
J221P117	O-RING
J221P121	O-RING
J221P122	O-RING
J221P123	O-RING
J221P124	O-RING
J221P125	O-RING
J221P126	O-RING
J221P129	O-RING
J221P130	O-RING
J221P131	O-RING
J221P132	O-RING
J221P134	O-RING
J221P135	O-RING
J221P138	O-RING
J221P139	O-RING
J221P140	O-RING
J221P145	O-RING
J221P148	O-RING
J221P150	O-RING
J221P1501	O-RING
J221P1502	O-RING
J221P152	O-RING
J221P153	O-RING
J221P156	O-RING
J221P160	O-RING
J221P161	O-RING
J221P163	O-RING
J221P166	O-RING
J221P170	O-RING
J221P175	O-RING
J221P210	O-RING
J221P213	O-RING
J221P214	O-RING
J221P216	O-RING
J221P218	O-RING
J221P219	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J221P220	O-RING
J221P222	O-RING
J221P224	O-RING
J221P225	O-RING
J221P226	O-RING
J221P228	O-RING
J221P229	O-RING
J221P230	O-RING
J221P231	O-RING
J221P234	O-RING
J221P235	O-RING
J221P236	O-RING
J221P238	O-RING
J221P240	O-RING
J221P240HT	O-RING
J221P241	O-RING
J221P242	O-RING
J221P243	O-RING
J221P244	O-RING
J221P245	O-RING
J221P247	O-RING
J221P252	O-RING
J221P255	O-RING
J221P258	O-RING
J221P260	O-RING
J221P262	O-RING
J221P263	O-RING
J221P264	O-RING
J221P265	O-RING
J221P266	O-RING
J221P269	O-RING
J221P270	O-RING
J221P278	O-RING
J221P324	O-RING
J221P341	O-RING
J221P344	O-RING
J221P349	O-RING
J221P390	O-RING
J221P429	O-RING
J221P433	O-RING
J221P437	O-RING
J221P444	O-RING
J221P460	O-RING
J221P902	O-RING
J221P903	O-RING
J221P904	O-RING
J221P905	O-RING
J221P906	O-RING
J221P908	O-RING
J221P910	O-RING
J221P912	O-RING
J221P914	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J221P916	O-RING
J221P920	O-RING
J221P975	O-RING
J224P042	O-RING
J224P044	O-RING
J224P139	O-RING
J224P150	O-RING
J228P116	SEAL
J228P128	O-RING
J334P12A	Bolt, Machine
J334P16B	Bolt
J334P21A	BOLT
J334P23A	Bolt, Machine
J335P10A	BOLT
J336P28B	BOLT
J414P034A	Bolt
J414P052A	Bolt
J415P123A	Bolt
J423P045A	Bolt, Shear
J424P008A	Bolt, Shear
J431P124A	Bolt
J4620	KIT, Calibration
J490P05	NUT
J511P106	Nipple
J511P108	Fitting
J511P110	FITTING
J515P04	CONNECTOR, ELBOW
J522P17-AR	Reducer
J522P57 - AR	REDUCER
J522P60 - AR	REDUCER
J522P65 - AR	REDUCER
J534P04	NIPPLE
J534P04 - AR	NIPPLE
J534P06	FITTING
J534P06 - AR	FITTING
J534P08	INSERT
J534P08 - AR	INSERT
J534P10	INSERT
J534P12	Fitting
J574P02	Nut
J626P04	NUT
J626P09	NUT
J627P05	NUT
J628P03	Nut
J628P06D	NUT
J643P04B	Bolt
J643P05D	BOLT
J643P06B	BOLT, MACHINE
J643P07A	BOLT
J643P08A	BOLT
J643P08B	BOLT
J643P09A	BOLT, MACHINE

## Starfish PPS - Complete Catalog

Part Number	Description
J643P11A	Bolt
J643P12A	BOLT
J644P04F	Bolt
J644P05D	Bolt
J644P06A	BOLT
J644P06B	Bolt
J644P06D	Bolt
J644P07B	Bolt
J644P07D	Bolt
J644P07F	BOLT
J644P08A	BOLT
J644P08D	BOLT
J644P09A	Bolt
J644P09D	BOLT
J644P09F	Bolt
J644P10A	Bolt
J644P10D	Bolt
J644P11A	Bolt
J644P12A	BOLT
J644P12B	BOLT
J644P13A	Bolt
J644P13B	Bolt
J644P13F	BOLT
J644P14A	BOLT
J644P14B	BOLT
J644P14BQQ	BOLT
J644P14E	BOLT
J644P15A	BOLT
J644P16A	BOLT
J644P16F	Bolt
J644P17A	bolt
J644P18A	BOLT, MACHINE, DBL HEX HD, 0.250-28 BY 1.312
J644P19A	BOLT
J644P19F	Bolt
J644P21A	Bolt
J644P22A	Bolt
J644P23A	BOLT
J644P25B	Bolt
J644P26A	Bolt
J644P26C	Bolt
J645P10A	BOLT
J645P10D	BOLT
J645P11A	Bolt
J645P12A	BOLT
J645P12F	BOLT
J645P13A	BOLT
J645P13D	Bolt
J645P14A	Bolt
J645P15A	BOLT
J645P17A	Bolt
J645P17D	BOLT
J645P18A	Bolt

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
J645P19D	BOLT
J645P20A	Bolt
J645P21A	BOLT
J645P23A	BOLT
J645P23D	Bolt
J645P25A	BOLT
J645P26A	BOLT
J645P27D	Bolt
J645P30A	BOLT, MACHINE
J645P31A	BOLT
J645P33	Bolt, Machine DBL Hex
J645P33A	Bolt
J646P06F	BOLT
J646P12B	Bolt
J646P14A	BOLT
J646P17D	Bolt
J646P18A	BOLT
J646P19A	Bolt
J646P19D	Bolt
J646P20A	Bolt
J646P21E	Bolt
J646P22A	Bolt
J646P23A	BOLT, MACHINE
J646P24A	BOLT, DBL HEX HEAD
J648P21D	BOLT
J6G3R	Rectifier
J714P051A	Bolt
J813P003A	BOLT
J813P010A	BOLT
J815P029A	BOLT
J815P040A	BOLT, SHEAR-HEX
J815P052A	Bolt
J815P060A	BOLT
J816P052A	Bolt
J816P072C	Bolt
J864P019A	BOLT
J904P03B	Bolt
J904P06A	BOLT
J904P07A	BOLT
J94129	O-RING
J951P07A	SCREW, MACHINE, FLATHEAD
J952P07C	SCREW
J952P20A	BOLT
J970P04	INSERT
J979P03	NUT
J979P08D	NUT
JPMG-336-CE-R	FILTER, ELEMENT
K/13220-1406	KIT, REPAIR, CIRCLE SEAL VALVE
K/15830-1061	REPAIR KIT FOR 15830-1061
K/32840-1650	Kit, Overhaul, Valve
K30B18	Bergen Cables
K30B24	Bergen Cable; 24"

Starfish PPS - Complete Catalog

Part Number	Description
K333P20	Blade HPC S3
K415P12	Blade, HPC STG 4
KAL26200	Breaker
KCF-24-J-18-F	Probe
KCX006703320	Gasket
KCX013609020	Gasket
KD485	CONVERTER
KDE2412PMS1-6A	FAN
KEYSWITCH	SWITCH, HORN
KFZ213400604	Gasket
KFZ335060704	Gasket
KHA032903501	O-Ring
KHA047203501	O-Ring
KHS-17D11-24	RELAY
KLM10	FUSE, 10 AMP
KLM15	FUSE, 15 AMP
KLM2	FUSE, 2A
KLM20	FUSE, 20A
KLM30	FUSE, 30A
KPB150LMTZ2	HOUSING, BALLAST, MERCMASTER 3
KPWB75	HOOD, WALL MOUNTING, 3/4" NPT, MERCMASTER 3
KR9P35RH1	Pushbutton
KSC328324V-1	Bearing, Torque Arm, Rear
KSF-ST-T-1.00-V-S-P	Sight Flow Indicator, Vilton Seals
L-150	COUPLING
L14517P01	GASKET
L14520P01	Spacer
L14542P01	Nut
L150	Spider
L150N	Insert, Coupling
L15500P01	SPRING
L16562G03	PROBE
L1941A396780	Cable, overspeed trip
L21060G01	BRACKET
L21103P01	RTD, Detector, Resistance Immersion
L21131P02	Sensor, Speed
L21225P02	Sensor
L21273G01	PLATE
L21325	Strap, sub bracket
L21325G05	Strap
L21348G02	Strap
L21384G01	Tube
L21393G05	Adapter Assy, Starter
L21418G01	Bracket, Mounting-Transfer Gearbox
L21432P01	SHIM, RADIAL
L21454P04	Exciter, Ignition
L21454P05	Exciter, Ignition
L21524G03	Bracket
L21564G01-AR	TUBE, MANIFOLD, OIL
L21617P01	GASKET
L21618P06	Gasket

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L21618P07	RETAINER
L21656P04	TRANSDUCER MOTIONAL PICKUP
L21658P01	LEAD, LEFT OVERSPEED TRIP
L21658P02	LEAD, LEFT OVERSPEED TRIP
L21674P12	VALVE
L21674P13	VALVE, CHECK
L21674P13-A	Valve, Check
L21674P14	VALVE, CHECK
L21674P14-A	Valve, Check
L21693P02	Cable, VSV feedback
L21696P09	Solenoid Valve
L21742P01	LEAD, RIGHT OVERSPEED TRIP
L21785P06	Valve, Check
L21803P02	GASKET
L21849P24	PLATE
L21860P01	Bracket
L22046P07	BEARING
L22047P02	FWD Mount Bearing
L22047P03	Bearing
L22069G02	FOD SOCK
L22077P02	SPACER
L22128P02	Seal Ring, Turbine Bellmouth
L22159P06	Transducer, Pressure
L22161P21	Transducer, Pressure
L22161P22	Transducer, Pressure
L22276G01	TUBE
L22424P01	Gasket
L22425P01	ARRESTOR
L22441P01	BRACKET
L22444G01	STRAP
L24065P02	Spacer
L24337P01	RTD, Detector, Resistance Immersion
L24407P02	PUMP, LUBE AND SCAVENGE
L24434P02	Support
L24435P01	BOLT
L24922P03	Pump, VG
L24922P03-OH	PUMP, VG
L24932P02	Ignition Lead
L24983G05	BEARING
L24983G06	BEARING
L25105P08	Starter
L25806P02	Ignition Exciter
L25806P04	Ignition Exciter
L25892P02	Starter
L279N1e25967-FLANGE	Heater Flange
L279N1e25967-GG	Garlock 3000 Fiber Gasket
L279N1e25967-VG	Flange Viton Gasket
L28004P01	GASKET SEAL
L28023P02	Cable, XN2 SP
L28066P01	THERMOCOUPLE
L28124P01	GASKET, RING
L28124P02	GASKET, RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L28124P03	GASKET, RING
L28266P02	Pump, hyd
L28266P03	Pump
L28339P01	T3 sensor
L28343P01	Thermocouple
L28361P10	RING, COVER, IGNITER PLUG
L28361P14	RING
L28490P01	FLAME SENSOR, UV
L28490P05	Flame Sensor UV
L28497P01	Hose, fuel
L28497P02	Hose, fuel
L31177P02	Retainer
L31266P10	SPACER
L31266P10AR	SPACER, METERING, AS REMOVED
L31289P01	Igniter Cover
L31302G01	ROD
L31302G02	Rod End Bearing
L31303G01	Link
L31413P01	Cooling Air Tube
L31476P57-AR	NOZZLE, DUAL FUEL
L31476P59	NOZZLE, DUAL FUEL
L31476P61	NOZZLE, DUAL FUEL
L31476P61-AR	NOZZLE, DUAL FUEL, AS REMOVED
L31476P61-OH	NOZZLE, DUAL FUEL, OVERHAULED
L31476P62	NOZZLE, DUAL FUEL
L31476P62-AR	NOZZLE, DUAL FUEL
L31476P62-OH	NOZZLE, DUAL FUEL, OVERHAULED
L31476P65	Fuel Nozzle
L31476P65-AR	Fuel Nozzle, As Removed
L31476P65-OH	Fuel Nozzle, Overhauled
L31476P67	Fuel Nozzle
L31476P67-OH	Fuel Nozzle - Overhauled
L31707G01	BOLT
L31711P01	RETAINER
L31805G09	NOZZLE, GAS / STEAM
L31805G09-AR	Fuel Nozzle, GAS / STEAM
L31809P02	NOZZLE, FUEL
L31809P02-AR	NOZZLE, FUEL, AS REMOVED
L31809P08	Nozzle, fuel
L31809P08-AR	FUEL, NOZZLE, AS REMOVED
L31809P10	NOZZLE, Fuel, DUAL, LM2500
L31809P10-AR	AS REMOVED NOZZLE, FUEL, DUAL, LM2500
L31809P10-OH	NOZZLE, FUEL, DUAL, LM2500
L31809P11	NOZZLE, FUEL
L31809P11-AR	Nozzle, Fuel
L31809P11-OH	NOZZLE, FUEL
L31809P12	Fuel Nozzle
L31809P12-AR	FUEL NOZZLE, DUAL FUEL, LM2500
L31809P12-OH	Nozzle, Dual Fuel, LM2500
L31809P12OH	Nozzle, Dual Fuel, LM2500
L31809P13	NOZZLE, FUEL
L31809P13-AR	NOZZLE, FUEL (2500)

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L31809P13-OH	NOZZLE, FUEL, Overhauled
L31918P04	Conditioner, Signal
L31918P05	Detector, Flame
L31947P04	SENSOR T2/P2
L31967P03	ACCELEROMETER, CRF
L31967P04	Accelerometer
L31967P13	CRF ACCELEROMETER
L31967P18	ACCELEROMETER, CRF
L31967P21	TRF Accelerometer
L31967P22	ACCELEROMETER, CRF
L31967P25	Accelerometer
L31967P27	ACCELEROMETER, CRF
L31967P28	ACCLRMTR
L31967P29	TRF Accelerometer
L31967P31	ACCELEROMETER, CRF
L34036G01	BRACKET
L34128P01	Bracket
L34134P01	BRACKET
L34143G01	Probe
L34151P02	Accelerometer
L34152P01	Accelerometer
L34152P04	Accelerometer
L34214P05	Amplifier
L34235G01	Bracket, Accelerometer
L34246P03	Accelerometer, LM2500
L34246P04	Accelerometer, LM2500
L34283P01	FILTER ASSEMBLY
L34283P01-AR	FILTER ASSEMBLY - AS REMOVED
L34283P01-BOWL	Filter Bowl
L34283P03	Filter Bowl
L34283P03-Bowl	Filter Bowl
L34319P01	SENSOR
L34356P01	VALVE, SERVO
L34358P06	Actuator
L34366G01	TUBE ASSY, FUEL FEEDER
L34379P03	CONTROLLER, VSV
L34379P04	Control
L34379P04-OH	CONTROLLER, VSV, OVERHAULED
L34447G01	BRACKET
L34448G01	Hinged Bracket
L34448G02	BRACKET
L34492P001A	Bracket
L34518P01	Orifice, Plate
L34518P02	Orifice, Plate
L34518P03	Orifice, Plate
L34518P04	Orifice, Plate
L34518P05	Orifice, Plate
L34518P06	Orifice, Plate
L34518P07	Orifice, Plate
L34518P08	Orifice, Plate
L34518P09	Orifice, Plate
L34518P10	Orifice, Plate

## Starfish PPS - Complete Catalog

Part Number	Description
L34518P11	Orifice, Plate
L34518P12	Orifice, Plate
L34518P13	Orifice, Plate
L34518P14	Orifice, Plate
L34518P15	Orifice, Plate
L34518P16	Orifice, Plate
L34518P17	Orifice, Plate
L34518P18	Orifice, Plate
L34582P001A	BRACKET
L34596G01	BRACKET
L34597G01	BRACKET
L34648P06	SEAL, FITTING
L34847P01	RTD, Detector, Resistance Immersion
L34848G01	BRACKET
L34975P005	BOLT, FINISHED
L34975P007	BOLT, FINISHED
L34976P007	BOLT
L34976P069	BOLT, SELF-LOCKING
L35054P01	600266 Cable and conduit
L35055P01	600267 Cable and conduit
L35056P03	Accelerometer
L35056P04	ACCELEROMETER
L35166P01	RTD, Detector, Resistance Immersion
L35166P01-AR	RTD, AS REMOVED
L35166P02	RTD, Detector, Resistance Immersion
L35167P01	Thermocouple Harness Top Right
L35169P01	TC harness, Btm right LM5000
L35171P01	TC harness, Top Left LM5000
L35173P01	TC harness, Btm Left LM5000
L35228P18	Gasket
L35228P19	Gasket
L35246P01	GASKET
L35246P02	Gasket, Seal
L35248P01	Gasket, Seal
L35248P10	Gasket, Seal
L35350P04	GASKET
L35579P01	Gasket
L35579P02	Gasket
L35579P04	Gasket
L35579P05	Gasket
L35579P12	Gasket
L35579P19	Gasket
L36000G02	Sight, Flame
L37238P01	VBV Door
L37238P01 - AR	Hinge
L37239G02	VBV Door
L37239G02-AR	VBV DOOR
L37239G02-OH	VBV DOOR
L37241G01	Hinge
L38030G02	BAFFLE, ACOUSTIC, COMBUSTOR
L38060P02-AR	HP Sprint Nozzle
L38060P04-AR	HP Sprint Nozzle

## Starfish PPS - Complete Catalog

Part Number	Description
L38060P13	HP Sprint Nozzle
L38060P15	LP Inlet Sprint Nozzle
L38060P15-AR	LP Inlet Sprint Nozzle
L38060P16	HP Sprint Nozzle
L38060P18	LP Inlet Sprint Nozzle
L38165P07	NOZZLE, FUEL, DLE, PREMIXER, 2-CUP
L38165P07-OH	NOZZLE, FUEL, DLE, PREMIXER, 2-CUP
L38166P04	NOZZLE, FUEL, DLE, PREMIXER, 3-CUP
L38238P01	Gasket, Fuel Nozzle
L38238P01SR	Gasket, Fuel Nozzle, SEAL RING
L38240P06	Fuel Nozzle (Dual Fuel)
L38240P06-OH	Overhauled Fuel Nozzle (Dual Fuel)
L38240P07	Fuel Nozzle (Dual Fuel)
L38631P01	Nozzle, Fuel
L38631P01-AR	AS REMOVED, Nozzle, Fuel
L38631P01-OH	Overhauled Fuel Nozzle
L38756P01	Fuel Nozzle (Gas only)
L38756P03	FUEL NOZZLE (Gas only)
L38756P03-OH	FUEL NOZZLE, OVERHAULED (Gas only)
L3MF 100/200 IFOKTO-G	COUPLING
L3MF 100/200-AC	ASSEMBLY: PUMP & AC MOTOR
L3MF 80/132 IFOKTO-G	COUPLING
L3MF 80/132DC	ASSEMBLY: PUMP & DC MOTOR
L41143P02	Chip Detector
L42062P01	Bracket
L42070G01	Exhaust Wedge
L42092P04	TUBE
L42157G01	BRACKET
L42602P01	Seal
L42603P01	SEAL
L42604P01	Seal
L42635G01	Bracket
L42757P001A	BRACKET
L428120P02	CABLE
L42816G01	Bracket
L42818G01	Bracket
L42819G01	Bracket
L42821P01	Seal
L42835G01	ACOUSTIC BAFFLE
L42837P01	Seal
L42990P01	HOSE
L42990P01-AM	HOSE
L43014P03	Cable, T25
L43014P04	CABLE, T2/T25 RTD
L43014P05	CABLE, T2/T25 RTD
L43014P09	Cable, T25
L43014P10	CABLE, T2/T25 RTD
L43014P11	CABLE, T2/T25 RTD
L43019P03	CABLE, T3
L43019P04	CABLE, TC, DUAL, T3
L43019P05	CABLE, TC, DUAL

Starfish PPS - Complete Catalog

Part Number	Description
L43019P09	CABLE, T3
L43019P10	CABLE, TC, DUAL, T3
L43019P11	CABLE, TC, DUAL
L43020P02	CABLE, T44
L43020P08	Thermocouple Harness
L43031P01	Sensor, T21
L43064P07	NOZZLE, FUEL, LIQUID / WATER;
L43064P08	NOZZLE, FUEL, LIQUID / WATER;
L43064P09	NOZZLE, FUEL, LIQUID / WATER;
L43064P10	NOZZLE, FUEL, LIQUID / WATER;
L43073P01	GASKET, FLAME DETECTOR
L43324G03	Bell Crank
L43324G03 - AR	ACTUATOR, BELL CRANK
L43326G02	Bell crank
L43326G02-AR	BELL CRANK
L43326G02-OH	Bellcrank, OVERHAULED
L43339P01	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
L43339P02	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
L43340P01	CABLE, ELECTRICAL, IGV, LVDT, XM
L43340P02	CABLE, ELECTRICAL, IGV, LVDT, XM
L43341P02	Cable
L43342P01	CABLE, TEMP, LIQUID MANIFOLD
L43342P02	CABLE, TEMP, LIQUID MANIFOLD
L43342P03	CABLE, TEMP, LIQUID MANIFOLD
L43342P04	CABLE, TEMP, LIQUID MANIFOLD
L43345P01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
L43345P02	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
L43346P01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
L43346P02	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
L43347P01	CABLE, SPEED, GAS GENERATOR
L43347P02	CABLE, SPEED, GAS GENERATOR
L43347P03	CABLE, SPEED, GAS GENERATOR
L43347P04	CABLE, SPEED, GAS GENERATOR
L43348P02	CABLE, ELECTRICAL
L43350P02	Cable, T48 Lower Thermocouple Harness
L43351P02	Cable, T48 Upper Thermocouple Harness
L43352P01	CABLE, ELECTRICAL, VBV/VSV/LVDT; RIGHT- ON ENGI
L43352P02	CABLE, ELECTRICAL, VBV/VSV/LVDT; RIGHT- ON ENGI
L43356P04	CABLE, IGV/LVDT, RIGHT
L43356P05	CABLE, IGV/LVDT, RIGHT
L43356P10	CABLE, IGV/LVDT, RIGHT
L43356P11	CABLE, IGV/LVDT, RIGHT
L43357P04	CABLE, IGV/LVDT/XN2, LEFT
L43357P05	CABLE, IGV/LVDT/XN2, RIGHT
L43357P10	CABLE, IGV/LVDT/XN2, LEFT
L43357P11	CABLE, IGV/LVDT/XN2, RIGHT
L43358P03	CABLE, VBV/VSV/IGV
L43358P04	CABLE, VBV/VSV/IGV
L43358P09	CABLE, VBV/VSV/IGV
L43358P10	CABLE, VBV/VSV/IGV
L43359P04	CABLE, MANIFOLD TEMPERATURE
L43359P05	CABLE, MANIFOLD TEMPERATURE

<b>Part Number</b>	<b>Description</b>
L43359P10	CABLE, MANIFOLD TEMPERATURE
L43359P11	CABLE, MANIFOLD TEMPERATURE
L43360P04	CABLE, CHIP DETECTOR, A/B
L43360P05	CABLE, CHIP DETECTOR, A/B
L43360P10	CABLE, CHIP DETECTOR, A/B
L43360P11	CABLE, CHIP DETECTOR, A/B
L43361P03	CABLE, CHIP DETECTOR, C/D/E
L43361P04	CABLE, CHIP DETECTOR, C/D/E
L43361P09	CABLE, CHIP DETECTOR, C/D/E
L43361P10	CABLE, CHIP DETECTOR, C/D/E
L43362P02	CABLE, TEMP LUBE & SCAVENGE
L43362P03	CABLE, TEMP LUBE & SCAVENGE
L43362P04	CABLE, TEMP LUBE & SCAVENGE
L43362P05	CABLE, TEMP LUBE & SCAVENGE
L43362P08	CABLE, TEMP LUBE & SCAVENGE
L43362P09	CABLE, TEMP LUBE & SCAVENGE
L43362P10	CABLE, TEMP LUBE & SCAVENGE
L43362P11	CABLE, TEMP LUBE & SCAVENGE
L43363P03	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P04	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P05	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P09	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P10	CABLE, TEMP LUBE RTD, D&E SUMPS
L43363P11	CABLE, TEMP LUBE RTD, D&E SUMPS
L43364P04	CABLE, XN25 SPEED
L43364P05	CABLE, XN25 SPEED
L43364P10	CABLE, XN25 SPEED
L43364P11	CABLE, XN25 SPEED
L43365P03	CABLE, XNSD SPEED
L43365P04	CABLE, XNSD SPEED
L43365P05	CABLE, XNSD SPEED
L43365P09	CABLE, XNSD SPEED
L43365P10	CABLE, XNSD SPEED
L43365P11	CABLE, XNSD SPEED
L43367P03	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43367P04	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43367P05	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43367P09	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43367P10	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43367P11	CABLE, OFF-ENGINE, T/C, T48 - LOWER
L43368P03	CABLE, EGT THERMOCOUPLE, RIGHT
L43368P04	CABLE, EGT THERMOCOUPLE, RIGHT
L43368P05	CABLE, EGT THERMOCOUPLE, RIGHT
L43368P09	CABLE, EGT THERMOCOUPLE, RIGHT
L43368P10	CABLE, EGT THERMOCOUPLE, RIGHT
L43368P11	CABLE, EGT THERMOCOUPLE, RIGHT
L43369P04	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P05	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P10	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43369P11	CABLE, VBV/VSV-LVDT, RIGHT SIDE
L43370P04	CABLE, VBV/VSV/LVDT
L43370P05	CABLE, VBV/VSV/LVDT

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L43370P10	CABLE, VBV/VSV/LVDT
L43370P11	CABLE, VBV/VSV/LVDT
L43371P04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P05	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P06	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P10	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P11	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43371P12	CABLE, TEMP COMPRESSOR DISCHARGE, T3
L43379P04	BEARING
L43395P02	Clevis
L43398G01	Packing
L43416P02	T3 Sensor
L43418P02	ACTUATOR, VSV
L43418P02-OH	VSV Actuator
L43418P03	Actuator
L43418P03-OH	ACTUATOR, OVERHAULED
L43418P06	Actuator
L43418P07	Actuator
L43419P04	Actuator
L43419P07	Actuator
L43420P04	Actuator
L43420P07	Actuator
L43434P06	TRUNION
L43450P01	Igniter Plug
L43529G05	NOZZLE ASSEMBLY, HPT STAGE 2
L43529G07	NOZZLE ASSEMBLY, HPT STAGE 2
L43529G09	NOZZLE ASSEMBLY, HPT STAGE 2
L43529G11	NOZZLE ASSEMBLY, HPT STAGE 2
L43563P01	Mag Chip Detector
L43563P01-AR	DETECTOR, AS REMOVED
L43567G02	Bellcrank
L43616P01	BOLT
L43682P01	SPRING
L43778P01	Accumulator
L43885P01	ACCUMULATOR, HYDRAULIC
L44500P09	PUMP, LUBE AND SCAVENGE
L44500P09-OH	Pump, Lube and Scavenge (L&S)
L44500P12	L&S Pump
L44500P13	L&S Pump
L44500P13-OH	Overhauled L&S Pump
L44500P15	PUMP
L44500P17	PUMP, LUBE AND SCAVENGE
L44500P17-OH	PUMP, LUBE AND SCAVENGE
L44529P01	Staging Valve
L44538P01	GAS STAGING VALVE
L44538P01-AR	VALVE, AS REMOVED
L44538P01-OH	VALVE, STAGING, OVERHAULED
L44543P03	CABLE, T5.4, RIGHT
L44544P03	CABLE, T5.4, LEFT SIDE
L44550P01	Sensor, Dynamic
L44569P11	ASSEMBLY: PUMP, VSV
L44569P13	PUMP

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L44569P13-AR	PUMP; AS REMOVED
L44569P16	VALVE, SERVO
L44569P18	VALVE, SERVO
L44569P22	VALVE, SERVO
L44569P24	VALVE, SERVO
L44569P25	PUMP
L44569P25-AR	PUMP, AS REMOVED
L44569P31	ASSEMBLY: SERVO VALVE & PUMP
L44569P32	PUMP, VSV
L44569P32-OH	PUMP, OVERHAULED
L44569P35	ASSEMBLY: SERVO VALVE & PUMP
L44569P36	ASSEMBLY: SERVO VALVE & PUMP
L44569P38	ASSEMBLY: SERVO VALVE & PUMP
L44571P01	HYDRAULIC CONTROL UNIT
L44571P01-AR	HYDRAULIC CONTROL UNIT
L44571P01-OH	HYDRAULIC CONTROL UNIT
L44571P02	HYDRAULIC CONTROL UNIT
L44579P05	CABLE, ELECTRICAL, VSV/LVDT RIGHT/LEFT
L44579P07	CABLE, ELECTRICAL, VSV/LVDT
L44630P01	SENSOR, DUAL PT, SPEED
L44655P01	O-RING
L44680P01	Staging Valve
L44680P01-AR	Liquid Fuel Staging Valve - AS REMOVED
L44680P01-OH	Liquid Fuel Staging Valve - OVERHAULED
L44684P01	SENSOR, SPEED
L44705P04	CABLE, STAGING VALVES, LEFT
L44705P06	CABLE, STAGING VALVES, LEFT
L44705P10	CABLE, STAGING VALVES, LEFT
L44705P12	CABLE, STAGING VALVES, LEFT
L44706P04	CABLE, STAGING VALVES, RIGHT
L44706P06	CABLE, STAGING VALVES, RIGHT
L44706P10	CABLE, STAGING VALVES, RIGHT
L44706P12	CABLE, STAGING VALVES, RIGHT
L44707P01	Harness
L44707P03	Harness
L44709P01	HARNESS, ELECTRICAL
L44709P03	HARNESS, ELECTRICAL
L44715P02	CABLE, ELECTRICAL, IGV, LEFT
L44716P01	CABLE, ELECTRICAL, IGV, RIGHT
L44716P02	CABLE, ELECTRICAL, IGV, RIGHT
L44721P01	CABLE, T5:4, FOR 2 PROBES
L44721P02	CABLE, T5:4, FOR 2 PROBES
L44722P01	CABLE, T5.4, FOR 3 PROBES
L44722P02	CABLE, T5.4, FOR 3 PROBES
L44723P01	SENSOR, ACOUSTIC
L44723P03	SENSOR, ACOUSTIC
L44723P04	SENSOR, ACOUSTIC. PX36
L44735P01	CABLE, LPT, SPEED
L44735P02	CABLE, LPT, SPEED
L44735P03	CABLE, LPT, SPEED
L44735P04	CABLE, LPT, SPEED
L44735P05	CABLE, LPT, SPEED

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L44735P06	CABLE, LPT, SPEED
L44736P05	Cable, T48 Upper Thermocouple Harness
L44737P04	Cable, T48 Lower Thermocouple Harness
L44741P16	Bearing, Torque Arm, Rear
L44745P01	SENSOR
L44745P02	Sensor, T25
L44745P03	SENSOR
L44745P04	Sensor, T25
L44747P01	CABLE, FLAME SENSOR
L44755P01	ACTUATOR, VARIABLE
L44756P01	Speed Sensor
L44777G01	link
L44777G02	Connecting Link
L44777G03	VSV Link
L44777G04	Connecting Link
L44777G05	VSV Link
L44777G06	VSV Link
L44777G07	VSV Link
L44777G08	VSV Link
L44780P01	Sensor, speed
L44785P01	SENSOR
L44793P01	Mag Chip Detector
L44819P01	Flame Sensor
L44820P17	CABLE, UV FLAME DETECTOR
L44821P01	CAN, COOLING
L44827G04	Seal
L44830P01	T5.4/T4.4 T/C PROBE
L44830P02	Thermocouple T5:4
L44830P03	Thermocouple T5:4
L44860P01	HOUSING
L44860P02	HOUSING
L44861P01	HPC Bushing Stg 3/4
L44861P07	HPC Bushing Stg 5
L44862P02	HPC Bushing Stg 3/4 (Washer)
L44862P03	HPC Bushing Stg 5 (Washer)
L44867P01	HOUSING
L44867P02	HOUSING
L44867P03	HOUSING
L44867P04	HOUSING
L44920P01	Speed Sensor, Transducer
L44921P01	SENSOR, SPEED, DUAL
L44921P02	SPEED SENSOR, DUAL
L44951P01	BOOT SEAL
L44979P02	Bolt, CLV-TRQ Tube
L44982P01	EH Servo Valve for VSV ACTUATOR
L44983P01	Wiring Harness
L44984P01	P23/T23 SEN B - ES204 Harness
L44988P01	Harness, XNSD Speed
L44991P01	ACCUMULATOR, HYDRAULIC
L44991P01-AR	Accumulator, Hydraulic
L44991P01-OH	Accumulator, Hydraulic
L45045P01	BOLT

## Starfish PPS - Complete Catalog

Part Number	Description
L45063P13	Ring
L45066P01	RING
L45130G01	Bearing
L45135P03	Bushing
L45135P04	Bushing
L45137P01	Washer
L45525G01	TUBE, ASSY
L45529G01	Tube, Air
L45535G01	Manifold, upper
L45554G01-AR	TUBE
L45555G01-AR	TUBE
L45556G01-AR	TUBE
L45633G01	MANIFOLD
L45730G02	MANIFOLD, FUEL, PRIMARY, LEFT
L45731G02	MANIFOLD, FUEL, PRIMARY, RIGHT
L45732G02	MANIFOLD, FUEL, SECONDARY, LEFT SIDE, FOR NOX INJECTION
L45732G02-AR	MANIFOLD, FUEL, SECONDARY, LEFT SIDE, FOR NOX INJECTION - AS REMOVED
L45732G02-OH	MANIFOLD, FUEL, SECONDARY, LEFT SIDE, FOR NOX INJECTION
L45733G02	MANIFOLD, FUEL, SECONDARY, RIGHT SIDE, FOR NOX INJECTION
L45733G02-AR	MANIFOLD, FUEL, SECONDARY, RIGHT SIDE, FOR NOX INJECTION - AS REMOVED
L45733G02-OH	MANIFOLD, FUEL, SECONDARY, RIGHT SIDE, FOR NOX INJECTION
L45816P01	Hose
L45816P04	Hose
L45817P04	HOSE, STEAM
L45841G02	MANIFOLD, OIL - LUBE AND SCAVENGE
L45841G02-AR	MANIFOLD, AR
L45842G03	MANIFOLD, OIL
L45843P01	MANIFOLD, OIL
L45859G01	Bracket
L45881P01	Fuel Primary Hose
L45881P04	Fuel Primary Hose
L45882P04	Fuel Secondary Hose
L45921P01	GASKET, SPIRAL WOUND
L45921P10	GASKET, SPIRAL WOUND
L45924G01	Tube, Air
L45944G02	BRACKET, COMPRESSOR
L45946P001A	BRACKET
L45970G01	Fuel Tube
L45972G01	Fuel Tube
L45972G01-AM	Fuel Tube, Aftermarket
L45983P03	HOSE
L46017G03	Bracket
L46032P01	GASKET
L46055G05	BRACKET, ELECTRICAL
L46101G02	TUBE, OIL - VSV
L46109G02	MANIFOLD, OIL
L46110G01	MANIFOLD, OIL, SUPPLY
L46114P01	COVER, FLANGE

## Starfish PPS - Complete Catalog

Part Number	Description
L46116P01	Cover
L46131G02	TUBE, OIL - VSV
L46133G02	TUBE, OIL - VBV
L46152G01-AR	TUBE
L46192P001A	BRACKET, ULTRA VIOLET SENSOR
L46198G01	BRACKET
L46201G01	BRACKET
L46202G01	Bracket
L46203G01	Bracket
L46205G01	Bracket
L46219P01	PLATE
L46226G01	Bracket
L46408P03	HOSE
L46459G01	MANIFOLD, STEAM/FUEL
L46459G02	MANIFOLD, STEAM/FUEL
L46466G01	TUBE
L47022P02	BRACKET
L47045P16	CABLE, CRF ACCELEROMETER
L47045P19	CABLE, ACCELEROMETER
L47045P22	CABLE, CRF ACCELEROMETER
L47045P25	CABLE, ACCELEROMETER
L47045P26	CABLE, CRF ACCELEROMETER
L47046P04	CABLE, TRF ACCELEROMETER
L47046P10	CABLE, TRF ACCELEROMETER
L47046P15	CABLE
L47046P16	CABLE, TRF ACCELEROMETER
L47046P22	CABLE, TRF ACCELEROMETER
L47046P25	CABLE
L47046P26	CABLE, TRF ACCELEROMETER
L47072P01	CABLE, CHIP DETECTOR, A/B/COM
L47072P02	CABLE, CHIP DETECTOR, A/B/COM
L47073P01	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
L47073P02	CABLE, ELECTRICAL, CHIP DETECTOR, C/D/E
L47074P01	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT ON ENGINE
L47074P02	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT ON ENGINE
L471-02	SWITCH, FLOAT, LINC
L471-03	SWITCH, FLOAT, LINC
L47138P01	PIN
L47314P03	SENSOR, T3
L47314P04	SENSOR, T3
L47319P04	CABLE, TBV
L47319P05	CABLE, TBV
L47319P10	CABLE, TBV
L47319P11	CABLE, TBV
L47320P05	CABLE, 8TH STAGE BLEED VALVE
L47328P02	Valve
L47328P02-AR	VALVE, BLEED AIR, AS REMOVED
L47328P02-OH	VALVE, BLEED AIR, OVERHAULED
L47329P05	Valve, Bleed Air
L47329P05-AR	VALVE, BLEED AIR, AS REMOVED
L47329P05-OH	VALVE, BLEED AIR - OVERHAULED
L47330P04	Valve, Bleed Air

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L47330P04-AR	VALVE, BLEED AIR, AS REMOVED
L47330P04-OH	VALVE, BLEED AIR
L47372P01	PACKING
L47373P01	Thrust Balance Valve
L47400P02	Bushing
L47419P01	Spacer
L47419P02	Spacer
L47443P03	Thermocouple T5:4
L47444P03	Sensor, Temp
L47444P04	Sensor, Temp
L47444P05	Sensor, Temp
L47494P01	Seal
L47494P02	Seal, Retaining plate
L47494P03	Seal
L47593G04	Support
L47618P01	ASSEMBLY: SEAL RING
L47618P02	PLATE, RETAINER
L47618P03	RING, SEAL
L47805P03	RING, RETAINING
L47834P01	Seal
L47865P03	SPACER
L47865P04	SPACER
L47865P05	SPACER
L47865P06	SPACER
L47865P07	SPACER
L47865P08	SPACER
L47865P09	SPACER
L47865P10	SPACER
L47865P11	SPACER
L47865P12	SPACER
L47896P01	Bracket
L47910P01	PLUG
L47914P01	Seal
L47914P03	Seal
L47932G01	ADAPTER, STRUT END
L47937P01	PLATE
L47941G01	SPACER
L47963P01	PIN
L48119P01	Temperature Electrical Harness
L48120P02	CABLE
L48153P01	Hose
L49070P01	REDUCER TUBE
L49222P03	TUBE AND HOSE
L49237P03	TUBE AND HOSE
L49273P01	Hose
L49273P03	Hose
L49274P01	Fuel Secondary Hose
L49274P03	Fuel Secondary Hose
L49438P01	Orifice, Plate
L49438P02	Orifice, Plate
L49438P03	Orifice, Plate
L49438P04	Orifice, Plate

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L49438P05	Orifice, Plate
L49438P06	Orifice, Plate
L49438P07	Orifice, Plate
L49438P08	Orifice, Plate
L49438P09	Orifice, Plate
L49438P10	Orifice, Plate
L49438P11	Orifice, Plate
L49438P12	Orifice, Plate
L49438P13	Orifice, Plate
L49438P14	Orifice, Plate
L49438P15	Orifice, Plate
L50030P01	SENSOR, P2/T2
L50554G01	Bracket
L50621P01	Strip
L50621P03	Strip
L50621P04	Strip
L50621P07	Strip
L50621P08	Strip
L50622P01	Bracket, Bearing
L50631P02	Rod Body
L50643G01	Washer, thrust
L50655P03	Sleeve
L50661P04	Bushing, Sleeve
L50666G07	BRACKET
L50667G04	ASSEMBLY: BRACKET, BEARING
L50667G04 - AR	ASSEMBLY: BRACKET, BEARING
L51151G02	Tube
L51230G01	HOSE, AIR / OIL
L51268P03	TUBE & HOSE, CONVOLUTED
L51269P03	Hose, Convoluted
L51270P03	Hose, Convoluted
L51286G01	BRACKET
L51328P06	Clamp, Bracket
L51392G01	Bracket
L51399P01	COUPLING
L52030G01	TUBE, WATER
L52032G01	air tube
L52044G01	ADAPTER, FLANGE TO V BAND
L52044G01 - AR	Adapter, Flange to V Band
L52046P01	PLATE, ORIFICE
L52049P001	Plate, Orifice
L52049P01 - AR	PLATE, ORIFICE (0.600 IN ID)
L52073G01 - AR	TEE, FLANGE.
L52114P01	BOLT, MACHINE DBL HEX
L52143G01	VALVE
L52150G01	Tee
L52173G01	Bracket
L52174G01	Bracket
L52175G01	Bracket
L52176G01	Tube
L52177P01	Orifice, Plate
L52177P02	Orifice, Plate

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L52177P03	Orifice, Plate
L52177P04	Orifice, Plate
L52177P05	Orifice, Plate
L52177P06	Orifice, Plate
L52177P07	Orifice, Plate
L52177P08	Orifice, Plate
L52177P09	Orifice, Plate
L52177P10	Orifice, Plate
L52177P11	Orifice, Plate
L52177P12	Orifice, Plate
L52177P13	Orifice, Plate
L52177P14	Orifice, Plate
L52177P15	Orifice, Plate
L52177PXX	ORIFICE, PLATE
L52216G01	Bracket
L52241G01	BRACKET
L52242G01	BRACKET
L52619P01	ORIFICE
L52619P02	ORIFICE
L52619P03	ORIFICE
L52619P04	ORIFICE
L52619P05	ORIFICE
L52619P06	ORIFICE
L52619P07	ORIFICE
L52619P08	ORIFICE
L52619P09	ORIFICE
L52804G01	TUBE, OIL SCAVENGE
L52806P01	Adapter
L52809P001A	Bracket
L52814G01	MANIFOLD
L52815G01	LPT Cooling Manifold
L52840P01	ADAPTER, STRUT END
L53644P04	Washer
L54129P01	Hose, Fuel
L54129P01-AM	Hose, Fuel
L54129P02	Hose, Fuel
L54129P02-AM	Hose, Fuel
L54157P02	HOSE
L54157P02-AM	HOSE
L54659P01	Gasket
L56212G01	Door, VBV
L56830G02	TURBINE REAR FRAME - THRUST CONE
L56833P01	BRACKET
L56926P02	SEAL,AIR,STRUT
L56941P01	Seal
L57187P01	GASKET
L57196G01	MANIFOLD
L57365P01	Chip Detector Harness
L57366P01	Wiring Harness
L57367P01	Wiring Harness
L57368P01	Wiring Harness
L57369P01	Wiring Harness

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L57371P01	Wiring Harness
L57372P01	Wiring Harness
L57375P01	Harness, XNSD Speed
L57375P02	Harness, XNSD Speed
L57377P01	Wiring Harness
L57378P01	Wiring Harness
L57378P02	Wiring Harness
L57382P01	Wiring Harness
L57384P01	Probe, Pressure
L57386P01	T23/P23 SENSOR
L57386P03	T23/P23 SENSOR
L57387P02	Sensor, T3
L57389P01	Sensor, XNSD SP
L57390P06	Sensor, Speed
L57390P07	Sensor, Speed
L57390P08	Sensor, Speed
L57391P01	Speed Sensor, XN25
L57392P01	Sensor, speed
L57395P01	PUMP, LUBE AND SCAVENGE
L57395P01-AR	PUMP, LUBE AND SCAVENGE, AS REMOVED
L57395P01-OH	PUMP, LUBE AND SCAVENGE, OVERHAULED
L57611P01	Speed Sensor
L57620P01	C Seal
L57907P01	Joint, Elastic
L57924P01	HOSE
L59002G01	Connector Bridge
L59016P01	HARNESS, ELECTRICAL
L59017P01	HARNESS, ELECTRICAL
L59017P02	CABLE
L59020P02	Cable
L59029P01	Bearing
L59031P01	Wiring Harness
L59032P01	Wiring Harness
L59033P01	HARNESS, LOWER, T48
L59034P01	HARNESS, TC, UPPER
L59035	THERMOCOUPLE, T48
L59035P01	THERMOCOUPLE, T48
L59037P01	Gasket
L59039P01	P25/T25 Sensor Harness
L59039P02	P25/T25 Sensor Harness
L59041P01	P25/T25 Sensor Harness
L59041P02	P25/T25 Sensor Harness
L59053P01	Sensor, Speed
L59086P01	T3 Sensor
L59090P02	VALVE, BLEED AIR
L59090P02-AR	VALVE, BLEED AIR, AS REMOVED
L59090P02-OH	VALVE, BLEED AIR, OVERHAULED
L59091P04	Valve, Bleed Air
L59091P05	Valve, Bleed Air
L59092P03	Valve, Bleed Air
L59092P03-AR	VALVE, AS REMOVED
L59092P03-OH	Overhauled Bleed Air Valve

Starfish PPS - Complete Catalog

Part Number	Description
L59095P01	SENSOR, SPEED
L59096P03	Cable, Speed, Right
L59096P04	Cable, Speed, Left
L59341G01	Retainer, spring
L61119P01	Wiring Harness
L61120P01	Wiring Harness
L61140G01	TUBE
L61209P01	Wiring Harness
L61210P01	Wiring Harness
L61437P01	NUT, COUPLING LPTS
L61450P01	T23/P23 SENSOR
L61450P02	T23/P23 SENSOR
L61566G01	Tube, air
L61813G01	BAFFLE
L61839P02	Speed Sensor
L61842G02	VALVE, CHECK
L61843G01	TUBE
L61883P01	Spacer
L61917P01	Gasket
L61951P01	Pin
L62120G01	Crossover Tube
L62163P01	NOZZLE, FUEL, LIQUID / WATER
L62322G01	TUBE
L62381P01	Gasket, Clutch to AGB
L62451G01	TUBE, D SUMP, IPT FRAME STRUT 9
L62629P01	SLV, SFT-FWD BRG
L62630P01	Bushing
L62631P01	BEARING, PLAIN, AFT MOUNT
L62634G01	BRACKET, BEARING TORQUE SHAFT, AFT
L62745G01	8th Stage Tube
L62762P01	GASKET
L62770P01	Shim
L62774P01	Check Valve
L62868P01	HOUSING, DRIVE SHAFT
L63392P01	HOSE, FUEL, GAS
L63397P01	SEAL RING
L63585P01	Exciter, Ignition
L63592P01	DAMPER
L63592P02	DAMPER
L63593P01	DAMPER
L63671P01	NOZZLE, FUEL 3-CUP DLE+
L63754P01	GAS STAGING VALVE
L63754P01-AR	GAS STAGING VALVE, AS REMOVED
L63754P01-OH	GAS STAGING VALVE - overhauled
L63875P01	Clamp
L63957G01	BRACKET
L63965G06	ARM
L63985G01	BRACKET, HINGE
L63985G02	BRACKET, HINGE
L63985G03	Bracket
L65081P01	CLAMP
L69800P01	Bushing, Stage 3 and 4

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
L69800P02	Bushing, Stage 5
L6EPB-B-S-3-C	SWITCH, FLOAT
L70999P01	Support Assembly
L71550P01	Liquid Fuel Staging Valve
L71550P01-AR	Liquid Fuel Staging Valve - AS REMOVED
L71550P01-OH	OH Liquid Fuel Staging Valve
LA-5-C-MA-9	Linear Link
LA-5-C-MA-FCFP	Flow Meter, linear link
LEV015.53.11101	Portable pH/ORP/mV Meter
LF16015	FILTER, WATER SEPERATOR
LG1093AA24	Scanner, Flame
LG1093AA25	Scanner, Flame
LG1093AA26	Scanner, Flame
LG1093AA36	Scanner, Flame
LG1093AA44	Flame Scanner
LG1093AA45	Flame Scanner
LG1093AA46	Scanner, Flame
LG1093AB01	FLAME SENSOR, UV
LG1093AC01	SENSOR, FLAME
LG1093AC05	Flame Sensor UV
LG1237CD04	PRESSURE TRANSDUCER
LIC022A-R3	Multipower Industrial Media Converter
LIT777-P2	3 PHASE OLR/200-480V/2-800 FLA+
LITRS485MS-2W	COMMUNICATIONS MODULE
LM-5000-1200	FOD Sock
LM6000-NMO1200	FOD Sock
LN-5-C-MA-FCFP	METER, FLOW, LINEAR LINK
LOCTITE 243	Thread Lock
LPIN	Locking Pin, 1/8", 321SS
LPRD00-00008306	PRESSURE RELIEF DEVICE
LR47190	Pump, Lube and Scavenge
LR60407	Directional Control Valve
LS1900-2-SP-CE	SWITCH, LEVEL
LSP51-08	Flow Sight
LU240	Probe, Level
LV471-03-05	TLO Tank Level Switch
LW18440	Sensor, Speed RB211
LW19356	Probe, OH Temp
M029.AD-V-1-1-29-04	ADAPTER GLAND, 1/2 INCH MNPT-20MM FEMALE
M12X50MM	Pin
M13000208-0185	HOSE
M13000212-0110	Tube
M161-BT-CA1	Pump
M16X80MM	Pin
M18000104-0380	Hose Assembly
M19-67	PLUG, BORESCOPE, HPT, STG1
M22759/16-12	GROUND CABLE
M22759/16-12-9	GROUND CABLE
M22759/16-14	GROUND CABLE
M22759/16-14-9	Wire
M22759/16-4-5	GROUND CABLE
M22759/16-6-5	GROUND CABLE

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
M25988-3-110	O-RING
M25988/2-020	O-RING
M25988/2-120	O-RING
M25988/2-139	O-RING
M25988/2-218	O-RING
M25988/2-224	O-RING
M25X3/4	Flame Sensor Conduit Adapter
M270N6	Coupling Insert
M6706015	GASKET
M6709490	SCREEN, REPLACEMENT, 100 MESH
M6710542	Basket for Mueller 125 Strainer
M6716930	Plug
M6718132	Y-STRAINER
M6722689	Gasket
M6724139	Y STRAINER GASKET
M770H5	COUPLING INSERT, MAGNALOY
M83248/1-006	O-RING
M83248/1-007	O-RING
M83248/1-008	O-RING
M83248/1-009	O-RING
M83248/1-010	O-RING
M83248/1-011	O-RING
M83248/1-012	O-RING
M83248/1-013	O-RING
M83248/1-014	O-RING
M83248/1-015	O-RING
M83248/1-016	O-RING
M83248/1-017	O-RING
M83248/1-018	O-RING
M83248/1-019	O-RING
M83248/1-020	O-RING
M83248/1-021	O-RING
M83248/1-022	O-RING
M83248/1-023	O-RING
M83248/1-026	O-RING
M83248/1-028	O-RING
M83248/1-029	O-RING
M83248/1-030	O-RING
M83248/1-031	O-RING
M83248/1-034	O-RING
M83248/1-035	O-RING
M83248/1-036	O-RING
M83248/1-037	O-RING
M83248/1-042	O-RING
M83248/1-043	O-RING
M83248/1-044	O-RING
M83248/1-050	O-RING
M83248/1-110	O-RING
M83248/1-112	O-RING
M83248/1-113	O-RING
M83248/1-114	O-RING
M83248/1-115	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
M83248/1-116	O-RING
M83248/1-117	O-RING
M83248/1-118	O-RING
M83248/1-119	O-RING
M83248/1-120	O-RING
M83248/1-121	O-RING
M83248/1-122	O-RING
M83248/1-123	O-RING
M83248/1-124	O-RING
M83248/1-125	O-RING
M83248/1-126	O-RING
M83248/1-128	O-RING
M83248/1-129	O-RING
M83248/1-130	O-RING
M83248/1-131	O-RING
M83248/1-132	O-RING
M83248/1-134	O-RING
M83248/1-135	O-RING
M83248/1-137	O-RING
M83248/1-138	O-RING
M83248/1-139	O-RING
M83248/1-140	O-RING
M83248/1-141	O-RING
M83248/1-143	O-RING
M83248/1-145	O-RING
M83248/1-148	O-RING
M83248/1-150	O-RING
M83248/1-151	O-RING
M83248/1-152	O-RING
M83248/1-153	O-RING
M83248/1-155	O-RING
M83248/1-156	O-RING
M83248/1-159	O-RING
M83248/1-160	O-RING
M83248/1-161	O-RING
M83248/1-163	O-RING
M83248/1-165	O-RING
M83248/1-166	O-RING
M83248/1-169	O-RING
M83248/1-170	O-RING
M83248/1-175	O-RING
M83248/1-176	O-RING
M83248/1-210	O-RING
M83248/1-212	O-RING
M83248/1-213	O-RING
M83248/1-214	O-RING
M83248/1-215	O-RING
M83248/1-216	O-RING
M83248/1-218	O-RING
M83248/1-219	O-RING
M83248/1-220	O-RING
M83248/1-222	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
M83248/1-223	O-RING
M83248/1-224	O-RING
M83248/1-225	O-RING
M83248/1-226	O-RING
M83248/1-228	O-RING
M83248/1-229	O-RING
M83248/1-230	O-RING
M83248/1-231	O-RING
M83248/1-232	O-RING
M83248/1-234	O-RING
M83248/1-235	O-RING
M83248/1-236	O-RING
M83248/1-237	O-RING
M83248/1-238	O-RING
M83248/1-240	O-RING
M83248/1-241	O-RING
M83248/1-242	O-RING
M83248/1-243	O-RING
M83248/1-244	O-RING
M83248/1-245	O-RING
M83248/1-247	O-RING
M83248/1-252	O-RING
M83248/1-255	O-RING
M83248/1-258	O-RING
M83248/1-260	O-RING
M83248/1-261	O-RING
M83248/1-262	O-RING
M83248/1-263	O-RING
M83248/1-264	O-RING
M83248/1-265	O-RING
M83248/1-266	O-RING
M83248/1-269	O-RING
M83248/1-270	O-RING
M83248/1-278	O-RING
M83248/1-279	O-RING
M83248/1-283	O-RING
M83248/1-324	O-RING
M83248/1-330	O-Ring
M83248/1-341	O-RING
M83248/1-344	O-RING
M83248/1-349	O-RING
M83248/1-390	O-RING
M83248/1-429	O-RING
M83248/1-433	O-RING
M83248/1-437	O-RING
M83248/1-444	O-RING
M83248/1-902	O-RING
M83248/1-903	O-RING
M83248/1-904	O-RING
M83248/1-905	O-RING
M83248/1-906	O-RING
M83248/1-908	O-RING

Starfish PPS - Complete Catalog

Part Number	Description
M83248/1-910	O-RING
M83248/1-912	O-RING
M83248/1-914	O-RING
M83248/1-916	O-RING
M83248/1-920	O-RING
M83248/1-924	O-RING
M83248/1-954	O-RING
M83248/1-975	O-RING
M83248/1-977	O-RING
M83248/2-014	O-Ring
M83248/2-019	O-Ring
M83248/2-114	O-RING
M83248/2-116	O-RING
M83248/2-117	Oring
M83248/2-133	O-Ring
M83248/2-209	O-RING
M83248/2-210	O-RING
M83248/2-214	O-RING
M83248/2-219	O-RING
M83248/2-222	O-RING
M83248/2-225	O-RING
M83248/2-228	O-RING
M83248/2-255	O-RING
M83248/2-332	O-RING
M83248/2-337	O-Ring
M83248/2-342	O-RING
M83248/2-437	Gasket, Filter Housing Cover
M83723/95G1005N	CABLE, TEMP, HYD STARTER CLUTCH OIL
M870N8	Coupling Insert, Neoprene
M95H-3063-3371493	REGULATOR
M95L-3068-9348174	Air Pressure Regulator
MA3286-200052	BOLT
MCC1401E100H13	CARTRIDGE, FILTER
MCD200-18101	Thyristor, Diode Module, VSR
MCD50	I/O Bus & power extension module
MCD51	I/O Bus & power extension module
MDD56-16N1B	DIODE PACK
METRIC BOLT	METRIC BOLT KIT, DO NOT DISCARD
METRIC BOLT, NEED FOR INSTALLATION	METRIC BOLT KIT, DO NOT DISCARD
MF9639LKPSS	Cap, Filler
MICSSEP0001	ASSEMBLY: MAVR MICRO AVR
MJ-FJS-90D	FITTING
MJ-MB-90D	FITTING
MK102C616VVN3/4T6A	VALVE, SOLENOID
MK252C6100TTN11/2T6AY	VALVE, SOLENOID
MLLEDA42CD5BU	LED Light Fixture
MO015430570	Gasket, Filter Housing Cover
MPU50	General controller/Communication controller/ACU
MPU50/51/52	General controller/Communication controller/ACU
MPU51	General controller/Communication controller/ACU
MPU52	General controller/Communication controller/ACU
MR105	NOx Water Pup Regulator

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
MR95L	REGULATOR, 3/4"
MS-T5544	Anti-Seize
MS122903	CLAMP
MS122907	Clamp, Loop
MS122909	Clamp, Loop
MS122926	CLAMP, LOOP
MS124662	INSERT, HELICOIL
MS124702	INSERT, HELICOIL
MS124741	INSERT, HELICOIL
MS124821	INSERT, HELICOIL
MS14103-5	BEARING
MS16555-682	PIN
MS16555-688	PIN
MS16555-689	PIN
MS16555-701	PIN
MS16555-702	PIN, STRAIGHT HEADLESS
MS20427F4-9	RIVET
MS20500-428	NUT, SILVER PLATED
MS20500-624	NUT, LOCK
MS20756-24	GASKET, FLANGE SEAL
MS21043-06	NUT
MS21043-3	NUT
MS21046C10	Nut, .6250-18 UNJF-3B
MS21046C14	NUT, SS, ENGINE MOUNT
MS21046C4	NUT, 6 PT, SILVER PLATED
MS21046C5	Nut
MS21046C8	NUT
MS21060-4	NUT
MS21062-4	NUTPLATE
MS21076-4	NUTPLATE
MS21076L4N	NUT, SELF-LOCK
MS21083C4	Nut, SS Lock, 1/4
MS21083C5	Nut, SS Lock
MS21914-4J	FITTING
MS21914-5J	FITTING
MS22759/16-10-9	Wire
MS22759/16-12-9	Wire
MS22759/16-14-54	CABLE, 16AWG
MS22759/16-18-9	Wire
MS24391J4L	PLUG
MS24693-C272	SCREW
MS24693-C273	SCREW, MACHINE, FLATHEAD
MS24693-C342	SCREW
MS27116-15B	CLAMP, V-BAND, RETAINER
MS27194-20	Gasket
MS27196-12	Gasket
MS27196-16	Gasket
MS27196-20	Gasket
MS27196-24	Gasket
MS27196-32	Gasket
MS27196-40	Gasket, Seal-Flange
MS27196-48	Seal

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
MS28774-228	Backup Ring
MS29513-013	O-RING
MS3106F20-27S	Plug, free, 14 way
MS3367-4-9	STRAP
MS35275-215	Screw
MS35275-230	SCREW
MS35275-240	Screw
MS35307-414	BOLT, HEX SS
MS35649-2254	Nut
MS35842-12	Clamp Hose
MS35842-13	Clamp Hose
MS35842-14	Clamp, Hose
MS35842-15	Clamp Hose
MS51525B6S	FITTING
MS51830CA202	Insert
MS51830CA202L	INSERT
MS51831-201	INSERT
MS51832-202	INSERT
MS51914-6J	FITTING
MS9025-10	CLAMP
MS9025-20	CLAMP
MS9025-28	CLAMP
MS9061-08	BCan Sleeve Bolts
MS9141-12	Gasket
MS9141-15	Gasket
MS9193-04	CONNECTOR
MS9197-12	NUT
MS9201-02	Nut
MS9201-03	Nut
MS9201-04	Nut
MS9202-042	Gasket, Metal
MS9204-151	Gasket
MS9209-16	BOLT
MS9217-05	BOLT
MS9218-12	BOLT, MACHINE
MS9276-10	WASHER, KEY
MS9276-14	WASHER, KEY
MS9315-04	CAP
MS9315-04 AR	Cap
MS9315-05	Cap
MS9315-08	CAP
MS9315-10	CAP
MS9315-10-AR	Cap
MS9315-12	CAP
MS9315-12 - AR	CAP
MS9321-09	Washer
MS9321-10	Washer
MS9321-12	WASHER
MS9371-15	Gasket
MS9371-16	GASKET
MS9372-029	Gasket

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
MS9373-020	SEAL RING
MS9373-021	SEAL RING
MS9373-023	SEAL RING
MS9373-029	Seal Ring
MS9373-035	Gasket
MS9373-041	Gasket
MS9373-045	GASKET
MS9373-055	Gasket
MS9373-061	GASKET
MS9375-035	Gasket, Ring
MS9375-038	Gasket, Ring
MS9375-047	Gasket, Ring
MS9375-071	GASKET, RING
MS9386-111	PACKING, PREFORM, O RING
MS9386-261	PACKING, PREFORM, O-RING
MS9388-210	O-RING
MS9388-219	Packing, O RING
MS9388-222	O-RING
MS9388-228	O-RING
MS9388-241	O-RING
MS9390-090	PIN
MS9404-04	Plug
MS9489-05	Bolt
MS9489-06	Bolt
MS9489-07	Bolt
MS9489-08	BOLT
MS9489-09	BOLT
MS9489-12	Bolt
MS9489-14	BOLT, MACHINE, HEX HEAD
MS9490-08	Bolt
MS9490-09	Bolt
MS9490-10	Bolt
MS9490-11	Bolt
MS9490-12	Bolt
MS9490-13	Bolt
MS9490-15	BOLT
MS9490-16	Bolt
MS9490-17	Bolt
MS9490-18	Bolt
MS9490-20	BOLT
MS9490-21	Bolt
MS9490-22	BOLT, HEX
MS9490-23	BOLT, SS, 6 PT
MS9490-24	BOLT, SS, 6 PT
MS9490-26	BOLT, HEX
MS9491-13	BOLT
MS9491-15	Bolt
MS9491-18	Bolt
MS9491-20	Bolt
MS9491-22	BOLT
MS9491-24	BOLT
MS9501-07	Bolt

Starfish PPS - Complete Catalog

Part Number	Description
MS9501-12	Bolt
MS9501-17	Bolt
MS9556-04	Bolt, Machine DBL Hex
MS9556-06	Bolt
MS9556-07	BOLT
MS9556-09	BOLT, MACHINE
MS9556-10	Bolt, Machine DBL Hex
MS9556-14	BOLT, MACHINE
MS9556-18	BOLT
MS9557-06	BOLT
MS9557-07	Bolt, Machine DBL Hex
MS9557-08	Bolt, Machine DBL Hex
MS9557-09	BOLT, MACHINE, DBL HEX
MS9557-10	BOLT, ENG CABLE, 5/8"
MS9557-11	BOLT
MS9557-12	Bolt, Machine DBL Hex
MS9557-13	Bolt, Machine DBL Hex
MS9557-14	BOLT, MACHINE
MS9557-15	Bolt, Machine DBL Hex
MS9557-16	BOLT, MACHINE
MS9557-17	Bolt, Machine DBL Hex
MS9557-18	Bolt, Machine DBL Hex
MS9557-19	Bolt, Machine DBL Hex
MS9557-20	Bolt, Machine DBL Hex
MS9557-22	BOLT, MACHINE, DBL HEX
MS9557-23	BOLT, MACHINE, DBL HEX
MS9557-25	BOLT, MACHINE, DBL HEX
MS9557-26	BOLT
MS9557-28	BOLT, MACHINE, DBL HEX
MS9557-31	BOLT, MACHINE, DBL HEX
MS9557-32	BOLT, MACHINE, DBL HEX
MS9557-35	BOLT, MACHINE, DBL HEX
MS9557-38AR	BOLT, AS REMOVED
MS9558-08	BOLT
MS9558-12	BOLT, MACHINE
MS9558-13	Bolt, Machine DBL Hex
MS9558-14	Bolt, Machine DBL Hex
MS9558-16	BOLT, MACHINE, DBL HEX
MS9558-17	BOLT, MACHINE, DBL HEX
MS9558-18	Bolt, Machine DBL Hex
MS9558-24	BOLT
MS9558-3	Bolt
MS9558-32	Bolt, Machine DBL Hex
MS9565-04	Bolt, Machine DBL Hex
MS9565-05	Bolt, Machine DBL Hex
MS9565-14	Bolt, Machine DBL Hex
MS9565-17	Bolt, Machine DBL Hex
MS9566-06	Bolt
MS9566-09	Bolt, Machine DBL Hex
MS9566-10	Bolt, Machine DBL Hex
MS9566-12	Bolt, Machine DBL Hex
MS9566-16	Bolt, Machine DBL Hex

## Starfish PPS - Complete Catalog

Part Number	Description
MS9566-18	BOLT
MS9566-20	BOLT, MACHINE, DBL HEX
MS9566-21	Bolt, Machine DBL Hex
MS9566-22	Bolt, Machine DBL Hex
MS9566-27	Bolt, Machine DBL Hex
MS9566-31	Bolt, Machine DBL Hex
MS9566-33	BOLT, MACHINE, DBL HEX
MS9566-37	Bolt, Machine DBL Hex
MS9567-14	Bolt, Machine DBL Hex
MS9901-08 - AR	PLUG
MS9902-03	Plug, Borescope
MS9902-04	PLUG
MS9902-05	Plug, Borescope
MS9902-06	Plug
MS9902-08	PLUG
MS9902-10	PLUG
MS9902-20	PLUG, FLARELESS
MS9953-05	PLUG
MS9966-06	Packing - Preformed, Boss
MS9966-07	Packing
MS9966-10	Packing, O RING
MS9966-16	Packing - Preformed
MS9967-020	O-RING
MS9967-036	O-RING
MS9967-116	Packing
MS9967-120	O-RING
MS9967-139	O-RING
MS9967-224	O-RING
MSM0004-AM	HOSE
MT100HP	Motor, TCF Aerovent
MT125HP	Motor, TCF Aerovent
MT125HP-OH	OVERHAULED Motor, TCF Aerovent
MTL728	DIODE, SHUNT
MTL728+	DIODE, SHUNT
MTL7729+	BARRIER, SHUNT-DIODE, SAFETY
MTL7796+	SHUNT DIODE, SAFETY
MVAJ053RA0802B	RELAY, TRIPPING, AREVA
Magnalloy200	Coupling
N14AP27064	Screw
N14P33036	Bolt
N14P33044	Bolt
N14P33048	Bolt
N14P35064	Screw
N14P35072	Screw
N14TP33036	Bolt
N14TP39080	Bolt
N170CP35032	Bolt
N170P25012	Screw
N170P39036	Bolt
N171P25014	Screw
N173P2312	SCREW, SET
N213P00044	Nut

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
N227P00033	NUT
N22BP29016B	Bolt
N22BP29020B	Bolt
N22BP35036B	BOLT
N22P21013	BOLT, HEX HEAD
N22P21016M11	SCREW, HEX HEAD
N22P250012	SCREW
N265BP00021	LOCK NUT
N265BP33	Nut
N265BP35	Nut
N271TP00039	NUT, 12 POINT
N271TP00044	Nut
N271TP00050	Nut
N271TP39	Nut
N2720P00039	Nut
N272QP00033	Nut, Lock
N272QP00039	NUT, LOCK
N272QP00044	Nut
N272QP00052	Nut
N400BP11	WASHER
N400P41	Washer
N4021-01NC	Pre Amp
N402P18	Washer
N405P00050	Lock Plate
N406P42	Washer, Lock
N500P1108	Pin
N5605P12001G1	Gasket
N5606P04001G11	GASKET, SPIRAL WOUND
N5606P04003G11	Gasket
N5606P05001G11	GASKET, SPIRAL WOUND
N5606P14001G11	Gasket
N58P17012	Screw
N58P21010	SCREW,MACHINE
N60CP44076	BOLT, LP INNER SHELL
N60HP33036	SCREW, HEX HEAD
N646P23012	Cap Screw
N646P25020	SCREW, CAP
N646P29020	Screw
N733AP21012	1/4-20 X 3/4 B16 12 POINT
N733AP25020	Screw
N733AP33052	Bolt
N733AP33064	Bolt
N733AP35036	Bolt
N733AP39048	Bolt
N733AP39072	Bolt
N733AP39144	BOLT, 12 POINT
N733AP50096	BOLT, 12 POINT
N733BP44104	BOLT
N733DP33028	BOLT
N733DP33036	BOLT
N733P28032	Bolt
N733P39064	SCREW, 12 POINT

## Starfish PPS - Complete Catalog

Part Number	Description
N733P39088	SCREW, 12 POINT
N733P44072	Bolt
N733P50096	Bolt
N756AP37068	Bolt
N926BP00450	Insert
N926BP329	Insert
NAS1102E3-8	SCREW
NAS1102E4-10	SCREW
NAS1149C0332R	Washer
NAS1149C0432R	Washer, Flat
NAS1149C0532R	WASHER
NAS1149C0632R	Washer
NAS1149C0832R	Washer; 1/2
NAS1149C1290R	Washer
NAS1291C8M	NUT
NE05023504NHXGE	AC
NE06023504NHXGE	AC, Panel
NE06023604C2G2H3M11WGG	AC, CABINET
NE06023604EHAGE	AC, CABINET
NEXUS 1250-4	RTU, Power Quality, Revenue Meter
NK1000063V250	Viton Gasket
NMO-1200-LM6000	FOD Sock
NMO-2000-LM2500	FOD Sock
NPS 1 1/2 EDR 655 Size 3B	Pressure Control Valve
NPS 1 MR98HH	Pressure Unloading Valve
O-RING-8.975IN-REP	Filter Head Gasket, Replacement
OFS-820X-12B	Filter, Fuel, Liquid
OFS-820X-3B	Filter, Liquid, 5uM
OFS820X12B	Filter, Fuel, Liquid
OFS820X3B	Filter, Liquid, 5uM
OR-SuperGlue	O-Ring Glue, 1oz Bottle
P-010-P4-IP	FILTER
P0000051006006	GASKET, SPIRAL WOUND
P0000051008001	GASKET, SPIRAL WOUND
P030648-016-190	HEPA Final Filter
P034-2308	Valve
P105534	Elbow
P1202804001	FILTER, OIL
P126530	Reducer
P128990	Elbow
P13-2582	Fuse
P15-6458	Program Control
P16-5332	Hydraulic Filter Element
P16-5354	Hydraulic Filter Element
P16-5659	Filter, Element
P16-7183	FILTER, HYDRAULIC, CARTRIDGE
P16-7185	Hydraulic Filter, Jacking Oil Discharge
P162696	INDICATOR, FILTER (P16-2696)
P165332	Hydraulic Filter Element
P165354	Hydraulic Filter Element
P165659	Filter, Element
P165882	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
P165965	INDICATOR
P166134	Blanking Plate/Block
P166603	Visual Bar Indicator
P167183	FILTER, HYDRAULIC, CARTRIDGE
P167185	Hydraulic Filter, Jacking Oil Discharge
P167412	Filter
P169985	Head, Dual Filter
P17-6567	FILTER, ELEMENT
P176567	FILTER, ELEMENT
P179075	Element, filter
P19-1129	Filter
P19-1469	Filter
P33Z70	VARISTOR, RADIAL
P553771	FILTER, LUBE
P564468	Element, filter
P566338	FILTER, VBV
P9B10VN	Block, Contact
PA-39946960	Pressure Transmitter
PA3000-500-48-13-21-00-93	Pressure Transmitter
PA3000-500-48-13-21-01-93	TRANSMITTER, PRESSURE
PA92146900	
PC-T400	Cable, Interface
PCV50071	1.5" VALVE
PD1-A734-A2-R01	PUMP
PDFP1000A25V32P	Fuse
PDM4723	BOOT, INSUL
PDMC10SS50P36IN	RIBBON CABLE, 36" SOC-SOC 50-PIN
PDPS100M200P310	EMI Suppression Core
PDSB10A05P2RLCB	CIRCUIT BREAKER
PF1	SWITCH, DIGITAL NO FLOW
PG-2S25-2B-FPLSG	Differential Pressure Gauge for Liquids
PH312	Filter Elements
PH312-01-CG	Filter Element
PH312-11-CG	Filter Element
PH312-12-CGV	Nitrogen Supply Filter
PH404-12-CG	Filter
PH414-10-CG	Filter
PH414-12-CGV	Filter Element
PH518-12-CG	FILTER, ELEMENT, 3 MICRON, GLO
PH718-01-CNVGE	Filter Element
PH718-03CN	Mineral Oil Filter
PH730-01-CG1VGE	Filter Element
PH739-05-CGJ	Cartridge Filter
PH739-11-CGV	Filter
PIRECLA1A1W1	Detector, Gas
PIRECLA4A2W1	PIRECL Infrared Hydrocarbon Gas Detector
PIRECLB1A1W1	Detector, gas
PIRECLB1D1T2	Gas Detector
PIRECLB4A2W1	Gas Sensor
PJ36	NOZZLE, AMMONIA
PK-IS420ESWBH1A	Switch Kit
PK0027-00	AT10 Auxilary Relay Alarm Board

Starfish PPS - Complete Catalog

Part Number	Description
PL718-05-CN	ELEMENT, FILTER CARTRIDGE, CONDENSATE
PLP10.2D0-81E1-LGC/GC-N-EL	Pump
PLSOFT-COM1	Visualization & Analysis Software for EPM Meters, 1 year li
PLSOFT-COM5	Visualization & Analysis Software for EPM Meters, 5 year li
PLW375x156	Pantleg Washer, 0.375" x 1.5625"
PM1-5E1-XD3	HMI, BENTLY NEVADA
PM180-G-A-60Hz-1-ACDC-21DC180	Multi-Function Power & Energy Meter
PM180-G-A-U-60Hz-5-ACDC-TXFX-180-21DC180	Multi-Function Power & Energy Meter
PM296	SATEC, POWER ANALYZER
PM6C3CA-AAAAP12	SWITCH, TEMPERATURE
POC550G0800S	HV Bushing Assembly
POWIRCUT-1/4"	GLASS, WIRED
POWLUBE-104	CHEMICAL,PETROLEUM BASED,LUBRICANT,POWLVAO KIT
PQMII-T20-C Passcode	-A Passcode
PQMII-T20-C-A	Power Quality Meter
PR440238	Ring
PRS09i-10T	Regulator, Sprint
PRS09i-20A	Regulator, Water
PRS09i-20A-KIT	Regulator Seal Kit
PS24-150	POWER SUPPLY; MARK VI
PS24-500DC-DC	POWER SUPPLY; MARK VI
PSX/006164F	Filter, Air, Gen 8
PTG5-1-110-SD03422F	Transformer
PTG5-1-110-SD03559F	TRANSFORMER
PTG5-110-SD03726-F	TRANSFORMER, VOLTAGE, BIL110kV
PTG5-2-110-1442FF	Transformer
PTP-2	HANGER, SPRING
PTW5-1-110-SD02552F	VOLTAGE TRANSFORMER 11000 VOLTS
PTX 611	4-20mA 600 psi abs. 9-30V dc
PTX59J2-150PSI	TRANSMITTER, PRESSURE
PTX59J2-2000PSI	TRANSMITTER, PRESSURE
PTX59J2-300PSI	TRANSMITTER, PRESSURE
PTX59J2-500PSI	TRANSMITTER, PRESSURE
PTX59J2-600PSI	TRANSMITTER, PRESSURE
PTX59J2-70PSI	TRANSMITTER, PRESSURE
PTX59J2-TD-A1-CA-HT-PP-150PSIG	Transmitter, Pressure
PTX59J2-TD-A2-CA-HT-RP-300PSI	TRANSMITTER, PRESSURE
PTX59J2-TD-A2-CA-HT-RP-600PSI	TRANSMITTER, PRESSURE, PS3
PTX651-1000ABS	TRANSMITTER, PRESSURE
PTX651-300ABS	TRANSMITTER, PRESSURE
PTX651-500ABS	TRANSMITTER, PRESSURE
PTX651-600ABS	TRANSMITTER, PRESSURE
PTX651-700ABS	TRANSMITTER, PRESSURE
PTX651-70ABS	TRANSMITTER, PRESSURE
PW1772D32001	Ignitor
PW668B535001	SCANNER, FLAME
PWA85435-01	Power Terminal
PWC50370	Socket
PWC50370-2	Socket
PWT/120AC	WATT TRANSDUCER
PX780	UNION, ALUMINUM, 1/2"

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
Pin, Clevis	Front Stachion Clevis Pin
Pressure Blower	Blower Assembly
Pressure Blower Impeller-CCW	Impeller
Pressure Blower Impeller-CW	Impeller
Puller, Speed Sensor	Speed Sensor, Removal Slide Hammer
Q0241504G511C	EnerGenius IQ2 Battery Charger
Q0241504G512C	CHARGER, BATTERY, 230VAC
Q468-5000	TRANSDUCER, VOLTS LM SERIES
Q478-0000	Signal conditioner
Q478-5002	Signal conditioner
Q478-5003	Signal conditioner
Q478-5004	Signal conditioner
Q501-2B00	2 Channel, 4/20 mA I
QA3VAI	QUICK EXHAUST VALVE, 3/8" VITON SEALS
QU3	QUICK EXHAUST VALVE, 3/8" VITON SEALS
QUINT-PS-100-240AC/24DC/10	Power Supply
QX2GE02SRA	Fire System CO2 Block Limit Switch
QX2HE02SRA	Fire System CO2 Block Limit Switch
R1 2 7/16	Fan Bushing
R1 2 7/8	Motor Bushing
R1394P026	BOLT
R287P04	FITTING
R287P04L	FITTING
R287P06	FITTING
R287P08L	Fitting
R287P10	FITTING
R287P12	Fitting
R287P12L	NIPPLE
R289P06	ELBOW, TUBE
R289P10	Fitting
R291P06L	Fitting
R291P08L	Fitting
R294P04	FITTING
R297P02	Wire
R297P04	WIRE, NONELECTRICAL, STEEL CRES ALY
R2V12-333	Pressure Relief Valve
R304P2A	Gasket
R306ET22AA11	In-Line Manifold
R306ET22BA11	In-Line Manifold
R413937	NUT
R413P02	Nut
R413P33	NUT
R413P41	Nut
R417P1	Nut
R4425-V90	O-RING
R4V0653310A1	Pressure Relief Valve
R5077B090B	HOSE
R5077B100B	HOSE
R5078B172B	HOSE
R5079F174B	Hose
R584P05SL	Bolt
R584P18U	BOLT, MACHINE, DBL HEX HD, 0.250-28 BY 1.312

## Starfish PPS - Complete Catalog

Part Number	Description
R6W02033VO	Diode
R6W12033VO	Diode
R8900-F	SEAL, FILTER HOUSING, O-RING
R900205510	Valve, Assembly
R900357576	Kit, Seal, Solenoid Valve
R900730182	Transducer
R902073462	Starter Motor
R909441692	Solenoid 24V
R928006646	Filter Element
R928010115	FILTER
R928046571	FILTER
RAO08702	ACCELEROMETER
RAO20093	MODULE, INTERFACE
RAO20139	Driver
RAO21076	Woodward Driver
RAO21076-AR	WOODWARD DRIVER
RASW-94-60	STRAINER
RC778NZ097Z	DP INDICATOR, VISUAL, 100PSID
RC861CZ097H	SWITCH
RC861CZ097Z	SWITCH
RCBX12-21	AC Unit
RCBX16-21	AC unit
RCBX24-21	AC; Explosion Proof, 2 ton
RCBX36-21	AC Unit
RCN-2007A	PUMP, JACKING,
RCN-2029	Pump, Jacking Oil
RCN1970	Pump, Jacking Oil
RCN1970-AR	PUMP, JACKING OIL
RCN1970-OH	Pump, Jacking Oil
RCN1970A	Pump, Jacking Oil
RCN1970B	Pump, Jacking Oil
RCN2007A	PUMP, JACKING,
RCN2029	Pump, Jacking Oil
RCO10322	CABLE, OFF-ENGINE
RCO260394301	Filter
RCO263580282	FILTER, SYNTHETIC OIL, MAIN
RCO369481121	Oil Filter
RCO39719	CABLE, STAGING VALVE
RCO39720	CABLE, STAGING VALVE
RCO39721	CABLE, TVBV/VSV/IGVO
RCO39722	CABLE, IGV/LVDT, LEFT
RCO39723	CABLE, IGV/LVDT, LEFT
RCO39724	CABLE, XN25
RCO39725	CABLE, CHIP DETECTOR, A/B
RCO39726	CABLE, VB/VSV/VDT, LEFT
RCO39727	Cable
RCO39728	Cable
RCO39729	CABLE, VB/VSV/LVDT, RIGHT
RCO39730	CABLE, STAGING VALVE
RCO39731	Cable
RCO39732	CABLE, T/C T48, RIGHT
RCO39733	CABLE, T/C T48, LEFT

## Starfish PPS - Complete Catalog

Part Number	Description
RCO39734	CABLE, CDP, 16TH STAGE BLEED VALVE
RCO39735	CABLE, 8TH STAGING BLEED VALVE
RCO39736	Cable
RCO39737	CABLE, STAGING VALVE, GAS SWITCH
RCO39738	CABLE, TEMP, LUBE & SCAVENGE, SUPPLY
RCO39740	CABLE, IGNITION TRANSFORM
RCO39742	Cable
RCO39743	CABLE, CHIP DETECTOR, C/D/E/COMM
RCO39757	CABLE, XN25
RCO39758	CABLE, CHIP DETECTOR
RCO39759	CABLE, LUBE, RTD
RCO39760	CABLE, LUBE, RTD
RCO39762	CABLE, XNSD
RCO39764	CABLE, T/C, T48
RCO39765	CABLE, T/C, T48
RCO39766	CABLE, CDP
RCO39767	CABLE, VBV/VSV/LVDT
RCO39768	CABLE, T/C, T3
RCO39770	CABLE, RTD, T2
RCO39771	CABLE, RTD, T2
RCO39773	CABLE, CHIP DETECTOR
RCO39774	CABLE, IGNITION TRANSFORM
RCO39781	CABLE, VBV/VSV/LVDT, RIGHT
RCO39782	CABLE, STAGING BLEED VALVE
RCO39783	CABLE, RTD, T2
RCO40002	CABLE, T4.8
RCO40004	CABLE, T/C, DUAL, T3
RCO40320	CABLE, OFF-ENGINE
RCO40358	CABLE, OFF-ENGINE, TM2500
RCO410331	CABLE, OFF-ENGINE
RCO410332	Cable, Off-Engine
RCO410335	CABLE, ELECTRICAL, VIBRATION
RCO41345	CABLE, XN44A LPC-IPT ROTOR SPEED
RCO41348	CABLE, VIBRATION
RCO43926	CABLE
RCO43932	CABLE
RCO43933	CABLE, RTD
RCO43946	CABLE, BLEED VALVE
RCO43948	CABLE, DUAL RTD/VSV/LVDT
RCO43949	CABLE, CHIP DETECTOR
RCO43950	CABLE
RCO43953	CABLE, VSV
RCO43954	CABLE, T3
RCO43994	CABLE
RCO43995	CABLE
RCO47369	CABLE, STAGING VALVE, LEFT
RCO47447	CABLE
RCO50665	Cable
RCO5300875	CABLE, PT SPEED NPT
RCO84224	CABLE, NGG1 GG SPEED
RCO85220	Cable
RDM312-SP-2DC	MODULE, DISPLAY, SATEC

Starfish PPS - Complete Catalog

Part Number	Description
RDQ17466	Nut
RE0016-05	Breaker
RE10731	CONNECTOR, PRESSURE TERMINAL
REO059230000	KIT - PCBA REPLACEMENT, QUICKTRIP
RFL-875S	TRANSDUCER, LVDT
RFR331030000	INSERT
RFR331220000	Insert
RG34155-6 Romec	Lube & Scavenge Pump
RGASKETX172	Gasket, Set
RGASKETX232	Gasket, Set
RH1-TP/FL	Hub, Ethernet, Rail
RH1522-014	MAGNETIC HALL SENSOR
RH4B-U-DC-24V	RELAY, 24VDC COIL, 4PDT
RJO04208	PROBE, VIBRATION, REVERSE MOUNT
RJO04247	VIB PROBE
RJO04249	PT KP PROBE
RJO04868	SENSOR, SPEED, PT
RJO05385	PT KP PROBE
RJO06015	Clutch
RJO06015-AR	CLUTCH, AS REMOVED
RJO06017	Clutch
RJO06039	Clutch
RJO219970023	Accelerometer
RJO219970024	Accelerometer
RJO219970025	Accelerometer
RJO219970026	Accelerometer
RJO219970027	Accelerometer
RJO219970028	Accelerometer
RJO5385	PROBE, KEYPHASER
RK5334	
RLO01267	GSOV, Woodward
RM00100201000	Block RM 20
RM00100301000	Block RM 30
RM2000GE-MODBUS	RELAY, PROTECTION, REMOTE MONITOR
ROA S-375	Pump, Low Pressure
ROAIII S-375	Pump, Low Pressure
ROHA S-375	Pump, High Press
RP0019-09	CAP,ELEC,75V,37000UF,2.5-IN
RPACKX00012	Kit, Repair, Packing
RPGCCWN-3800PSI-ZBW	VALVE, RELIEF
RPM074	Meter, Remote Power
RPQ54103	Stud
RPS12V	POWER SUPPLY
RR-56082	SENSOR, FLAME
RR0633961311	Detector
RR35230 - AR	PUMP, LUBE AND SCAVENGE
RR8	RELAY WITH PILOT
RRO00148	Flame Sensor
RRO00149	FLAME TRACKER
RRO00345	FLAME TRACKER
RRO56082	SENSOR, FLAME
RS-E2-0285	CABLE, UV FLAME DETECTOR

Starfish PPS - Complete Catalog

Part Number	Description
RS-E2-0285P003	Interconnecting 60 Foot Cable
RS-E2-0285P011	CABLE, UV FLAME DETECTOR
RS-E2-285	CABLE, UV FLAME DETECTOR
RS-FS-9001	Flame Sensor
RS-FS-9004	FLAME TRACKER
RS-FS-9006	Flame Sensor
RS-FS-9009	FLAME TRACKER
RS-FS-9009-03	FLAME TRACKER
RS-FS-9009-03-173	FLAME TRACKER
RS-FS-9100	FT LITE
RS2-4TX	SWITCH, RAIL
RS2-4TX/1FX	SWITCH, RAIL
RSM RKC 5711-3M	CABLE, TURCK
RT00028	QUICK COUPLING
RT00029	QUICK COUPLING, NIPP
RTO02703	ELEMENT, TEMP
RV-46412	SCREW
RVG15-25	TRANSDUCER, ROTARY
RVO237735210	Woodward GS6 valve
RVO237735210-OH	Overhauled Woodward GS6 valve
RVO45002	Pressure Relief Valve
RVO518360000	GSOV, Woodward
RVO518360500	GSOV
RVO518361000	GSOV, Woodward
RVO90440	Valve, Fuel
Rental	Tooling Rental
Repair-Kit,2in,85-150200-000,WST-FS	Repair Kit
Repair-Kit,3in,85-170200-000,WST-FS	Repair Kit
Rotex 42 Insert, Orange	Coupling Spider
Rotex 42 Insert, Yellow	Insert, Spider
Rotex 48 Insert, Purple	INSERT, SPIDER
Roxtec	Wall Penetration Seal
S-5168	DESSICANT
S017651202	Grease, Coupling, Brush
S018713133	Compound, Sealing
S018757126	Detector, Temp
S024371603	Adaptor
S025281528	Heater
S025281572	Heater, Stator
S025281852	Heater, Exciter, Set of 2
S025384182	Gland, Brass
S025711425	Fuse, Brush
S025711428	FUSE Brush
S025771163	Relay
S02577502	PROTECTION UNIT
S028239088	Diode
S028239089	Diode
S029812762	THERMOCOUPLE, BRUSH
S102618PD3S144B0	RTD
S132774704	Fuse
S187111115	Non-Setting Gasket and Jointing Compound
S19350PDPD3S48B0	RTD

## Starfish PPS - Complete Catalog

Part Number	Description
S26-58622-0	Adapter
S2A	LVDT Signal Conditioner
S311722702	Weight, Balance, Generator
S311735202	Key, Machine
S312402403	PLATE, FUSE LOCKING
S312402408	PLATE, FUSE LOCKING
S312402409	PLATE, FUSE LOCKING
S3124245501	RTD
S312559801	Gasket, Endframe (set of 2)
S312986501	DIODE WHEEL
S313012411	Gasket, Bearing (Set of 2)
S313033201	Temp Detector
S313174401	DIODE
S313174501	FUSE, 250V, 1000A
S313223712	Hose Assembly
S313223713	Hose, BRUSH
S313223714	Hose, BRUSH
S313223717	Hose, BRUSH
S313223719	Hose, Brush
S313223720	HOSE
S313223721	Hose
S313240102	Temp Detector
S313273905	HOSE, LUBE BRUSH
S313382718	Gasket, Bearing
S313448702	Gasket, Endframe (set of 2)
S313535601	GASKET,BEARING,(SET OF 2)
S313568201	VALVE, NON RETURN
S313825201	Gen Lube Pump
S313925005	BRACKET, MOUNTING POST
S313925701	ASSEMBLY: BRUSH HOLDER
S313941901	HOSE, LUBE BRUSH
S314011101	GASKET,BEARING,(SET OF 2)
S314023404	Hose, Lube
S314023412	HOSE
S314023414	Hose, Lubrication
S314081801	RTD, Dual
S314089901	Lube Pump
S314096901	ADAPTER
S314097101	Seal, bonded
S314149411	SEAL, OUTBOARD
S314149412	SEAL, INBOARD
S314149413	Shaft Seal, DE, OB
S314149414	Seal, IB
S314245501	TEMPERATURE DETECTOR - DUPLEX
S314263801	Coupling, GLO
S314263801-ALT	Coupling, Brush, Mech Lube Pump
S314263801-ALT-BLoad	GLO Lube Pump Coupling w/ Flex Element
S314415402	Heater (Stator)
S314428801	Fuse
S314513901	WEIGHT, BALANCE, ROTOR
S314712001	PLATE
S314816002	Gasket, Exciter

Starfish PPS - Complete Catalog

Part Number	Description
S314853502	Gasket, Exciter (set of 2)
S315236618	KIT, Bearing Feed Inlet
S316657502	Gasket, Exciter (set of 2)
S317187201	Gasket, STR Terms (set of 2)
S317436001	Stator Gasket Set
S317520801	DETECTOR, TEMP
S317520809	Temperature detector
S317638301	Gasket (set of 2)
S317658401	INSULATOR, BUSHING
S317684302	BEARING, BUSHING, COMPLETE, INSULATED
S317684402	BEARING, BUSHING, COMPLETE, INSULATED
S317695902	Temp Detector
S317696801	Seal, Brush, NDE, Outer
S317713601	Gasket, Exciter
S317715101	Gasket, Bearing (Set of 2)
S317734800	Seal, Brush Bearing, DE
S317734900	Seal, Brush Bearing, NDE
S317741201	KIT: RECTIFIER, INDUSTRIAL, SPARES
S317743442	Temperature Detector
S317779401	HOSE
S3178447-1	LVDT
S317929001	BUSHING, BEARING
S317931101	Bearing, Brush
S317946701	Gen Lube Pump
S317947301	Coupling, GLO
S317947301-ALT	Coupling, Brush, Mech Lube Pump
S317947301-ALT-BLoad	GLO Lube Pump Coupling w/ Flex Element
S317947301-ALT-BLoad Element	FLEX ELEMENT FOR ALTERNATE COUPLING
S317947301-ELEMENT	COUPLING, ALT-ELEMENT
S317978707	Filter, Air
S317987076	Power Supply
S317988102	Heater
S318347607	ASSEMBLY: BRUSH, EARTHING
S318347608	ASSEMBLY: BRUSH, EARTHING
S318347698	Gasket
S318761855	Switch, Float
S318930017	Make-Up Air Filter, Generator
S318992501	PLATE, LOCKING, SET OF 20
S319875101	FILTER, AIR, SET OF 2
S320965901	Kit, Rectifier Spares
S321371301	KIT, RADIAL JACKING OIL
S321400001	KIT, AXIAL OIL JACKING HOSE
S326NA2S36B0	Thermocouple RTD
S386A3317P0001	Gasket, Bearing (Set of 2)
S3FSSPFLTT050	VALVE, HIGH PRESSURE
S4GX46	Shell Turbo Oil
S4X32	Turbine Lube Oil
S500-1-R	Fuse 1 A
S500-100-R	Fuse 100 mA
S500-2-R	Fuse 2 A
S500-250-R	Fuse 250 mA
S500-5-R	Fuse 5 A

Starfish PPS - Complete Catalog

Part Number	Description
S598931983Z	VALVE, SOL, BLEED AIR, REPLACEMNT
S701765801	Lube Pump, Counterclockwise
S701849400	Coupling, Replacement
S701849401	Coupling, Replacement
S701849401ALT-BLoad	GLO Lube Pump Coupling w/ Flex Element
S701849500	Coupling, Replacement
S701849501	Coupling, Replacement
S701849501-ALT-BLoad	GLO Lube Pump Coupling w/ Flex Element
S704012801	DETECTOR, AERIAL, ROTOR, EARTH FAULT
S7131A116208U	Immersion Heater
S840012001	BRUSH, CARBON
S840012101	BRUSH HOLDER AND CLAMP
S840012101-Spring	Replacement spring
S840013102	Temperature Detector
S840013202	Temperature Detector
S840013210	Temp Sensor
S840014402	Temp Detector
S840019502	Transducer, Proximity
S840019503	Transducer, Proximity
S959200700	Handbook for (R10) REFM
S959202000	Handbook for A30
S960293300	MAVR Auto Power Card
S960294300	MAVR Power Factor Control Card
S960294700	MAVR Voltage Monitor Card
S960708700	Electronic Hand Control Card
S9608470	Excitation Limiter
S960847000	Excitation Limiter
S960848800	MAVR Excitation Monitor Card
S961159200	MAVR Control Card
S961502100	TRANSMITTER, ROTOR, EARTH FAULT
S961503300	RECEIVER, FAULT, ROTOR EARTH, R10; PCB
S961503700	AERIAL, ROTOR, EARTH FAULT
S961517500	MAVR Exitation Limiter Card Type B
S961529800	Card, MAVR, A30 Utilities
S961752200	A30 - BPL
S961755400	A30 Extender Card
S962243100	CARD, MAVR MAIN CONTROL
S962243400	Card, A30/Micro AVR Standby
S962243700	CARD, MAVR A30/MONITOR
S962425300	Card, MAVR, A30 Auxillaries
S962602800	Rack Chasis
S962608900	A30 Con Complete
S962609000	A30 Mon Complete
S962609700	Cable, Com Cab
S962609800	AVR HMI Software
S962609900	C10 Low Speed Detector
S962615908	Fuse, Semiconductor
S962615909	Fuse 5 A
S962615912	Fuse 250 mA
S962615913	Fuse 1 A
S962615914	Fuse 100 mA
S962615921	DIODE PACK

Starfish PPS - Complete Catalog

Part Number	Description
S962615922	THYRISTOR
S962615926	Motorised Pot Drive Unit
S962615935	Relay, 125VDC
S962615936	Fuse 2 A
S963001810	TRANSFORMER
S963047300	Receiver assembly
S963091001	R10 RECEIVER, ROTOR, EARTH FAULT
S963097600	FUSE, 80000 AMP
S963100901	A30 AVR System
S963150501	C10 Low Speed Detector
S963191901	PRISMIC, MODEL R10, FIELD GROUND DETECTOR, EA
S963192001	PRISMIC, MODEL R10, FIELD GROUND DETECTOR
S963194001	STABILIZER, T10 POWER SYSTEM
S963243101	PRISMIC, MODEL R10, FIELD GROUND DETECTOR, EA
S963303001	R10 ROTOR EARTH FAULT MONITOR
S963343201	A30 Con Complete
S963359201	Standby
S963416101	A30 Standby Card
S965011504	R10 RECEIVER, ROTOR, EARTH FAULT
S965011515	Receiver assembly
S965011518	REFM Receiver
S965011518 Ethos - list is \$10K	REFM Receiver
SB-04-04	REDUCER, QUICK CONNECT
SB0006A	KIT, COUPLING
SBM 56-2	Battery, 2 Cell
SCM7B34-1582	RTD Input
SCM7B34-1583	RTD, 200 OHM
SCM7B47K-1509	INPUT, TC, TYPE K
SCM7B47K-1574	Converter - Isolated Linearized
SCM7BPT-1460	Converter - Non-Isolated Pass Through
SD7201D20-AA	AMPLIFIER
SE-O-HF64-V	O-RING
SE-SW5U-SC	SWITCH, ETHERNET
SE8E	Igniter
SECO77-4/14	KIT, SEAL, COPPER
SELA36AI007	Breaker, Motor Control
SELA36AI0100	Breaker
SELA36AT0030	Breaker, 3P 600V 30A
SER1-03-10-0001	FOD SOCK
SF02002CF-316SS	Coalescer Panel, inlet
SF1530PVW4-X25-140	Thermostatic Valve
SF1530PVW4-X53-140	VALVE, THERMO, CONTROL
SFLA36A0250	Breaker
SFLA36AT0250	Breaker
SGH2-00200	ISGH FILTER
SH4B-05	SOCKET, SURFACE MOUNT
SHIMS	Shims
SK011509	Front Panel Adapter
SL-QX2GR05SRA	Switch
SLX-10MG-1	Ethernet ring switch
SLX-18MG-1	Switch, Ring, Ethernet
SLX-6ES-4SC	Switch, Ring, Ethernet

## Starfish PPS - Complete Catalog

Part Number	Description
SLX-6RS-4SC	SWITCH, ETHERNET, 6 PORT
SLX-6RS-4ST-D1	ETHERNET RING SWITCH, 4-10/100
SLX-8MS-4SC	Switch, Ethernet, 8 Port
SLX-9ES-2SC	Switch, Ring, Ethernet
SLX-9ES-2ST	SWITCH, ETHERNET
SMO0411347	INNER/OUTER TIP ASSEMBLY
SMO1610219	GAS STAGING VALVE
SMO1654609	Sensor, Speed
SMQ25654	Bushing
SMR-A41241-S	Servomotor
SMR-A41271-S	Servomotor
SMTB4TBCSFRT	Test Block 20A 400V
SMTB4TBVSFRT	TEST BLOCK & PLUG
SN7S/002268F	Filter, Inlet
SNGF/000230F	Filter, Inlet
SO659A185G0004	BACK PLATE & SPRING ASSEMBLY, SHAFT GROUNDING
SP170	24V 170W SOLAR PANEL
SPASI23	ANALOG INPUT MODULE ABB SYMPHONY PLUS
SPFEC12	MODULE, INPUT
SPME-16-16U	FITTING, TUBE, #16MORB X 1 IN TUBE 90
SPPS STRT-DRAIN	Start Hose Drain
SPPS STRT-RET	Start Hose Return
SPPS STRT-Supply	Start Hose Supply
SPS917-2	Board, Circuit, HIGH VOLTAGE, PCB95 VSR175
SPXCDXSO1SS	SENSOR, OXYGEN
SR-6024-6	RTD, Dual
SR-9631G001	RTD, Dual
SR1000-124	INVERTER, DC-AC
SR1000T-124	INVERTER, DC-AC
SR1H-4A3EM-6-6C6-GF66C	RTD Assembly
SR71225-OH	KIT, COUPLING OVERHAUL
SRD08-00002	IGBT DF200R12KE3 VSR100 / VSR175
SRD08-00003	IGBT FD200R12KE3 VSR100 / VSR175
SRD09-00002	CAPACITOR .47UF 1200V for VSR100 / VSR175
SRD09-00031	CAPACITOR 3300UF 400V VSR100 / VSR175
SS-0306-N-04	Jam Nut
SS-1210-6	SWAGELOK TUBE UNION 3/4"
SS-1210-6-10	SWAGELOK REDUCING UNION 3/4" X 5/8"
SS-1610-2-12ST	Adapter, 90 Deg
SS-1610-2-16	ADAPTER, 90
SS-1610-2-16PD-E-118	ADAPTER, 90
SS-1610-2-16ST	1 IN. TUBE OD X 1 5/16-12 SAE/MS STRAIGHT THREAD
SS-1610-3	SWAGELOK UNION TEE 1"
SS-1610-6	SWAGELOK TUBE FITTING, UNION 1"
SS-1610-6-8	SWAGELOK REDUCING UNION 1" X 1/2"
SS-1610-F16-150	ADAPTER, FLANGE
SS-20-RB-16	REDUCING BUSHING 1 1/4" MALE NPT X 1" FEMALE NPT
SS-20-TA-7-20	SWAGELOK TUBE ADAPTER
SS-2000-2-20	SWAGELOK MALE ELBOW 1 1/4" TUBE OD X 1 1/4" MALE NPT
SS-2000-6	SWAGELOK 1 1/4" UNION
SS-24-AN-1-16	SWAGELOK AN ADAPTER

Starfish PPS - Complete Catalog

Part Number	Description
SS-2400-1-20	SWAGELOK MALE CONNECTOR 1 1/2" OD X 1 1/4" MAL
SS-2400-6	UNION
SS-2400-9	SWAGELOK 1 1/2" UNION ELBOW
SS-25MO-1-16BM	Swagelock 1
SS-2701-04-04	90-Degree Stainless Adapter
SS-2702-04-04	45-Degree Stainless Bulkhead Adapter
SS-2703-04-04-04	Bulkhead Branch Tee Stainless Adapter
SS-2F-K4-2	FILTER, ELEMENT
SS-400-C	SWAGELOK 1/4" CAP
SS-6801-04-04-NWO	90-Degree Stainless Adapter
SS-6801-06-06-FG	Fitting, Elbow
SS-6802-04-04-NWO	45-Degree Stainless Adapter
SS-6803-04-04-04-NWO	Branch Tee Stainless Adapter
SS-8-HRN-4	SWAGELOK HEX REDUCING NIPPLE 1/2" MALE NPT X
SS1210-3	SWAGELOK UNION TEE 3/4"
SSR10	Relay, Safety
SST7200	SWITCH, SPEED, DIGITAL
ST1050-016	O-RING
ST1540-06	Clamp
ST1540-10	Clamp
ST1946-010	O-RING
ST1946-113	O-RING
ST1946-136	O-RING
ST1946-222	O-RING
ST1946-241	O-RING
ST1946-910	O-RING
ST2283-113	PACKING, PREFORM
ST2283-121	PACKING, PREFORM
ST260SHEX	Basket, Strainer
ST260Z6B	O-RING
ST718-00-03ZXCO	Filter Element
STARA2210	A221 Portable pH Meter
STB1A2MW	QUAD-BOX, TERMINAL
STB1A2NW	QUAD BOX
STB2A2NW	BOX, JUNCTION, QUAD
STB5A2NW	CONDULET B
STD820-E1HC4AS-1-A-AH0-11S-E-00A0-00-0	Differential Pressure Transmitter
STS-2015-PST	Innova HMI LM 6000 MARK VI
STS-2015-PTC	Innova HMI LM 6000 MARK VI
STS-2015-PTC-SSGE	Innova HMI LM 6000 MARK VI
SV13NA10	PUMP, GOULDS
SV209N11T/A	PUMP
SW-50-100	SPEED SWITCH, OVERSPEED PROTECTION, ALARM, 2
SWAGELOK-316LOF	
Stands, LM6000	LM6000 Universal work stand, 2 Trunnion pedestals and 2 with attaching brackets
T10540800	O-RING
T24B734G01	SEAL, BEARING
T401	CURRENT OUTPUT & RELAY
T501.10	POWER SUPPLY
T6CM-B10-1R01-C1	PH VANE PUMP
T6CMB101R01C5	PH VANE PUMP

## Starfish PPS - Complete Catalog

Part Number	Description
T6CY-017	PUMP, HYDRAULIC
TA4T6SL411	SOLENOID, 24V
TBVO BOLT KIT	KIT: HARDWARE, TBV ORIFICE
TCCS-10LM6-16-NF	NOZZLE, WATER
TEC36007	Motor Circuit Protector Breaker 3P7A600V
TEFR1	Handle
TEY230	BREAKER, CIRCUIT, 30 AMP
TH-1000-16F0-25	Valve, Thermostatic
TH7325	Thermostat
THMG3X-3000SR	LVDT
THQL1130	BREAKER, 30 AMP GE PLUG IN
THREEBOND 1215	ADHESIVE, LIQUID GASKET
TJC36400G	Molded Case Circuit Breaker, 400A, 3Ph, 600V
TM-900020	Filter, H2O Injection Skid
TM-900021	Filter Element
TM-900022	Filter, H2O Injection Skid
TM-900025	Filter
TM-900027	Filter Element
TM-900052	DUPLEX, GAS, FUEL, 3" 3um
TM-900344	Filter Element
TM7S/00268AM	Filter, Inlet
TMF BRACKET	Turbine Midframe Bracket
TMF Bottom Support	Tubine Midframe Bottom Support with Pedestals
TMO-30315E2T2XX	Turbine lube oil Tank Heater and Thermostat
TMO-30415E2T2XX	Generator Lube Oil Tank Heater
TMR-S-00700-XHT-API-SS10-F	Filter Element
TMR-S-00700-XHT-API-SS10-V	Filter Element
TMR-S-0663-API-PF010-V	Water Injection Pump Discharge Filter
TMR-S-1100-UPG-10-XHF-V	Element, Filter
TMR-S-200-CC10-V	Filter, Element, Sprint
TMR-S-320-A-GF010-V	Filter, H2O Injection Skid
TMR-S-620-CC-05-V	Liquid Fuel Filter Element
TMR-S-620-CC05-V	Liquid Fuel Filter Element
TMR-S-620-CC10V	Filter, Element
TMR-S-710-H-CC3-V	DUPLEX, GAS, FUEL, 3" 3um
TMR-S-710-HCC3-V	DUPLEX, GAS, FUEL, 3" 3um
TMR-S-860-D-UPG-F	FILTER CARTRIDGE
TMR-S200-CC10V	Filter, Element, Sprint
TMR-S320-A-CC25-V	Filter, H2O Injection Skid
TMR-S320-A-GF-020V	Filter, H2O Injection Skid
TMR-Z-320-A-GF006-V	Filter
TMR-Z320-GF006V	Filter
TPM-30-24V-U1	RECTIFIER MODULE, 30 AMP 24 VDC
TR150R	FUSE
TRF BOLT KIT	KIT, BOLT, TRF TO EXHAUST DIFFUSER
TRM2	FUSE, 2A
TRM5	FUSE, 5A
TRN16282	Thermocouple
TRN16283	Thermocouple
TRN16284	Thermocouple

Starfish PPS - Complete Catalog

Part Number	Description
TRN17444	Thermocouple
TRS3R	FUSE, 3A
TRS6R	FUSE, 6A
TSS32S30	CLAMP
TSU151	GENERATOR, SIGNAL, PRECISION
TT285N12KOF	Thyristor Module
TURKISH SURPLUS	8MM, 150GR
TURKISH SURPLUS BULLETS	8MM, 150GR
TXL-L1S-Q10	SWITCH, TEMPERATURE
TZ1032GK100-8	Jeumont Honsburg Flow Meter
Thyro-Tool Family / Pro Version	Software for Thryo-Tool Family
U-51111	Cable, Turck
U252EO85U0020	Thermocouple
U252J085G0072	THERMOCOUPLE
U252K085U0032	Thermocouple
U252K085U0034	Thermocouple
U252K085U0040	Thermocouple
U252K088U0020	Thermocouple
U252K088U0026	THERMOCOUPLE
U252K088U0030	Thermocouple
U252K095U0016	Thermocouple
U336W034D0156	Gasket
U336W060D0178	Gasket
U336W062D0462	GASKET, .. VALVE,CAP, 4-5/8"1D X 5-7/8"OD, METAL, ROU SINGLE
U336WI00DI756	GASKET, .. LOWER HD, 17-9/16"ID X 19-9/16"OD, METAL THK, SINGLE
U3HSSVT.125SS	Check Valve
U3HSSVT.500SS	Valve, check
U408A306L0262	PIN
U408A306L0438	Pin
U408A308L0437	Pin
U408A408L0162	Pin
U409A308L0518	Pin
U409A312L0638	Pin
U605P318L1888	Stud
U605P824L3812	Stud
U606P321L2125	STUD
U606P816L1190	Stud
U607P321L2075	Stud
U613P211	NUT, STEAM TURBINE
U613X000P0112	1.5" , 8 Hex Nut
U613X000P0208	Nut
U613X000P0210	Nut
U613X000P0218	Nut
U614X000P0210	Nut
U614X000P0211	Nut
U614X000P0214	NUT, TURBINE, COVERED, 1-3/4" DIA, 2-1/4 CHROME, 8
U615X000P0220	Nut
U615X000P0416	Nut
U615X000P0418	Nut
U615X000P0424	Nut
U615X000P0425	Nut

Starfish PPS - Complete Catalog

Part Number	Description
U619P308L0438	Stud
U623P208L0550	Bolt
U623P210L0637	Bolt
U623P212L0400	Bolt
U623P307L0275	BOLT, VALVE COVER
U623P308L0500	Bolt
U623P309L0500	Bolt
U623P310L0375	BOLT, GUIDE
U623P310L0600	Bolt
U624P206L0825	Bolt
U624P206L0950	Bolt
U624P206L1200	Bolt
U624P208L0800	Bolt
U624P208L0850	BOLT
U624P210L0850	Bolt
U624P212L0450	Bolt
U624P212L0850	Bolt
U624P308L0238	BOLT, SOCKET HEAD
U624P308L0325	Bolt
U624P308L0338	SCREW
U624P308L0375	BOLT, ., 1" DIA, 3-3/4" LTH, 8UN, STEEL, SOCKET HD, TU
U624P308L0900	Bolt
U624P308L1112	Bolt
U624P310L0750	Bolt
U624P310L0800	BOLT, HEX SOCKET HEAD
U624P310L0900	Bolt
U627P206L0568	Bolt, Hex
U627P308L0362	Bolt
U627P311L0400	BOLT, HEX HEAD
U628P201L0062	SCREW
U695C016N0875	Packing Spring
U695D002N0928	Packing Spring
U695D016N0928	Packing Spring
U8108D1250H14	Tooth, Oil Deflector
U8108D1275H14	Oil Deflector
U8108D1775H14	Tooth, Oil Deflector
U810P306L0175	SCREW, CHAMBER
U817P102W2000	Shim
U818P103W2000	Shim
UA-1474-01	CABLE, ELECTRICAL, IGV/LVDT/XN2, RIGHT
UA-1480-01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, A/B/C
UA-1481-01	CABLE, ELECTRICAL, TEMP LUBE & SCAVENGE, E SU
UA-1482-03	CABLE, SPEED, GAS GENERATOR
UA-1482-04	CABLE, SPEED, GAS GENERATOR
UA-1486-01	CABLE, ELECTRICAL, VBV/VSV/LVDT; RIGHT- ON ENGI
UA-1492-04	CABLE, VBV/VSV/IGV
UA-1493-04	CABLE, MANIFOLD TEMPERATURE
UA-1494-04	CABLE, CHIP DETECTOR, A/B
UA-1494-05	CABLE, CHIP DETECTOR, A/B
UA-1496-04	CABLE, TEMP LUBE & SCAVENGE
UA-1497-04	CABLE, TEMP LUBE RTD, D&E SUMPS
UA-1498-04	CABLE, XN25 SPEED

## Starfish PPS - Complete Catalog

Part Number	Description
UA-1499-03	CABLE, XNSD SPEED
UA-1502-03	CABLE, EGT THERMOCOUPLE, RIGHT
UA-1518-04	CABLE, TEMP COMPRESSOR DISCHARGE, T3
UA-1559-01	CABLE, CHIP DETECTOR, A/B/COM
UA-1561-01	CABLE, ELECTRICAL, VBV/VSV/LVDT, LEFT ON ENGINE
UA-1577-04	CABLE, CRF ACCELEROMETER
UA-1754-03	CABLE, ELECTRICAL, VSV/LVDT RIGHT/LEFT
UA-1754-04	CABLE, ELECTRICAL, VSV/LVDT
UA-1786-01	Harness
UA-1787-01	HARNESS, ELECTRICAL
UA-1802-01	CABLE, LPT, SPEED
UA-1802-02	CABLE, LPT, SPEED
UA-2101-01	CABLE
UA-2267-03	Cable, Speed, Right
UA-2267-04	Cable, Speed, Left
UD10A5M28W2C	DISPLAY, DCU
UD10A5N28W2	Transmitter, DCU
UD10A5N28W2C	DISPLAY, DCU
UD10S5M25W2N	DISPLAY, RELAY
UE310AS20Z	Filter Element
UE319AS20Z	UR319 SUCTION FILTER
UN-3-100-SS-V-1/2	Valve, check
UN-3-100-SS-V-1/8	Check Valve
UR319CD32++20ZE1YT33	FILTER HOUSING
UR319CD3220ZE1YT33	FILTER HOUSING
USB-100-BST	USB adapter
V	Relief Valve
V1000-007	O-RING
V1000-011	O-RING
V1000-014	O-RING
V1000-029	O-RING
V1000-030	O-RING
V1000-031	O-RING
V1000-034	O-RING
V1000-037	O-RING
V1000-043	O-RING
V1000-044	O-RING
V1000-050	O-RING
V1000-110	O-RING
V1000-112	O-RING
V1000-116	O-RING
V1000-118	O-RING
V1000-119	O-RING
V1000-120	O-RING
V1000-123	O-RING
V1000-128	O-RING
V1000-131	O-RING
V1000-134	O-RING
V1000-137	O-RING
V1000-138	O-RING

## Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
V1000-139	O-RING
V1000-140	O-RING
V1000-141	O-RING
V1000-143	O-RING
V1000-150	O-RING
V1000-151	O-RING
V1000-155	O-RING
V1000-156	O-RING
V1000-159	O-RING
V1000-161	O-RING
V1000-165	O-RING
V1000-169	O-RING
V1000-176	O-RING
V1000-212	O-RING
V1000-213	O-RING
V1000-215	O-RING
V1000-218	O-RING
V1000-222	O-RING
V1000-223	O-RING
V1000-225	O-RING
V1000-226	O-RING
V1000-228	O-RING
V1000-230	O-RING
V1000-232	O-RING
V1000-234	O-RING
V1000-235	O-RING
V1000-237	O-RING
V1000-242	O-RING
V1000-243	O-RING
V1000-258	O-RING
V1000-261	O-RING
V1000-263	O-RING
V1000-264	O-RING
V1000-265	O-RING
V1000-266	O-RING
V1000-270	O-RING
V1000-278	O-RING
V1000-279	O-RING
V1000-283	O-RING
V1000-441	O-Ring
V1000-5X91	O-RING, GLO FILTER HOUSING
V1000-904	O-RING
V1000-905	O-RING
V1000-908	O-RING
V1000-912	O-RING
V1000-914	O-RING
V1000-916	O-RING
V1000-920	O-RING
V1000-924	O-RING
V1000-954	O-RING
V1000-977	O-RING
V1005-330	O-Ring

## Starfish PPS - Complete Catalog

Part Number	Description
V1007-014	O-Ring
V1007-116	O-RING
V1007-210	O-RING
V1007-214	O-RING
V1007-219	O-RING
V1007-222	O-RING
V1007-225	O-RING
V1007-228	O-RING
V1007-380	O-RING
V1028-114	O-RING
V12F12-SS	QUICK COUPLING, NIPP
V33ZA70P	VARISTOR, RADIAL
V6EPB-S-S-3-S	Flow Switch
VAA-3321-316-33E-C471-D024	Solenoid Valve
VFK252C6100TTH2546BVXG1P1TAF	VALVE, SOLENOID
VI-2W3-CV	VICOR, DC CONVERTER
VI-LC14-EU-H1	POWER SUPPLY, 24VDC INPUT
VI-LC14-EU-H1-AR	POWER SUPPLY, AS REMOVED
VI-LCW3-IY	VICOR, DC
VI-PCW22-IYY	Power Supply
VIT-70-.210-C	Viton O-Ring Cord, .210 cross section
VIT-70-372	Viton O-Ring, Size 372, 8.725" I.D., .210 cross section
VL1073GE13-12	Gasket
VL1073GE13-16	Gasket
VL1073GE13-20	Gasket
VL1073GE13-24	Gasket
VL1073GE13-28	Gasket, Seal-Flange
VL1074GE14	Gasket, Seal-Flange
VL1175GE25-03	Seal Ring
VL1175GE25-05	E-SEAL, RING
VL1175GE25-08	E-SEAL, RING
VL1175GE25-10	E-SEAL, RING
VL1175GE25-12	Metal Gasket Ring, E Seal
VL1181GE25-17	Metal Gasket Ring, E Seal
VL1181GE25-24	Gasket, Liquid Fuel Mix Block
VL1222GE27	Gasket
VLM25E11	CABLE, RTD
VLM25E14	CABLE, NPT SPEED
VLM25E18	CABLE, RTD
VLM25E19	CABLE, DUAL ELEMENT, T2
VLM25E20	CABLE, T5:4
VLM25E31/E32	CABLE, TEMP, FUEL MANIFOLD
VLM25E35	CABLE, DUAL ELEMENT, T2
VLM25E3RTD	CABLE, RTD
VLM25E7	CABLE, NGG1 GG SPEED
VMK252C6100TTS1246BVBG1P1A	VALVE, DRAIN
VQCT118072-11	Filter
VQCT118072-18	Filter
VR1006-350	Clamp, Coupling
VR1006-400	Clamp
VR1006-450	Clamp
VSG-4322-E14-XXM-155-DO24	Valve, Solenoid

Starfish PPS - Complete Catalog

Part Number	Description
VSR175	NOx Water Pump+Motor Assembly, VFD (Overhauled)
VSR175-S484-AR	As Removed NOx Water Pump+Motor Assembly, VFD (Ov
VSR175-S484-OH	NOx Water Pump+Motor Assembly, VFD (Overhauled)
VSVF502C440TTA246BVXG1G1	VALVE, BLOCK, 2-WAY, COAX
VSVF503C440TTA246BVXG1G1	Valve, 3 way
W24NT1200	POWER SUPPLY, 240VDC TO 24VDC
W6268349003	Filter Assembly
W8000-20-W	Filter Regulator
WA3034	Lock wire termination Ferrule; -50 / magazine
WA47124	O-RING, SET
WA83802	O-Ring
WD-35617-50	Flexible Benchtop Electrode Holder
WD5000AAKX	HARD DRIVE, MARK VI
WF6560	Manual Pull
WFC02PS	SWITCH, HORN
WFCO2PS-A	Switch, CO2 Purge, Latching Relay
WFEFDC281KHA	SWITCH, HORN
WK251821	CO2 Hose
WK803370	NOZZLE, SIZE 5
WK803377	Nozzle, Size 8+
WK803378	Nozzle, Size 9
WK803379	Nozzle, Size 9+
WK803380	Nozzle, Size 10
WK803381	Nozzle, Size 2
WK872450	Plain Nut Discharge Head
WK967082	IND, DISCH, 3/4 POP-UP
WLT	PROBE, LEVEL TRANSDUCER
WLT-06N	PROBE, LEVEL TRANSDUCER
WP9012	Groundwater Purging Pump, 12V, 95' Cable
WV468-2000	Signal Conditioner/Isolator
Ward Kit 1	Ward Instrument Fitting & Hose/Tubing Kit
X0003HXX0AX0077X	PLUG, SQUARE HEAD
X0003HXX0AX007X	Plug, Forged
X3301A4N11W1	DETECTOR, FLAME
X3301S4M23T1	DETECTOR, FLAME
X54-600-1-2-2-DA	POWER SUPPLY
X9800A4N11W1	SENSOR, FLAME
X9800A4N14W1	SENSOR, FLAME
XA4AA	Kit, Diaphragm
XB4BVG35	LED Pilot Light, Green
XL31K5PA7	TRANSDUCER, ELECTRONIC WATT
XL31K5PA7-24-3-12-SC-CVR	Watt Transducer
XL31K5PA7-24-SC	Watt Transducer
XREF0155	Vibration Element
XREF0158	Fuel Gas Pressure Transmitter
XREF0203	Sensor, Temp
XREF0212	Transmitter
XREF0220	VALVE, SOLENOID
XREF0316	Filter, Element, Sprint
XREF75	RTD
XT20-1H3A-BAC	Top mounted float switch
XT31-002N-B0C	Switch, Level

Starfish PPS - Complete Catalog

<b>Part Number</b>	<b>Description</b>
YF105-NNNA3A-S3S3-E/FMF/SCT	METER, FLOW
YFC150	Filter
YS81-SS-1/2	Y-STRAINER
YS81-SS-1/2"-GASKET	GASKET, Y-STRAINER
YS81S0050	Y-STRAINER
YS81S0050MP	Magnetic Plug
Z1028-113	PACKING, PREFORM
Z1028-114	O-RING, HIGH TEMP
Z1028-121	PACKING, PREFORM
Z1352-113	PACKING, PREFORM
Z1352-121	PACKING, PREFORM
Z8670	Seal Kit
ZB2 BJ3	Selector Switch
ZOK 27	TURBINE COMPRESSOR WASH
iMOD096V083A23-02A	CAPACITOR